

AUTOMATIC TRANSMISSION

SECTION **AT**

CONTENTS

PREPARATION	AT- 2
PRECAUTIONS	AT- 3
A/T CONTROL DIAGRAM	AT- 4
ON-VEHICLE SERVICE	AT- 7
TROUBLE DIAGNOSES	AT- 11
REMOVAL AND INSTALLATION	AT- 75
MAJOR OVERHAUL	AT- 76
DISASSEMBLY	AT- 80
REPAIR FOR COMPONENT PARTS	AT- 91
ASSEMBLY	AT-136
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	AT-156

AT

When you read wiring diagrams:







- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".

PREPARATION

SPECIAL SERVICE TOOLS

*: Special tool or commercial equivalent

Tool number Tool name	Description	
ST2505S001 Oil pressure gauge set ① ST25051001 Oil pressure gauge ② ST25052000 Hose ③ ST25053000 Joint pipe ④ ST25054000 Adapter ⑤ ST25055000 Adapter		Measuring line pressure
ST07870000 Transmission case stand		Disassembling and assembling A/T
KV31102100 Torque converter one- way clutch check tool		Checking one-way clutch in torque converter
ST25850000 Sliding hammer		Removing oil pump assembly
KV31102400 Clutch spring compressor		Removing and installing clutch return springs
ST33200000* Drift	 <p>a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.</p>	Installing oil pump housing oil seal Installing rear oil seal


PRECAUTIONS

Service Notice

- Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transmission.
- When disassembling parts, place them in order in a parts rack so that they can be put back into the unit in their proper positions.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transmission is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place removed parts in order on a parts rack so they can be put back in the valve body in the same positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along their bores in the valve body under their own weight.
- Before assembly, apply a coat of recommended A.T.F. to all parts. Petroleum jelly may be applied to O-rings and seals and used to hold small bearings and washers in place during re-assembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- After overhaul, refill the transmission with new A.T.F.

A/T CONTROL DIAGRAM

Hydraulic Control Circuits




SAT123B

AT-4

A/T CONTROL DIAGRAM

Electrical Control Chart



Mechanical Operation

Shift position	Reverse clutch	High clutch	Forward clutch	Overrun clutch	Band servo			Forward one-way clutch	Low one-way clutch	Low & reverse brake	Lock-up	Remarks
					2nd apply	3rd release	4th apply					
P												PARK
R	○									○		REVERSE
N												NEUTRAL
D *4	1st		○	⊗				●	●			Automatic shift 1 → 2 → 3 → 4
	2nd		○	⊗	○			●				
	3rd		○	○	⊗	*2 ⊗	⊗	●				
	4th		○	⊗		*3 ⊗	⊗	○			○	
2	1st		○	⊗				●	●			Automatic shift 1 → 2
	2nd		○	⊗	○			●				
1	1st		○	○				●		○		Locks (held stationary) in 1st speed 1 → 2
	2nd		○	○	○			●				

*1. Operates when overdrive switch is set in "OFF" position.

*2. Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, because oil pressure area on the "release" side is greater than that on the "apply" side, brake band does not contract.

*3. Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

*4. A/T will not shift to 4th when overdrive switch is set in "OFF" position.

○ : Operates.

⊗ : Operates when throttle opening is less than 1/16. Engine brake activates.


● : Operates during "progressive" acceleration.

⊗ : Operates but does not affect power transmission.

⊗ : Operates when throttle opening is less than 1/16 but does not affect engine brake.


A/T CONTROL DIAGRAM

Cross-Sectional View



AT-6

SAT125B




Control Valve Assembly and Accumulators Inspection

1. Remove oil pan and gasket and drain A.T.F.



2. Remove oil strainer.

3. Remove control valve assembly by removing fixing bolts and disconnecting harness connector.

Bolt length and location


Bolt symbol	ℓ mm (in)	 ℓ
Ⓐ	33 (1.30)	
Ⓑ	45 (1.77)	

4. Remove solenoids and valves from valve body if necessary.
5. Remove terminal cord assembly if necessary.




6. Remove accumulator A, B, C and D by applying compressed air if necessary.

- Hold each piston with rag.
7. Reinstall any part removed.
- Always use new sealing parts.




Revolution Sensor Replacement

1. Remove rear engine mounting member from body panel while supporting A/T with jack.
2. Lower A/T assembly as much as possible.




3. Remove revolution sensor from A/T assembly.
 4. Reinstall any part removed.
- **Always use new sealing parts.**


Rear Oil Seal Replacement



1. Remove propeller shaft from vehicle. — Refer to section PD.
2. Remove rear oil seal.



3. Install rear oil seal.
- **Apply A.T.F. before installing.**
4. Reinstall any part removed.




Parking Components Inspection

1. Remove propeller shaft from vehicle. — Refer to section PD.
2. Remove rear engine mounting member from A/T assembly.


Parking Components Inspection (Cont'd)

3. Remove rear extension from transmission case.
 4. Replace parking components if necessary.
 5. Reinstall any part removed.
- Always use new sealing parts.




Inhibitor Switch Adjustment

1. Remove manual control linkage from manual shaft of A/T assembly.
2. Set manual shaft of A/T assembly in "N" position.
3. Loosen inhibitor switch fixing bolts.




4. Insert pin into adjustment holes in both inhibitor switch and manual shaft of A/T assembly as near vertical as possible.
5. Reinstall any part removed.
6. Check continuity of inhibitor switch. — Refer to "Electrical Components Inspection".



Manual Control Linkage Adjustment

Move selector lever from "P" range to "1" range. You should be able to feel the detents in each range. If the detents cannot be felt or the pointer indicating the range is improperly aligned, the linkage needs adjustment.

1. Place selector lever in "P" range.
2. Loosen lock nuts.




3. Tighten lock nut (X) until it touches trunnion pulling selector lever toward "R" range side without pushing button.
4. Back off lock nut (X) 1 turn and tighten lock nut (Y) to the specified torque.

Lock nut:

(Y): 11 - 15 N·m (1.1 - 1.5 kg-m, 8 - 11 ft-lb)

5. Move selector lever from "P" range to "1" range. Make sure that selector lever can move smoothly.



ON-VEHICLE SERVICE

NOTE

AT-10

TROUBLE DIAGNOSES

Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	AT-13
Preliminary Check	AT-14
A/T Electrical Parts Location	AT-25
Circuit Diagram for Quick Pinpoint Check	AT-27
Wiring Diagram	AT-28
Self-diagnosis	AT-30
SELF-DIAGNOSTIC PROCEDURE	AT-30
JUDGEMENT OF SELF-DIAGNOSIS CODE	AT-32
REVOLUTION SENSOR CIRCUIT CHECK	AT-36
SPEED SENSOR CIRCUIT CHECK	AT-36
THROTTLE SENSOR CIRCUIT CHECK	AT-37
SHIFT SOLENOID A CIRCUIT CHECK	AT-38
SHIFT SOLENOID B CIRCUIT CHECK	AT-39
OVERRUN CLUTCH CIRCUIT CHECK	AT-40
LOCK-UP SOLENOID CIRCUIT CHECK	AT-41
FLUID TEMPERATURE SENSOR CIRCUIT AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECKS	AT-42
ENGINE REVOLUTION SIGNAL CIRCUIT CHECK	AT-43
LINE PRESSURE SOLENOID CIRCUIT CHECK	AT-44
INHIBITOR, OVERDRIVE, KICKDOWN AND IDLE SWITCH CIRCUIT CHECKS	AT-45
Diagnostic Procedure 1 (SYMPTOM: O.D. OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".)	AT-47
Diagnostic Procedure 2 (SYMPTOM: Engine cannot be started with selector lever in "P" or "N" range or engine can be started with selector lever in "D", "2", "1" or "R" range.)	AT-48
Diagnostic Procedure 3 (SYMPTOM: Vehicle moves when it is pushed forward or backward with selector lever in "P" range.)	AT-48
Diagnostic Procedure 4 (SYMPTOM: Vehicle moves forward when setting "N" range.)	AT-49
Diagnostic Procedure 5 (SYMPTOM: There is large shock when changing from "N" to "R" range.)	AT-50
Diagnostic Procedure 6 (SYMPTOM: vehicle does not creep backward when selecting "R" range.)	AT-51
Diagnostic Procedure 7 (SYMPTOM: Vehicle does not creep forward when selecting "D", "2" and "1" range.)	AT-52
Diagnostic Procedure 8 (SYMPTOM: Vehicle cannot be started from D ₁ on Cruise test—Part 1.)	AT-53
Diagnostic Procedure 9 (SYMPTOM: A/T does not shift from D ₁ to D ₂ at specified speed. A/T does not shift from D ₄ to D ₂ when depressing accelerator pedal fully at the specified speed.)	AT-54
Diagnostic Procedure 10 (SYMPTOM: A/T does not shift from D ₂ to D ₃ at the specified speed.)	AT-55
Diagnostic Procedure 11 (SYMPTOM: A/T does not shift from D ₃ to D ₄ at the specified speed.)	AT-56
Diagnostic Procedure 12 (SYMPTOM: A/T does not perform lock-up at the specified speed.)	AT-57
Diagnostic Procedure 13 (SYMPTOM: A/T does not hold lock-up condition for more than 30 seconds.)	AT-58
Diagnostic Procedure 14 (SYMPTOM: Lock-up is not released when accelerator pedal is released.)	AT-58

TROUBLE DIAGNOSES

Contents (Cont'd)

Diagnostic Procedure 15

(SYMPTOM: Engine speed does not return to idle smoothly when A/T is shifted from D₄ to D₃ with accelerator pedal released.

Vehicle does not decelerate by engine brake when changing overdrive switch to "OFF" position with accelerator pedal released.

Vehicle does not decelerate by engine brake when changing selector lever from "D" to "2" range with accelerator pedal released.)

AT-59

Diagnostic Procedure 16

(SYMPTOM: Vehicle does not start from D₁ on Cruise test — Part 2.)

AT-60

Diagnostic Procedure 17

(SYMPTOM: Vehicle does not shift from D₄ on D₃ when changing overdrive switch to "OFF" position.)

AT-60

Diagnostic Procedure 18

(SYMPTOM: A/T does not shift from D₃ on D₂ when changing selector lever from "D" to "2" range.)

AT-61

Diagnostic Procedure 19

(SYMPTOM: Vehicle does not shift from 2₂ on 1₁ when changing selector lever from "2" to "1" range.)

AT-61

Diagnostic Procedure 20

(SYMPTOM: Vehicle does not decelerate by engine brake when shifting from 2₂ (1₂) to 1₁.)

AT-61

Electrical Components Inspection

AT-62

Final Check

AT-68


Symptom Chart

AT-72




TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



TROUBLE DIAGNOSES



Preliminary Check

A/T FLUID CHECK

Fluid leakage check

1. Clean area suspected of leaking, — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in "D" range and wait a few minutes.
3. Stop engine.

4. Check for fresh leakage.

Fluid condition check

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling — Overheating

Fluid level check

Refer to section MA.

TROUBLE DIAGNOSES

ROAD TEST PROCEDURE

1. Check before engine is started




2. Check at idle



3. Cruise test

SAT786A



SAT639A

Preliminary Check (Cont'd)

ROAD TESTING




Description

- The purpose of this road test is to determine overall performance of automatic transmission and analyze causes of problems.
- The road test consists of the following three parts:
 1. Check before engine is started
 2. Check at idle
 3. Cruise test
- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items. Troubleshoot items which check out No Good after road test. Refer to "Self-diagnosis" and "Diagnostic Procedure".


TROUBLE DIAGNOSES

Preliminary Check (Cont'd)


1. Check before engine is started



1
Park vehicle on flat surface.



2
Move selector lever to "P" range.




3
Does O.D. OFF indicator lamp come on for about 2 seconds?

No → Go to Diagnostic Procedure 1.

Yes
4
Does O.D. OFF indicator lamp flicker for about 8 seconds?

Yes → Perform self-diagnosis.
— Refer to SELF-DIAGNOSIS PROCEDURE.









Perform self-diagnosis.
— Refer to SELF-DIAGNOSIS PROCEDURE and note N.G. items.

Go to "ROAD TESTING
— 2. Check at idle".

TROUBLE DIAGNOSES







Preliminary Check (Cont'd)

2. Check at idle



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)




TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

3. Cruise test

- Check all items listed in Parts 1 through 3.
- Throttle position can be controlled by voltage across terminals ⑪ and ⑮ of A/T control unit.



Cruise test – Part 1

1

Warm up engine until engine oil and A.T.F. reach operating temperature after vehicle has been driven approx. 10 minutes.

A.T.F. operating temperature:
50 - 80°C (122 - 176°F)


Park vehicle on flat surface.

2

Set overdrive switch in "ON" position.

3

Move selector lever to "P" range.



4

Move selector lever to "D" range.

5

Accelerate vehicle by constantly depressing accelerator pedal half-way.





Does vehicle start from D₁?

No

Go to Diagnostic Procedure 8.






Yes

A



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

Cruise test – Part 2

Confirm overdrive switch is in "ON" position.

Confirm selector lever is in "D" range.

1 Accelerate vehicle by half throttle again.

Does vehicle start from D₁? No → Go to Diagnostic Procedure 16.

2 Accelerate vehicle to A km/h as shown in illustration.

3 Release accelerator pedal and then quickly depress it fully.

4 Does A/T shift from D₄ to D₂ as soon as accelerator pedal is depressed fully? No → Go to Diagnostic Procedure 9.







5 Does A/T shift from D₂ to D₃ at the specified speed?
Specified speed when shifting from D₂ to D₃:
Refer to Shift schedule. No → Go to Diagnostic Procedure 10.

6 Release accelerator pedal after shifting from D₂ to D₃.

7 Does A/T shift from D₃ to D₄ and does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 11.

Stop vehicle.






Go to "Cruise test – Part 3".



TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

Cruise test – Part 3



Confirm overdrive switch is in "ON" position.

Confirm selector lever is in "D" range.

1 Accelerator vehicle using half-throttle to D₄.

2 Release accelerator pedal.

3 Set overdrive switch in "OFF" position while driving in D₄ range.

4 Does A/T shift from D₄ to D₃? No → Go to Diagnostic Procedure 17.

Yes
5 Does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 15.

Yes
6 Move selector lever from "D" to "2" range while driving in D₃.

7 Does A/T shift from D₃ to 2₂? No → Go to Diagnostic Procedure 18.

Yes
8 Does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 15.

Yes
9 Move selector lever from "2" to "1" range while driving in 2₂.

10 Does A/T shift from 2₂ to 1₁ range? No → Go to Diagnostic Procedure 19.

Yes
11 Does vehicle decelerate by engine brake? No → Go to Diagnostic Procedure 20.

Yes
Stop vehicle.

Perform self-diagnosis. — Refer to SELF-DIAGNOSIS PROCEDURE.

TROUBLE DIAGNOSES

Preliminary Check (Cont'd)

Vehicle speed when shifting gears

Europe

Throttle position	Vehicle speed km/h (MPH)						
	D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	58 - 62 (36 - 39)	109 - 115 (68 - 71)	176 - 186 (109 - 116)	170 - 180 (106 - 112)	104 - 110 (65 - 68)	44 - 48 (27 - 30)	53 - 57 (33 - 35)
Half throttle	41 - 45 (25 - 28)	78 - 84 (48 - 52)	125 - 135 (78 - 84)	74 - 84 (46 - 52)	29 - 35 (18 - 22)	10 - 14 (6 - 9)	53 - 57 (33 - 35)

Except Europe

Throttle position	Vehicle speed km/h (MPH)						
	D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	54 - 58 (34 - 36)	101 - 107 (63 - 66)	164 - 174 (102 - 108)	158 - 168 (98 - 104)	95 - 101 (59 - 63)	44 - 48 (27 - 30)	53 - 57 (33 - 35)
Half throttle	41 - 45 (25 - 28)	73 - 79 (45 - 49)	119 - 129 (74 - 80)	78 - 88 (48 - 55)	34 - 40 (21 - 25)	10 - 14 (6 - 9)	53 - 57 (33 - 35)

Vehicle speed when performing and releasing lock-up

Europe

Throttle position	D ₄	
	Vehicle speed km/h (MPH)	
	Lock-up "ON"	Lock-up "OFF"
Full throttle	176 - 186 (109 - 116)	170 - 180 (106 - 112)
Half throttle	126 - 134 (78 - 83)	110 - 118 (68 - 73)


Except Europe

Throttle position	D ₄	
	Vehicle speed km/h (MPH)	
	Lock-up "ON"	Lock-up "OFF"
Full throttle	164 - 174 (102 - 108)	158 - 168 (98 - 104)
Half throttle	120 - 128 (75 - 80)	102 - 110 (63 - 68)

TROUBLE DIAGNOSES


Preliminary Check (Cont'd)

Shift schedule
Europe



SAT905B









Except Europe



SAT906B

TROUBLE DIAGNOSES


A/T Electrical Parts Location



SAT907B


TROUBLE DIAGNOSES

A/T Electrical Parts Location (Cont'd)



TROUBLE DIAGNOSES


Circuit Diagram for Quick Pinpoint Check



SAT903B


TROUBLE DIAGNOSES

Wiring Diagram












TROUBLE DIAGNOSES

Wiring Diagram (Cont'd)




TROUBLE DIAGNOSES





Self-diagnosis

SELF-DIAGNOSTIC PROCEDURE



TROUBLE DIAGNOSES












Self-diagnosis (Cont'd)



TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)













JUDGEMENT OF SELF-DIAGNOSIS CODE

O.D. OFF indicator lamp:	Damaged circuit
<p style="text-align: center;">All judgement flickers are same.</p> <div style="text-align: center;">  <p>O/D OFF</p> </div> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 5px auto;">Self-diagnosis start</div> <div style="text-align: center;">  <p>Start signal 10-judgement flickers Light Shade</p> <p>t_1 t_2 t_3 t_3 t_3 t_3 t_3 t_3 t_3 t_3</p> </div> <p style="text-align: right;">SAT723B</p>	<p>All circuits that can be confirmed by self-diagnosis are O.K.</p>
<p style="text-align: center;">1st judgement flicker is longer than others.</p> <div style="text-align: center;">  <p>O/D OFF</p> </div> <div style="text-align: center;">  <p>Light Shade</p> </div> <p style="text-align: right;">SAT724B</p>	<p>Revolution sensor circuit is short-circuited or disconnected.</p> <div style="text-align: center;">  <p>Revolution sensor</p> <p>16 15</p> <p>A/T control unit</p> </div> <p style="text-align: center;">➡ Go to REVOLUTION SENSOR CIRCUIT CHECK.</p> <p style="text-align: right;">SAT140B</p>
<p style="text-align: center;">2nd judgement flicker is longer than others.</p> <div style="text-align: center;">  <p>O/D OFF</p> </div> <div style="text-align: center;">  <p>Light Shade</p> </div> <p style="text-align: right;">SAT725B</p>	<p>Speed sensor circuit is short-circuited or disconnected.</p> <div style="text-align: center;">  <p>Speed sensor</p> <p>24</p> <p>A/T control unit</p> </div> <p style="text-align: center;">➡ Go to SPEED SENSOR CIRCUIT CHECK.</p> <p style="text-align: right;">SAT760A</p>
<p style="text-align: center;">3rd judgement flicker is longer than others.</p> <div style="text-align: center;">  <p>O/D OFF</p> </div> <div style="text-align: center;">  <p>Light Shade</p> </div> <p style="text-align: right;">SAT726B</p>	<p>Throttle sensor circuit is short-circuited or disconnected.</p> <div style="text-align: center;">  <p>Throttle sensor</p> <p>E.C.U.</p> <p>15 11 10</p> <p>A/T control unit</p> </div> <p style="text-align: center;">➡ Go to THROTTLE SENSOR CIRCUIT CHECK.</p> <p style="text-align: right;">SAT761A</p>

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second












TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

O.D. OFF indicator lamp:	Damaged circuit
<p>4th judgement flicker is longer than others.</p>  <p>Self-diagnosis start</p>  <p>SAT727B</p>	<p>Shift solenoid A circuit is short-circuited or disconnected.</p>  <p>➡ Go to SHIFT SOLENOID A CIRCUIT CHECK.</p> <p>SAT766A</p>
<p>5th judgement flicker is longer than others.</p>   <p>SAT728B</p>	<p>Shift solenoid B circuit is short-circuited or disconnected.</p>  <p>➡ Go to SHIFT SOLENOID B CIRCUIT CHECK.</p> <p>SAT767A</p>
<p>6th judgement flicker is longer than others.</p>   <p>SAT729B</p>	<p>Overrun clutch solenoid circuit is short-circuited or disconnected.</p>  <p>➡ Go to OVERRUN CLUTCH SOLENOID CIRCUIT CHECK.</p> <p>SAT768A</p>
<p>7th judgement flicker is longer than others.</p>   <p>SAT730B</p>	<p>Lock-up solenoid circuit is short-circuited or disconnected.</p>  <p>➡ Go to LOCK-UP SOLENOID CIRCUIT CHECK.</p> <p>SAT769A</p>

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

O.D. OFF indicator lamp:	Damaged circuit
<p>8th judgement flicker is longer than others.</p>  <p>Self-diagnosis start</p>  <p>SAT731B</p>	<p>Fluid temperature sensor is disconnected or A/T control unit power source circuit is damaged.</p>  <p>Go to FLUID TEMPERATURE SENSOR CIRCUIT AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECK.</p> <p>SAT143B</p>
<p>9th judgement flicker is longer than others.</p>   <p>SAT733B</p>	<p>Engine revolution signal circuit is short-circuited or disconnected.</p>  <p>Go to ENGINE REVOLUTION SIGNAL CIRCUIT CHECK.</p> <p>SAT624B</p>
<p>10th judgement flicker is longer than others.</p>   <p>SAT732B</p>	<p>Line pressure solenoid circuit is short-circuited or disconnected.</p>  <p>Go to LINE PRESSURE SOLENOID CIRCUIT CHECK.</p> <p>SAT776A</p>
<p>Flickers as shown below:</p>   <p>SAT734B</p>	<p>Battery power is low. Battery has been disconnected for a long time. Battery is connected conversely. (When reconnecting A/T control unit connectors. — This is not a problem.)</p>

$t_4 = 1.0$ second

TROUBLE DIAGNOSES







Self-diagnosis (Cont'd)

O.D. OFF indicator lamp:	Damaged circuit
<p>Does not come on.</p> <p>○ O/D OFF</p> <div data-bbox="220 367 427 434" style="border: 1px solid black; padding: 2px;"> Self-diagnosis start </div> <p>----- Light</p> <p>----- Shade</p> <p style="text-align: right;">SAT157C</p>	<p>Inhibitor switch, overdrive switch, kickdown switch or idle switch circuit is disconnected or A/T control unit is damaged.</p> <p> Ignition switch Fuse Inhibitor switch Throttle valve switch E.C.U. (Full throttle switch) (Idle switch) A/T control unit Over-drive switch Kickdown switch </p> <p> 26 19 20 1 2 9 23 7 17 4 </p> <p> ■ Go to INHIBITOR, OVERDRIVE, KICKDOWN AND IDLE SWITCH CIRCUIT CHECKS. </p> <p style="text-align: right;">SAT007C</p>

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

REVOLUTION SENSOR CIRCUIT CHECK



CHECK REVOLUTION SENSOR. — Refer to "Electrical Components Inspection".

N.G.

Repair or replace revolution sensor.

O.K.

A

CHECK INPUT SIGNAL.

1.



2. Check voltage between A/T control unit terminal ①⑥ and ground while driving. (Measure with A.C. range.)

Voltage:

At 0 km/h (0 MPH): 0V

At 30 km/h (19 MPH):

1V or more

(Voltage rises gradually in response to vehicle speed)

N.G.

Check the following items.

- Harness continuity between A/T control unit and revolution sensor (Main harness)
- Harness continuity between revolution sensor and E.C.U. (Main harness)
- Ground circuit for E.C.U. — Refer to section EF & EC.

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.

O.K.


INSPECTION END

SPEED SENSOR CIRCUIT CHECK

A

CHECK INPUT SIGNAL.

1.



2. Check voltage between A/T control unit terminal ②④ and ground while driving at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.

Voltage: Varies from 0V to 5V

N.G.

Check the following items.

- Speed sensor and ground circuit for speed sensor — Refer to section EL.
- Harness continuity between A/T control unit and speed sensor (Main harness)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

THROTTLE SENSOR CIRCUIT CHECK



Perform self-diagnosis (Mode III) for engine control.


N.G.

Check throttle sensor circuit for engine control. — Refer to section EF & EC.

O.K.

A

CHECK INPUT SIGNAL.



1. Check voltage between A/T control unit terminals ⑪ and ⑮ while accelerator pedal is depressed slowly.

Voltage:

Fully-closed throttle:

0.2 - 0.6V

Fully-open throttle:

2.9 - 3.9V

(Voltage rises gradually in response to throttle valve opening.)

N.G.

Check harness continuity between E.C.U. and A/T control unit regarding throttle sensor circuit. (Main harness)

O.K.

Perform self-diagnosis again after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

SHIFT SOLENOID A CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

1. 
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal 35 and ground.
Resistance: 20 - 30Ω


N.G.

1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Shift solenoid A — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

1. 
2. Disconnect A/T control unit 16-pin connector.
3. Check resistance between terminal 35 and A/T control unit terminal 35.
Resistance:
Approximately 0Ω
4. Reinstall any part removed.

N.G.

- Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

O.K.

Perform self-diagnosis after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

SHIFT SOLENOID B CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

1. 
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal 36 and ground.
Resistance: 20 - 30Ω


N.G.

1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Shift solenoid B — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

1. 
2. Disconnect A/T control unit 16-pin connector.
3. Check resistance between terminal 36 and A/T control unit terminal 36.
Resistance:
Approximately 0Ω
4. Reinstall any part removed.

N.G.

- Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

O.K.

Perform self-diagnosis after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

OVERRUN CLUTCH SOLENOID CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

- 1.
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ②① and ground.
Resistance: 20 - 30Ω

N.G.

1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Overrun clutch solenoid. — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

B

CHECK POWER SOURCE CIRCUIT.

- 1.
2. Disconnect A/T control unit 16-pin connector.
3. Check resistance between terminal ②① and A/T control unit terminal ②①.
Resistance: Approximately 0Ω
4. Reinstall any part removed.

N.G.

- Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

Perform self-diagnosis after driving for a while.

N.G.




1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.

INSPECTION END

TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

LOCK-UP SOLENOID CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

1. 
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal 22 and ground.
Resistance: 2.5 - 5Ω


N.G. →

1. Remove oil pan. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Lock-up solenoid — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K. ↓

B

CHECK POWER SOURCE CIRCUIT.

1. 
2. Disconnect A/T control unit 16-pin connector.
3. Check resistance between terminal 22 and A/T control unit terminal 22.
Resistance: Approximately 0Ω
4. Reinstall any part removed.

N.G. →

Repair or replace harness between A/T control unit and terminal cord assembly. (Main harness)

O.K. ↓

Perform self-diagnosis after driving for a while.

O.K. ↓

INSPECTION END




N.G. →

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

FLUID TEMPERATURE SENSOR CIRCUIT AND A/T CONTROL UNIT POWER SOURCE CIRCUIT CHECKS



A

CHECK A/T CONTROL UNIT POWER SOURCE.

-
- Check voltage between A/T control unit terminals 29, 30 and ground. Battery voltage should exist.

N.G.

- Check the following items.
- Harness continuity between ignition switch and A/T control unit (Main harness)
 - Ignition switch and fuse – Refer to section EL.

B

CHECK FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY

-
- Disconnect terminal cord assembly connector in engine compartment.
- Check resistance between terminals 12 and 15 when A/T is cold. Resistance:
Cold [20°C (68°F)]
Approximately 2.5 kΩ
- Reinstall any part removed.

N.G.





1. Remove oil pan.
2. Check the following items.
 - Fluid temperature sensor – Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K.


A

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)






ENGINE REVOLUTION SIGNAL CIRCUIT CHECK



TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

LINE PRESSURE SOLENOID CIRCUIT CHECK



A

CHECK GROUND CIRCUIT.

1. 
2. Disconnect terminal cord assembly connector in engine compartment.
3. Check resistance between terminal ③④ and ground.
Resistance: 2.5 - 5Ω


N.G.

1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items.
 - Line pressure solenoid — Refer to "Electrical Components Inspection".
 - Harness continuity of terminal cord assembly

O.K.

B

CHECK POWER SOURCE CIRCUIT.

1. 
2. Disconnect A/T control unit 16-pin connector.
3. Check resistance between terminal ③④ and A/T control unit terminal ③③.
Resistance: 11.2 - 12.8Ω

N.G.


Check the following items.

- Dropping resistor — Refer to "Electrical Components Inspection".
- Harness continuity between A/T control unit ③③ and terminal cord assembly (Main harness)

O.K.

C

CHECK POWER SOURCE CIRCUIT

1. 
2. Check resistance between terminal ③④ and A/T control unit terminal ③④.
Resistance: Approximately 0Ω
3. Reinstall any part removed.

N.G.

Repair or replace harness between A/T control unit ③④ and terminal cord assembly.

O.K.

Perform self-diagnosis after driving for a while.

N.G.

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K.

INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

INHIBITOR, OVERDRIVE, KICKDOWN AND IDLE SWITCH CIRCUIT CHECKS



A

CHECK INHIBITOR SWITCH CIRCUIT.

-
- Check voltage between A/T control unit terminals ①, ②, ⑱, ⑳, ㉔ and ground while moving selector lever through each range.

Voltage:
B: Battery voltage
0: 0V

Terminal No.	⑱	㉔	⑳	①	②
Lever position					
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

N.G. → Check the following items.

- Inhibitor switch — Refer to "Electrical Components Inspection".
- Harness continuity between ignition switch and inhibitor switch (Main harness)
- Harness continuity between inhibitor switch and A/T control unit (Main harness)

O.K. ↓

B

CHECK OVERDRIVE SWITCH CIRCUIT.

-
- Check voltage between A/T control unit terminal ⑨ and ground when overdrive switch is in "ON" position and in "OFF" position.

Switch position	Voltage
ON	Battery voltage
OFF	1V or less

N.G. → Check the following items.



- Overdrive switch — Refer to "Electrical Components Inspection".
- Harness continuity between A/T control unit and overdrive switch (Main harness)
- Harness continuity of ground circuit for overdrive switch (Main harness)

O.K. ↓

A

TROUBLE DIAGNOSES





Self-diagnosis (Cont'd)



TROUBLE DIAGNOSES

Diagnostic Procedure 1

SYMPTOM: O.D. OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".



1

CHECK A/T CONTROL UNIT POWER SOURCE.

-
- Check voltage between A/T control unit terminals 29, 30 and ground.
Battery voltage should exist.

N.G. → Check the following items.

- Harness continuity between ignition switch and A/T control unit (Main harness)
- Ignition switch and fuse
— Refer to section EL.

2

CHECK A/T CONTROL UNIT GROUND CIRCUIT.

-
- Disconnect A/T control unit 16-pin connector.
- Check resistance between A/T control unit terminals 31, 32 and ground.
Resistance:
Approximately 0Ω

N.G. → Check harness continuity between A/T control unit and ground.

3

CHECK LAMP CIRCUIT.

-
- Disconnect A/T control unit 16-pin connector.
- Check resistance between A/T control unit terminals 23 and 29.
Resistance: 50 - 100Ω
- Reinstall any part removed.

N.G. → Check the following items.

- O.D. OFF indicator lamp
— Refer to section EL.
- Harness continuity between ignition switch and O.D. OFF indicator lamp (Main harness)
- Harness continuity between power shift indicator lamp and A/T control unit


Check again.

N.G. →

1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.




O.K. → **INSPECTION END**

TROUBLE DIAGNOSES




Diagnostic Procedure 2

SYMPTOM: Engine cannot be started with selector lever in "P" or "N" range or engine can be started with selector lever in "D", "2", "1" or "R" range.







Diagnostic Procedure 3

SYMPTOM: Vehicle moves when it is pushed forward or backward with selector lever in "P" range.








Diagnostic Procedure 4

SYMPTOM: Vehicle moves forward or backward when selecting "N" range.







Diagnostic Procedure 5

SYMPTOM: There is large shock when changing from "N" to "R" range.







Diagnostic Procedure 6

SYMPTOM: Vehicle does not creep backward when selecting "R" range.




TROUBLE DIAGNOSES



Diagnostic Procedure 7






SYMPTOM: Vehicle does not creep forward when selecting "D", "2" or "1" range.








TROUBLE DIAGNOSES

Diagnostic Procedure 8

SYMPTOM: Vehicle cannot be started from D₁ on Cruise test — Part 1.




TROUBLE DIAGNOSES



Diagnostic Procedure 9





SYMPTOM: A/T does not shift from D₁ to D₂ at the specified speed.
A/T does not shift from D₄ to D₂ when depressing accelerator pedal fully at the specified speed.



TROUBLE DIAGNOSES

Diagnostic Procedure 10

SYMPTOM: A/T does not shift from D₂ to D₃ at the specified speed.



Are Diagnostic Procedures 7 and 8 O.K.?

No → Go to Diagnostic Procedure 7 or 8.

1 Does self-diagnosis show damage to inhibitor switch after cruise test?

Yes → Check inhibitor switch circuit. — Refer to "Self-diagnosis".

2 Check throttle sensor. — Refer to section EF & EC.

N.G. → Repair or replace throttle sensor.

3 1. Remove oil pan.
2. Check A/T fluid condition.

N.G. → 1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items:

- Shift valve B
- Shift solenoid B
- Pilot valve
- Pilot filter

O.K. → 3. Disassemble A/T.
4. Check the following items:

- Servo piston assembly
- High clutch assembly
- Oil pump assembly

4 Check again.





N.G. → 1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.

O.K. → INSPECTION END

TROUBLE DIAGNOSES

Diagnostic Procedure 11

SYMPTOM: A/T does not shift from D₃ to D₄ at the specified speed.



Are Diagnostic Procedures 7 and 8 O.K.?

No → Go to Diagnostic Procedure 7 or 8.

1 Does self-diagnosis show damage to inhibitor switch, overdrive switch, shift solenoid A, B, revolution sensor, speed sensor or fluid temperature sensor circuit after cruise test?

Yes → Check damaged circuit. — Refer to "Self-diagnosis".

2 Check throttle sensor. — Refer to section EF & EC.

N.G. → Repair or replace throttle sensor.

3 1. Remove oil pan.
2. Check A/T fluid condition.

N.G. → 1. Remove control valve assembly. — Refer to "ON-VEHICLE SERVICE".
2. Check the following items:
• Shift valve B
• Overrun clutch control valve
• Shift solenoid B
• Pilot valve
• Pilot filter

O.K. → 3. Disassemble A/T.
4. Check the following items:
• Servo piston assembly
• Brake band
• Torque converter
• Oil pump assembly

O.K. → 3. Disassemble A/T.
4. Check the following items:
• Servo piston assembly
• Brake band
• Torque converter
• Oil pump assembly

O.K. → 3. Disassemble A/T.
4. Check the following items:
• Servo piston assembly
• Brake band
• Torque converter
• Oil pump assembly





4 Check again.

N.G. → 1. Perform A/T control unit input/output signal inspection.
2. If N.G., recheck A/T control unit pin terminals for damage or connection of A/T control unit harness connector.



O.K. → INSPECTION END

Diagnostic Procedure 12

SYMPTOM: A/T does not perform lock-up at the specified speed.






TROUBLE DIAGNOSES




Diagnostic Procedure 13

SYMPTOM: A/T does not hold lock-up condition for more than 30 seconds.








Diagnostic Procedure 14

SYMPTOM: Lock-up is not released when accelerator pedal is released.




Diagnostic Procedure 15

SYMPTOM: Engine speed does not return to idle smoothly when A/T is shifted from D₄ to D₃ with accelerator pedal released.
 Vehicle does not decelerate by engine brake when changing overdrive switch to "OFF" position with accelerator pedal released.
 Vehicle does not decelerate by engine brake when changing selector lever from "D" to "2" range with accelerator pedal released.





TROUBLE DIAGNOSES




Diagnostic Procedure 16

SYMPTOM: Vehicle does not start from D₁ on Cruise test — Part 2.




Diagnostic Procedure 17

SYMPTOM: A/T does not shift from D₄ to D₃ when changing overdrive switch to "OFF" position.





TROUBLE DIAGNOSES





Diagnostic Procedure 18

SYMPTOM: A/T does not shift from D_3 to 2_2 when changing selector lever from "D" to "2" range.




Diagnostic Procedure 19

SYMPTOM: A/T does not shift from 2_2 to 1_1 when changing selector lever from "2" to "1" range.




Diagnostic Procedure 20

SYMPTOM: Vehicle does not decelerate by engine brake when shifting from 2_2 (1_2) to 1_1 .




TROUBLE DIAGNOSES



Electrical Components Inspection

INSPECTION OF A/T CONTROL UNIT

- Measure voltage between each terminal and terminal ① or ② by following "A/T CONTROL UNIT INSPECTION TABLE".








- Pin connector terminal layout.

A/T CONTROL UNIT INSPECTION TABLE
(Data are reference values.)

Terminal No.	Item	Condition	Judgement standard
1	Inhibitor "2" range switch	When setting selector lever to "D" range.	Battery voltage
		When setting selector lever to other ranges.	1V or less
2	Inhibitor "1" range switch	When setting selector lever to "1" range.	Battery voltage
		When setting selector lever to other ranges.	1V or less
3	—	—	—
4	Idle switch (in throttle valve switch)	When releasing accelerator pedal after warming up engine.	8 - 15V
		When depressing accelerator pedal after warming up engine.	1V or less
5	—	—	—
6	—	—	—










TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition	Judgement standard	
7	Kickdown switch		When releasing accelerator pedal after warming up engine.	3 - 8V
			When depressing accelerator pedal fully after warming up engine.	1V or less
8	—	—	—	
9	Overdrive switch		When setting overdrive switch in "ON" position.	Battery voltage
			When setting overdrive switch in "OFF" position.	1V or less
10	Throttle sensor (Power source)	—	4.5 - 5.5V	
11	Throttle sensor		When depressing accelerator pedal slowly after warming up engine.	Fully-closed throttle: 0.2 - 0.6V
			Voltage rises gradually in response to throttle opening angle.	Fully-open throttle: 2.9 - 3.9V
12	Fluid temperature sensor		When A.T.F. temperature is 20°C (68°F).	1.56V
			When A.T.F. temperature is 80°C (176°F).	0.45V
13	—	—	—	
14	—	—	—	
15	Throttle sensor (Ground)	—	—	
16	Revolution sensor (Measure in AC range)		When vehicle cruises at 30 km/h (19 MPH).	(1V or more Voltage rises gradually in response to vehicle speed.)
			When vehicle parks.	0V








TROUBLE DIAGNOSES


Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition	Judgement standard	
17	Full throttle switch		When depressing accelerator pedal more than half-way after warming up engine.	8 - 15V
			When releasing accelerator pedal after warming up engine.	1V or less
18	—	—	—	
19	Inhibitor "N" and "P" range switch		When setting selector lever to "N" or "P" range.	Battery voltage
			When setting selector lever to other ranges.	1V or less
20	Inhibitor "D" range switch		When setting selector lever to "2" range.	Battery voltage
			When setting selector lever to other ranges.	1V or less
21	Overrun clutch solenoid		When overrun clutch solenoid operates.	Battery voltage
			When overrun clutch solenoid does not operate.	1V or less
22	Lock-up solenoid		When A/T performs lock-up.	8 - 15V
			When A/T does not perform lock-up.	1V or less
23	O.D. OFF indicator lamp		When setting overdrive switch to "ON" position.	Battery voltage
			When setting overdrive switch to "OFF" position.	1V or less
24	Speed sensor		When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.	Vary from 0 to 5V
25	Engine revolution signal		When engine runs at idle speed.	9.5 - 12V
			When engine runs at 2,500 rpm.	Approximately 10V
26	Inhibitor "R" range switch		When setting selector lever to "R" range.	Battery voltage
			When setting selector lever to other ranges.	1V or less
27	—	—	—	

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

Terminal No.	Item	Condition	Judgement standard	
28	Power source (Back-up)	 or 	When turning ignition switch to "OFF".	Battery voltage
			When turning ignition switch to "ON".	Battery voltage
29 30	Power source		When turning ignition switch to "ON".	Battery voltage
			When turning ignition switch to "OFF".	1V or less
31 32	Ground	—	—	
33	Line pressure solenoid (with dropping resistor)		When releasing accelerator pedal after warming up engine.	5 - 14V
			When depressing accelerator pedal fully after warming up engine.	0.5V or less
34	Line pressure solenoid		When releasing accelerator pedal after warming up engine.	1.5 - 2.5V
			When depressing accelerator pedal fully after warming up engine.	0.5V or less
35	Shift solenoid A		When shift solenoid A operates. (When driving in "D ₁ " or "D ₄ ".)	Battery voltage
			When shift solenoid A does not operate. (When driving in "D ₂ " or "D ₃ ".)	1V or less
36	Shift solenoid B		When shift solenoid B operates. (When driving in "D ₁ " or "D ₂ ".)	Battery voltage
			When shift solenoid B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less



OVERDRIVE SWITCH

- Check continuity between two terminals.






O.D. switch position	Continuity
ON	No
OFF	Yes

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd) INHIBITOR SWITCH

1. Check continuity between terminals ① and ② and between terminals ③ and ④, ⑤, ⑥, ⑦, ⑧, ⑨ while moving selector lever through each range.

Terminal No.	①	②	③	④	⑤	⑥	⑦	⑧	⑨
Lever position									
P	○—○		○—○						
R			○—○	○—○					
N	○—○		○—○	○—○	○—○				
D			○—○	○—○	○—○	○—○			
2			○—○	○—○	○—○	○—○	○—○		
1			○—○	○—○	○—○	○—○	○—○	○—○	



2. If N.G., check again with manual control linkage disconnected from manual shaft of A/T assembly. — Refer to step 1.
3. If O.K. on step 2, adjust manual control linkage. — Refer to "ON-VEHICLE SERVICE".
4. If N.G. on step 2, remove inhibitor switch from A/T and check continuity of inhibitor switch terminal. — Refer to step 1.
5. If O.K. on step 4, adjust inhibitor switch. — Refer to "ON-VEHICLE SERVICE".
6. If N.G. on step 4, replace inhibitor switch.

REVOLUTION SENSOR

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between terminals ①, ② and ③.


Terminal No.		Resistance
①	②	500 - 650Ω
②	③	No continuity
①	③	No continuity

TROUBLE DIAGNOSES

Electrical Components Inspection (Cont'd)

FLUID TEMPERATURE SENSOR

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between two terminals while changing temperature as shown at left.



Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ


LOCK-UP SOLENOID AND LINE PRESSURE SOLENOID

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between two terminals.

Resistance:

Lock-up solenoid 10 - 16 Ω


Line pressure solenoid 2.5 - 5 Ω



3-UNIT SOLENOID ASSEMBLY

(Shift solenoid A, B and overrun clutch solenoid)

- For removal and installation, refer to "ON-VEHICLE SERVICE".
- Check resistance between terminals of each solenoid.




Solenoid	Terminal No.	Resistance
Shift solenoid A	③	Ground terminal 20 - 30Ω
Shift solenoid B	②	
Overrun clutch solenoid	④	


DROPPING RESISTOR

- Check resistance between two terminals.

Resistance: 11.2 - 12.8 Ω



TROUBLE DIAGNOSES



Final Check


STALL TESTING

Stall test procedure

1. Check A/T and engine fluid levels. If necessary, add.
2. Warm up engine until engine oil and A.T.F. reach operating temperature after vehicle has been driven approx. 10 minutes.


A.T.F. operating temperature:

50 - 80°C (122 - 176°F)




3. Set parking brake and block wheels.
4. Install a tachometer where it can be seen by driver during test.

● It is good practice to put a mark on point of specified engine rpm on indicator.



5. Start engine, apply foot brake, and place selector lever in "D" range.




6. Accelerate to wide-open throttle gradually while applying foot brake.
7. Quickly note the engine stall revolution and immediately release throttle.

● During test, never hold throttle wide-open for more than 5 seconds.

Stall revolution:

3,050 - 3,250 rpm



8. Shift selector lever to "N".

9. Cool off A.T.F.

● Run engine at idle for at least one minute.

10. Perform stall tests in the same manner as in steps 5 through 9 with selector lever in "2", "1" and "R", respectively.


TROUBLE DIAGNOSES

Final Check (Cont'd)

Judgement of stall test

Selector lever position	Judgement		
D	L	O	H
2	L	O	H
1	L	O	O
R	L	H	H

- O : Stall revolution is normal.
- H : Stall revolution is higher than specified.
- L : Stall revolution is lower than specified.



D	H	H	H	O
2	H	H	H	O
1	O	H	H	O
R	O	O	H	O
Selector lever position	Judgement			

Clutches and brakes except high clutch and brake band are O.K. (Condition of high clutch and brake band cannot be confirmed by stall test.)



SAT107B

TROUBLE DIAGNOSES

Final Check (Cont'd)

PRESSURE TESTING

- Location of line pressure test port
- Line pressure plugs are hexagon headed bolts.
- Always replace line pressure plugs as they are self-sealing bolts.




Line pressure test procedure

1. Check A/T and engine fluid levels. If necessary, add.
2. Warm up engine until engine oil and A.T.F. reach operating temperature after vehicle has been driven approx. 10 minutes.


A.T.F. operating temperature:

50 - 80°C (122 - 176°F)




3. Install pressure gauge to line pressure port.

— D, 2 and 1 ranges —



— R range —




4. Set parking brake and block wheels.

- Continue to depress brake pedal fully while line pressure test at stall speed is performed.

TROUBLE DIAGNOSES

Final Check (Cont'd)



5. Start engine and measure line pressure at idle and stall speed.

- When measuring line pressure at stall speed, follow the stall test procedure.

Line pressure:

Engine speed rpm	Line pressure kPa (bar, kg/cm ² , psi)	
	D, 2 and 1 ranges	R range
Idle	471 - 510 (4.71 - 5.10, 4.8 - 5.2, 68 - 74)	657 - 696 (6.57 - 6.96, 6.7 - 7.1, 95 - 101)
Stall	1,020 - 1,098 (10.20 - 10.98, 10.4 - 11.2, 148 - 159)	1,422 - 1,500 (14.22 - 15.00, 14.5 - 15.3, 206 - 218)

JUDGEMENT OF LINE PRESSURE TEST

Judgement		Suspected parts
At idle	Line pressure is low in all ranges.	<ul style="list-style-type: none"> ● Oil pump wear ● Control piston damage ● Pressure regulator valve or plug sticking ● Spring for pressure regulator valve damaged ● Fluid pressure leakage between oil strainer and pressure regulator valve
	Line pressure is low in particular range.	<ul style="list-style-type: none"> ● Fluid pressure leakage between manual valve and particular clutch. ● For example; If line pressure is low in "R" and "1" ranges but is normal in "D" and "2" range, fluid leakage exists at or around low & reverse brake circuit.
	Line pressure is high.	<ul style="list-style-type: none"> ● Mal-adjustment of throttle sensor ● Fluid temperature sensor damaged ● Line pressure solenoid sticking ● Short circuit of line pressure solenoid circuit ● Pressure modifier valve sticking ● Pressure regulator valve or plug sticking
At stall speed	Line pressure is low.	<ul style="list-style-type: none"> ● Mal-adjustment of throttle sensor ● Control piston damaged ● Line pressure solenoid sticking ● Short circuit of line pressure solenoid circuit ● Pressure regulator valve or plug sticking ● Pressure modifier valve sticking ● Pilot valve sticking

TROUBLE DIAGNOSES

Symptom Chart

Reference page (AT-)	Reference page (AT-)	ON vehicle										OFF vehicle																						
		9, 14	66	66	70	67, 96	67	67	7, 67	7	7	80, 91	110, 114	116, 127	116, 124	120	134																	
	Numbers are arranged in order of probability. Perform inspections starting with number one and working up. Circled numbers indicate that the transmission must be removed from the vehicle.	Fluid level Control linkage	Inhibitor switch	Throttle sensor (Adjustment)	Revolution sensor and speed sensor	Engine revolution signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid A	Shift solenoid B	Line pressure solenoid	Lock-up solenoid	Overrun clutch solenoid	Fluid temperature sensor	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components			
48	Engine does not start in "N", "P" ranges.	2	3																1															
48	Engine starts in range other than "N" and "P".	1	2																															
-	Transmission noise in "P" and "N" ranges.	1		3	4	5	2														7	6												
48	Vehicle moves when changing into "P" range or parking gear does not disengage when shifted out of "P" range.	1																														2		
49	Vehicle runs in "N" range.	1																	4				3		2		3							
51	Vehicle will not run in "R" range (but runs in "D", "2" and "1" ranges). Clutch slips. Very poor acceleration.	1					2	4			3												5	6	7	8	9							
-	Vehicle braked when shifting into "R" range.	1	2				3	5			4												6	8	9						7			
-	Sharp shock in shifting from "N" to "D" range.			2		5	1	3	7		6			4	8										9									
-	Vehicle will not run in "D" and "1" ranges (but runs in "1" and "R" range).	1																										2						
52	Vehicle will not run in "D", "1", "2" ranges (but runs in "R" range). Clutch slips. Very poor acceleration.	1					2	4			3												6	7	8	9	10							
-	Clutches or brakes slip somewhat in starting.	1	2	3			4	6		5			7			8						11	12	10	9					11				
-	Excessive creep.					1																												
51, 52	No creep at all.	1					2	3														6	5		4									
-	Failure to change gear from "D ₁ " to "D ₂ ".	2	1		5			4	3																							6		
-	Failure to change gear from "D ₂ " to "D ₃ ".	2	1		5			4	3															6								7		
-	Failure to change gear from "D ₃ " to "D ₄ ".	2	1		4				3				5																			6		
54, 55, 56	Too high a gear change point from "D ₁ " to "D ₂ ", from "D ₂ " to "D ₃ ", from "D ₃ " to "D ₄ ".			1	2				3	4																								
-	Gear change directly from "D ₁ " to "D ₃ " occurs.	1														2																3		
-	Engine stops when shifting lever into "R", "D", "2" and "1".					1		3				2									4													
-	Too sharp a shock in change from "D ₁ " to "D ₂ ".			1			2	4						5	3																	6		
-	Too sharp a shock in change from "D ₂ " to "D ₃ ".			1			2	4											3														6	

TROUBLE DIAGNOSES

Symptom Chart (Cont'd)


Reference page (AT-)	Reference page (AT-)	ON vehicle										OFF vehicle																					
		9, 14	66	66	70	67, 96	67	67	7, 67	7	7	80, 91	110, 114	116, 127	116, 124	120	134																
		Fluid level	Control linkage	Inhibitor switch	Throttle sensor (Adjustment)	Revolution sensor and speed sensor	Engine revolution signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid A	Shift solenoid B	Line pressure solenoid	Lock-up solenoid	Overrun clutch solenoid	Fluid temperature sensor	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components	
-	Too sharp a shock in change from "D ₃ " to "D ₄ ".	.	.	1	.	.	.	2	4	3	6	.	.	5	.	.		
-	Almost no shock or clutches slipping in change from "D ₁ " to "D ₁ ".	1	.	2	.	.	.	3	5	4	6	.	.	
-	Almost no shock or slipping in change from "D ₁ " to "D ₃ ".	1	.	2	.	.	.	3	5	4	6	7	.	.	
-	Almost no shock or slipping in change from "D ₃ " to "D ₄ ".	1	.	2	.	.	.	3	5	4	6	7	.	.	
-	Vehicle braked by gear change from "D ₁ " to "D ₃ ".	1	2	4	.	.	.	5	3	.	.	
-	Vehicle braked by gear change from "D ₁ " to "D ₃ ".	1	2	.	.
-	Vehicle braked by gear change from "D ₃ " to "D ₄ ".	1	4	.	.	3	2
-	Maximum speed not attained. Acceleration poor.	1	.	2	5	3	4	11	10	6	7	.	.	.	9	8	.	.
-	Failure to change gear from "D ₄ " to "D ₃ ".	1	.	2	6	4	5	3	8	7
-	Failure to change gear from "D ₃ " to "D ₃ " or from "D ₄ " to "D ₁ ".	1	.	2	5	3	4	6	7	.	.	.
-	Failure to change gear from "D ₁ " to "D ₁ " or from "D ₃ " to "D ₁ ".	1	.	2	5	3	4	7	.	.	6	8
-	Gear change shock felt during deceleration by releasing accelerator pedal.	.	.	1	.	.	.	2	4
-	Too high a change point from "D ₄ " to "D ₃ ", from "D ₃ " to "D ₂ ", from "D ₁ " to "D ₁ ".	.	.	1	2
-	Kickdown does not operate when depressing pedal in "D ₄ " within kickdown vehicle speed.	.	.	1	2	.	.	.	3	4
-	Kickdown operates or engine overruns when depressing pedal in "D ₄ " beyond kickdown vehicle speed limit.	.	.	2	1	.	.	.	3	4
-	Races extremely fast or slips in changing from "D ₄ " to "D ₃ " when depressing pedal.	1	.	2	.	.	.	3	5	.	4	6	7
-	Races extremely fast or slips in changing from "D ₄ " to "D ₁ " when depressing pedal.	1	.	2	.	.	.	3	6	5	4	8	.	.	7	.	.	.
-	Races extremely fast or slips in changing from "D ₃ " to "D ₁ " when depressing pedal.	1	.	2	.	.	.	3	5	.	4	.	.	8	.	0	9	7	.	.	.	6	.	.	.
-	Races extremely fast or slips in changing from "D ₄ " or "D ₃ " to "D ₁ " when depressing pedal.	1	.	2	.	.	.	3	5	.	4	6	7	.	8
-	Vehicle will not run in any range.	1	2	3	.	.	4	9	5	.	6	.	.	.	8	7	10	.
-	Transmission noise in "D", "2", "1" and "R" ranges.	1	2

TROUBLE DIAGNOSES

Symptom Chart (Cont'd)


Reference page (AT-)		ON vehicle											OFF vehicle																		
		9, 14	66	66	70	67, 96	67	67	7, 67	7	7	80, 91	110, 114	116, 127	116, 124	120	134														
Reference page (AT-)	Numbers are arranged in order of probability. Perform inspections starting with number one and working up. Circled numbers indicate that the transmission must be removed from the vehicle.	Fluid level	Control linkage	Inhibitor switch	Throttle sensor (Adjustment)	Revolution sensor and speed sensor	Engine revolution signal	Engine idling rpm	Line pressure	Control valve assembly	Shift solenoid A	Shift solenoid B	Line pressure solenoid	Lock-up solenoid	Overrun clutch solenoid	Fluid temperature sensor	Accumulator N-D	Accumulator 1-2	Accumulator 3-4 (N-R)	Ignition switch and starter	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse brake	Brake band	Parking components
61	Failure to change from "D ₃ " to "2" when changing lever into "2" range.	7	1	2	6	5	4	.	.	3	9	.	8	.	.
-	Gear change from "2" to "3" in "2" range.	.	.	1
61	Engine brake does not operate in "1" range.	2	1	3	4	.	.	.	6	5	.	.	.	7	8	.	9	.	.
-	Gear change from "1" to "1" in "1" range.	2	1
-	Does not change from "1 ₁ " to "1 ₁ " in "1" range.	.	1	.	2	.	.	.	4	3	.	.	.	5	6	.	7	.	.
-	Large shock changing from "1 ₁ " to "1 ₁ " in "1" range.	1	2	.	.
-	Transmission overheats.	1	.	3	.	2	4	6	.	5	14	7	8	9	11	12	13	10	.	.	.
-	A.T.F. shoots out during operation. White smoke emitted from exhaust pipe during operation.	1	2	3	5	6	7	4	.	.	.
-	Offensive smell at fluid charging pipe.	1	2	3	4	5	7	8	9	6	.	.
-	Torque converter is not locked up.	.	3	1	2	4	.	6	8	.	.	.	7	5	9
-	Lock-up piston slip	1	.	2	.	.	3	6	.	5	4	7
57	Lock-up point is extremely high or low.	.	.	1	2	.	.	4	.	.	3
-	A/T does not shift to "D ₄ " when driving with overdrive switch "ON".	.	2	1	3	.	8	6	4	.	.	5	7	10	.	9	.	.	
-	Engine is stopped at "R", "D", "2" and "1" ranges.	1	5	4	3	2

REMOVAL AND INSTALLATION




Removal

- Remove fluid charging pipe from A/T assembly.
- Remove bolts securing torque converter to drive plate.
- **Remove those bolts by turning crankshaft.**
- Plug up opening such as oil charging pipe hole, etc.



Installation

- Drive plate runout
**Maximum allowable runout:
 0.5 mm (0.020 in)**
 If this runout is out of allowance, replace drive plate with ring gear.




- When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled.

Distance "A":

23.5 mm (0.925 in) or more

- Install converter to drive plate.
- Reinstall any part removed.
- **After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.**




- Tighten bolts securing transmission.

Bolt No.	Tightening torque N·m (kg·m, ft·lb)	Bolt length "L" mm (in)
1	39 - 49 (4.0 - 5.0, 29 - 36)	80 (3.15)
2	39 - 49 (4.0 - 5.0, 29 - 36)	75 (2.95)
3	39 - 49 (4.0 - 5.0, 29 - 36)	55 (2.17)
4	29 - 39 (3.0 - 4.0, 22 - 29)	40 (1.57)
5	29 - 39 (3.0 - 4.0, 22 - 29)	25 (0.98)
Gusset to engine	29 - 39 (3.0 - 4.0, 22 - 29)	20 (0.79)




- Reinstall any part removed.
- Check fluid level in transmission.
- Move selector lever through all positions to be sure that transmission operates correctly.
 With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R". A slight shock should be felt by hand gripping selector each time transmission is shifted.
- Perform road test. — Refer to "ROAD TESTING".

MAJOR OVERHAUL



MAJOR OVERHAUL




AT-77

SAT911B

MAJOR OVERHAUL

Oil Channel



AT-78

SAT185B

MAJOR OVERHAUL

Locations of Needle Bearings, Thrust Washers and Snap Rings

Outer diameter of snap rings

Item number	Outer diameter mm (in)
②	161.0 (6.34)
③	140.1 (5.52)
④	156.4 (6.16)
⑥	142.0 (5.59)
⑦	159.2 (6.27)

Thrust washers

Item number	Color
①	Black
⑤	White

Outer diameter of needle bearings


Item number	Outer diameter mm (in)
⑧	47 (1.85)
⑨	53 (2.09)
⑩	53 (2.09)
⑪	78 (3.07)
⑫	53 (2.09)
⑬	78 (3.07)
⑭	59 (2.32)
⑮	78 (3.07)
⑯	64 (2.52)

Inner diameter of bearing races

Item number	Outer diameter mm (in)
⑪	58 (2.28)
⑬	58.8 (2.315)

Installation of one-piece bearings


Item number	Bearing race (black) location
⑫	Front
⑮	Rear side
⑯	Rear side



AT-79


SAT647A

DISASSEMBLY




Disassembly


1. Remove torque converter by holding it firmly and turning while pulling straight out.




2. Check torque converter one-way clutch.
 - a. Insert Tool into spline of one-way clutch inner race.
 - b. Hook bearing support unitized with one-way clutch outer race with suitable wire.
 - c. Check that one-way clutch inner race rotates only clockwise with Tool while holding bearing support with wire.



3. Remove inhibitor switch from transmission case.




4. Remove oil pan.
 - a. Drain A.T.F. from rear extension.
 - b. Raise oil pan by placing wooden blocks under converter housing and rear extension.
 - c. Separate the oil pan and transmission case.
 - **Always place oil pan straight down so that foreign particles inside will not move.**



5. Place transmission into Tool with the control valve facing up.


DISASSEMBLY

Disassembly (Cont'd)




6. Check oil pan and oil strainer for accumulation of foreign particles.
- If materials of clutch facing are found, clutch plates may be worn.
 - If metal filings are found, clutch plates, brake bands, etc. may be worn.
 - If aluminum filings are found, bushings or aluminum cast parts may be worn.

In above cases, replace torque converter and check unit for cause of particle accumulation.




7. Remove lock-up solenoid and fluid temperature sensor connectors.


- **Be careful not to damage connector.**



8. Remove oil strainer.
- a. Remove oil strainer from control valve assembly. Then remove O-ring from oil strainer.



- b. Check oil strainer screen for damage.






9. Remove control valve assembly.
- a. Straighten terminal clips to free terminal cords then remove terminal clips.

DISASSEMBLY


Disassembly (Cont'd)

- b. Remove bolts **(A)** and **(B)**, and remove control valve assembly from transmission.


Bolt symbol	ℓ mm (in)	 ℓ
(A)	33 (1.30)	
(B)	45 (1.77)	



- c. Remove solenoid connector.
- Be careful not to damage connector.



- d. Remove manual valve from control valve assembly.




10. Remove terminal cord assembly from transmission case while pushing on stopper.
- Be careful not to damage cord.
 - Do not remove terminal cord assembly unless it is damaged.


DISASSEMBLY

Disassembly (Cont'd)


11. Remove converter housing.
a. Remove converter housing from transmission case.




- b. Remove O-rings from converter housing.
c. Remove traces of sealant.
● **Be careful not to scratch converter housing.**




12. Remove O-ring from input shaft.



13. Remove oil pump assembly.
a. Attach Tool to oil pump assembly and extract it evenly from transmission case.




- b. Remove O-ring from oil pump assembly.
c. Remove traces of sealant from oil pump housing.
● **Be careful not to scratch pump housing.**




DISASSEMBLY

Disassembly (Cont'd)


- d. Remove needle bearing and thrust washer from oil pump assembly.




14. Remove input shaft and oil pump gasket.




15. Remove brake band and band strut.
a. Loosen lock nut and remove band servo anchor end pin from transmission case.



- b. Remove brake band and band strut from transmission case.




- c. Hold brake band in a circular shape with clip.




DISASSEMBLY

Disassembly (Cont'd)


16. Remove front side clutch and gear components.
- Remove clutch pack (reverse clutch, high clutch and front sun gear) from transmission case.




- Remove front bearing race from clutch pack.
- Remove rear bearing race from clutch pack.




- Remove front planetary carrier from transmission case.



- Remove front needle bearing from front planetary carrier.
- Remove rear bearing from front planetary carrier.



- Remove rear sun gear from transmission case.




DISASSEMBLY

Disassembly (Cont'd)


17. Remove rear extension.

- Remove rear extension from transmission case.
- Remove rear extension gasket from transmission case.




c. Remove oil seal from rear extension.

- Do not remove oil seal unless it is to be replaced.




d. Remove revolution sensor from rear extension.

e. Remove O-ring from revolution sensor.



18. Remove output shaft and parking gear.


a. Remove rear snap ring from output shaft.



b. Slowly push output shaft all the way forward.


- Do not use excessive force.

c. Remove snap ring from output shaft.




DISASSEMBLY


Disassembly (Cont'd)




- d. Remove output shaft and parking gear as a unit from transmission case.
- e. Remove parking gear from output shaft.




- f. Remove needle bearing from transmission case.



- 19. Remove rear side clutch and gear components.
- a. Remove front internal gear.




- b. Remove bearing race from front internal gear.




- c. Remove needle bearing from rear internal gear.

DISASSEMBLY


Disassembly (Cont'd)




- d. Remove rear internal gear, forward clutch hub and overrun clutch hub as a set from transmission case.




- e. Remove needle bearing from overrun clutch hub.



- f. Remove overrun clutch hub from rear internal gear and forward clutch hub.



- g. Remove thrust washer from overrun clutch hub.




- h. Remove forward clutch assembly from transmission case.

DISASSEMBLY


Disassembly (Cont'd)

20. Remove band servo and accumulator components.
- Remove band servo retainer from transmission case.




- Apply compressed air to oil hole until band servo piston comes out of transmission case.

- Hold piston with a rag and gradually direct air to oil hole.
- Remove return springs.




- Remove springs from accumulator pistons B, C and D.
- Apply compressed air to each oil hole until piston comes out.

- Hold piston with a rag and gradually direct air to oil hole.




Identification of accumulator pistons	A	B	C	D
Identification of oil holes	a	b	c	d

- Remove O-ring from each piston.




21. Remove manual shaft components, if necessary.

- Hold width across flats of manual shaft (outside the transmission case) and remove lock nut from shaft.




DISASSEMBLY


Disassembly (Cont'd)




b. Remove retaining pin from transmission case.




c. While pushing detent spring down, remove manual plate and parking rod from transmission case.



d. Remove manual shaft from transmission case.





e. Remove spacer and detent spring from transmission case.



f. Remove oil seal from transmission case.


REPAIR FOR COMPONENT PARTS

Oil Pump




DISASSEMBLY

1. Loosen bolts in numerical order and remove oil pump cover.



2. Remove rotor, vane rings and vanes.

- Inscribe a mark on back of rotor for identification of fore-aft direction when reassembling rotor. Then remove rotor.



3. While pushing on cam ring remove pivot pin.


- Be careful not to scratch oil pump housing.

REPAIR FOR COMPONENT PARTS


Oil Pump (Cont'd)

4. While holding cam ring and spring lift out cam ring spring.


- Be careful not to damage oil pump housing.
- Hold cam ring spring to prevent it from jumping.



5. Remove cam ring and cam ring spring from oil pump housing.




6. Remove pivot pin from control piston and remove control piston assembly.



7. Remove oil seal from oil pump housing.


- Be careful not to scratch oil pump housing.



INSPECTION


Oil pump cover, rotor, vanes, control piston, side seals, cam ring and friction ring

- Check for wear or damage.



REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



Side clearances

- Measure side clearances between end of oil pump housing and cam ring, rotor, vanes and control piston in at least four places along their circumferences. Maximum measured values should be within specified ranges.
- Before measuring side clearance, check that friction rings, O-ring, control piston side seals and cam ring spring are removed.

Standard clearance:


Cam ring

0.01 - 0.024 mm (0.0004 - 0.0009 in)

Rotor, vanes, control piston

0.03 - 0.044 mm (0.0012 - 0.0017 in)

- If not within standard clearance, replace oil pump assembly except oil pump cover assembly.



Seal ring clearance

- Measure clearance between seal ring and ring groove.


Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Wear limit:

0.25 mm (0.0098 in)


- If not within wear limit, replace oil pump cover assembly.



ASSEMBLY

1. Drive oil seal into oil pump housing.


- Apply A.T.F. to outer periphery and lip surface.




2. Install cam ring in oil pump housing using the following steps.
 - a. Install side seal on control piston.
 - Pay attention to its direction — Black surface goes toward control piston.
 - Apply petroleum jelly to side seal.
 - b. Install control piston on oil pump.

REPAIR FOR COMPONENT PARTS


Oil Pump (Cont'd)




- c. Install O-ring and friction ring on cam ring.
● Apply petroleum jelly to O-ring.




- d. Assemble cam ring, cam ring spring and spring seat. Install spring by pushing it against pump housing.



- e. While pushing on cam ring install pivot pin.




3. Install rotor, vanes and vane rings.
● Pay attention to direction of rotor.



4. Install oil pump housing and oil pump cover.
a. Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly in oil pump housing assembly, then remove masking tape.
b. Tighten bolts in a criss-cross pattern.

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



5. Install seal rings carefully after packing ring grooves with petroleum jelly. Press rings down into jelly to a close fit.

- Seal rings come in two different diameters. Check fit carefully in each groove.

Small dia. seal ring:

No mark


Large dia. seal ring:

Yellow mark in area shown by arrow

- Do not spread gap of seal ring excessively while installing. It may deform ring.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly



⊗ : N·m (kg·m, ft·lb)

SAT193B


AT-96

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)

DISASSEMBLY


1. Remove solenoids.
 - a. Remove lock-up solenoid and side plate from lower body.
 - b. Remove O-ring from solenoid.




- c. Remove line pressure solenoid from upper body.
 - d. Remove O-ring from solenoid.




- e. Remove 3-unit solenoid assembly from upper body.
 - f. Remove O-rings from solenoids.



2. Disassemble upper and lower bodies.
 - a. Place upper body facedown, and remove bolts, reamer bolts and support plates.
 - b. Remove lower body, separator plate and separate gasket as a unit from upper body.
 - **Be careful not to drop pilot filter, orifice check valve, spring and steel balls.**








- c. Place lower body facedown, and remove separate gasket and separator plate.
 - d. Remove pilot filter, orifice check valve and orifice check spring.



REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)

- e. Check to see that steel balls are properly positioned in upper body and then remove them from upper body.



INSPECTION

Lower and upper bodies

- Check to see that there are pins and retainer plates in lower body.

- Check to see that there are pins and retainer plates in upper body.

- **Be careful not to lose these parts.**

- Check to make sure that oil circuits are clean and free from damage.

- Check tube brackets and tube connectors for damage.

Separator plates



- Check to make sure that separator plate is free of damage and not deformed and oil holes are clean.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)


Pilot filter

- Check to make sure that filter is not clogged or damaged.




Lock-up solenoid

- Check that filter is not clogged or damaged.
- Measure resistance. — Refer to "Electrical Components Inspection".




Line pressure solenoid

- Check that filter is not clogged or damaged.
- Measure resistance. — Refer to "Electrical Components Inspection".



3-unit solenoid assembly (Overrun clutch solenoid and shift solenoids A and B)

- Measure resistance of each solenoid. — Refer to "Electrical Components Inspection".




Fluid temperature sensor


- Measure resistance. — Refer to "Electrical Components Inspection".

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd) ASSEMBLY




1. Install upper and lower bodies.
- a. Place oil circuit of upper body face up. Install steel balls in their proper positions.



- b. Install reamer bolts from bottom of upper body and install separate gaskets.




- c. Place oil circuit of lower body face up. Install orifice check spring, orifice check valve and pilot filter.



- d. Install lower separate gaskets and separator plates on lower body.
- e. Install and temporarily tighten support plates, fluid temperature sensor and tube brackets.


REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)



f. Temporarily assemble lower and upper bodies, using reamer bolt as a guide.


- Be careful not to dislocate or drop steel balls, orifice check spring, orifice check valve and pilot filter.



g. Install and temporarily tighten bolts and tube brackets in their proper locations.


Bolt length and location:

Item	Bolt symbol	a	b	c	d
		Bolt length	mm (in)	70 (2.76)	50 (1.97)




2. Install solenoids.

a. Attach O-ring and install lock-up solenoid and side plates onto lower body.



b. Attach O-rings and install 3-unit solenoids assembly onto upper body.




c. Attach O-ring and install line pressure solenoid onto upper body.

3. Tighten all bolts.

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body



Numbers preceding valve springs correspond with those shown in Spring Chart on page AT-105.


Apply A.T.F. to all components before their installation.

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd)

DISASSEMBLY

1. Remove valves at parallel pins.
 - Do not use a magnetic hand.




- a. Use a wire paper clip to push out parallel pins.




- b. Remove parallel pins while pressing their corresponding plugs and sleeves.

- Remove plug slowly to prevent internal parts from jumping out.




- c. Place mating surface of valve facedown, and remove internal parts.

- If a valve is hard to remove, place valve body facedown and lightly tap it with a soft hammer.
- Be careful not to drop or damage valves and sleeves.



2. Remove valves at retainer plates.


- a. Pry out retainer plate with wire paper clip.



REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd)

b. Remove retainer plates while holding spring.




c. Place mating surface of valve facedown, and remove internal parts.

- If a valve is hard to remove, lightly tap valve body with a soft hammer.
- Be careful not to drop or damage valves, sleeves, etc.



● 4-2 sequence valve and relay valve are located far back in upper body. If they are hard to remove, carefully push them out using stiff wire.

- Be careful not to scratch sliding surface of valve with wire.




REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)

INSPECTION

Valve springs

- Measure free length and outer diameter of each valve spring. Also check for damage or deformation.
- Numbers of each valve spring listed in table below are the same as those in the figure on AT-102.



Inspection standard

Unit: mm (in)

Parts	Item	Part No.	ℓ	D
①	Torque converter relief valve spring	31742-41X18	32.3 (1.272)	9.0 (0.354)
②	Pressure regulator valve spring	31742-41X16	61.5 (2.421)	8.9 (0.350)
③	Pressure modifier valve spring	31742-41X19	31.95 (1.2579)	6.8 (0.268)
④	Shuttle shift valve D spring	31762-41X00	26.5 (1.043)	6.0 (0.236)
⑤	4-2 sequence valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
⑥	Shift valve B spring	31762-41X01	25.0 (0.984)	7.0 (0.276)
⑦	4-2 relay valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
⑧	Shift valve A spring	31762-41X01	25.0 (0.984)	7.0 (0.276)
⑨	Overrun clutch control valve spring	31762-41X03	23.6 (0.929)	7.0 (0.276)
⑩	Overrun clutch reducing valve spring	31742-41X14	38.9 (1.531)	7.0 (0.276)
⑪	Shuttle shift valve S spring	31762-41X04	51.0 (2.008)	5.65 (0.2224)
⑫	Pilot valve spring	31742-41X13	25.7 (1.012)	9.1 (0.358)
⑬	Lock-up control valve spring	31742-41X22	18.5 (0.728)	13.0 (0.512)

- Replace valve springs if deformed or fatigued.

Control valves



- Check sliding surfaces of valves, sleeves and plugs.

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd) ASSEMBLY

1. Lubricate the control valve body and all valves with A.T.F. Install control valves by sliding them carefully into their bores.

- Be careful not to scratch or damage valve body.




- Wrap a small screwdriver with vinyl tape and use it to insert the valves into proper position.




Pressure regulator valve

- If pressure regulator plug is not centered properly, sleeve cannot be inserted into bore in upper body. If this happens, use vinyl tape wrapped screwdriver to center sleeve until it can be inserted.
- Turn sleeve slightly while installing.



Accumulator control plug

- Align protrusion of accumulator control sleeve with notch in plug.
- Align parallel pin groove in plug with parallel pin, and install accumulator control valve.




2. Install parallel pins and retainer plates.

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body (Cont'd)

- While pushing plug, install parallel pin.




4-2 sequence valve and relay valve


- Push 4-2 sequence valve and relay valve with wire wrapped in vinyl tape to prevent scratching valve body. Install parallel pins.



- Insert retainer plate while pushing spring.



Control Valve Lower Body



Numbers preceding valve springs correspond with those shown in Spring Chart on page AT-109.


Apply A.T.F. to all components before their installation.

REPAIR FOR COMPONENT PARTS


Control Valve Lower Body (Cont'd)

DISASSEMBLY

1. Remove valves at parallel pins.
 2. Remove valves at retainer plates.
- For removal procedures, refer to "DISASSEMBLY" of Control Valve Upper Body.



SAT838A



SAT829A

INSPECTION

Valve springs

- Check each valve spring for damage or deformation. Also measure free length and outer diameter.
- Numbers of each valve spring listed in table below are the same as those in the figure on AT-108.

Inspection standard:

Unit: mm (in)

Parts	Item	Part No.	l	D
①	Modifier accumulator piston spring	31742-41X15	30.5 (1.201)	9.8 (0.386)
②	1st reducing valve spring	31756-41X05	25.4 (1.000)	6.75 (0.2657)
③	3-2 timing valve spring	31742-41X08	20.55 (0.8091)	6.75 (0.2657)
④	Servo charger valve spring	31742-41X06	23.0 (0.906)	6.7 (0.264)


- Replace valve springs if deformed or fatigued.

Control valves

- Check sliding surfaces of control valves, sleeves and plugs for damage.

ASSEMBLY

- Install control valves.
- For installation procedures, refer to "ASSEMBLY" of Control Valve Upper Body.




SAT838A


Reverse Clutch

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.


(ATF) : Apply A.T.F.
 ★ : Select with proper thickness.



SAT912B



SAT840A




SAT841A

DISASSEMBLY


1. Remove reverse clutch assembly from clutch pack.
2. Check operation of reverse clutch.
 - a. Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not move to snap ring, D-ring or oil seal may be damaged or fluid may be leaking at piston check ball.

REPAIR FOR COMPONENT PARTS


Reverse Clutch (Cont'd)



- Remove drive plates, driven plates, retaining plate, dish plate and snap ring.



- Remove snap ring from clutch drum while compressing clutch springs.
 - Do not expand snap ring excessively.
- Remove spring retainer and return spring.



- Install seal ring onto oil pump cover and install reverse clutch drum. While holding piston, gradually apply compressed air to oil hole until piston is removed.
 - Do not apply compressed air abruptly.
- Remove D-ring and oil seal from piston.

INSPECTION

Reverse clutch snap ring and spring retainer

- Check for deformation, fatigue or damage.



Reverse clutch return springs

- Check for deformation or damage. Also measure free length and outside diameter.

Inspection standard:

Unit: mm (in)

Parts	Part No.	ℓ	D
Spring	30505-41X02	19.69 (0.7752)	11.6 (0.457)



Reverse clutch drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:

Standard value 2.0 mm (0.079 in)

Wear limit 1.8 mm (0.071 in)

- If not within wear limit, replace.

Reverse clutch dish plate






- Check for deformation or damage.

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)

Reverse clutch piston

- Shake piston to assure that balls are not seized.
- Apply compressed air to check ball oil hole opposite the return spring to assure that there is no air leakage.
- Also apply compressed air to oil hole on return spring side to assure that air leaks past ball.





ASSEMBLY

1. Install D-ring and oil seal on piston.
 - **Apply A.T.F. to both parts.**
2. Install piston assembly by turning it slowly and evenly.
 - **Apply A.T.F. to inner surface of drum.**
3. Install return springs and spring retainer.
4. Install snap ring while compressing clutch springs.


REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)


- Do not align snap ring gap with spring retainer stopper.



5. Install drive plates, driven plates, retaining plate and dish plate.



6. Install snap ring.



7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit

1.2 mm (0.047 in)

Retaining plate:


Refer to S.D.S.



8. Check operation of reverse clutch.
Refer to "DISASSEMBLY" of Reverse Clutch.


High Clutch

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.



(ATF) : Apply A.T.F.
 ★ : Select with proper thickness.


SAT913B



SAT853A

Service procedures for high clutch are essentially the same as those for reverse clutch, with the following exception:


- Check of high clutch operation




SAT854A

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)



- Removal and installation of return spring




- Inspection of high clutch return springs

Inspection standard:

Unit: mm (in)

Part No.	ℓ	D
31505-21X03	22.06 (0.8685)	11.6 (0.457)



- Inspection of high clutch drive plate


Thickness of drive plate:

Standard

1.6 mm (0.063 in)

Wear limit

1.4 mm (0.055 in)



- Measurement of clearance between retaining plate and snap ring

Specified clearance:

Standard

1.8 - 2.2 mm (0.071 - 0.087 in)

Allowable limit

3.2 mm (0.126 in)


Retaining plate:

Refer to S.D.S.

REPAIR FOR COMPONENT PARTS

Forward and Overrun Clutches

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.



(ATF) : Apply A.T.F.

★ : Select with proper thickness.

SAT914B


AT-116

REPAIR FOR COMPONENT PARTS


Forward and Overrun Clutches (Cont'd)

Service procedures for forward and overrun clutches are essentially the same as those for reverse clutch, with the following exception:


- Check of forward clutch operation.




- Check of overrun clutch operation.




- Removal of forward clutch drum
Remove forward clutch drum from transmission case by holding snap ring.



- Removal of forward clutch and overrun clutch pistons
1. While holding overrun clutch piston, gradually apply compressed air to oil hole.





2. Remove overrun clutch from forward clutch.



REPAIR FOR COMPONENT PARTS

Forward and Overrun Clutches (Cont'd)

- Removal and installation of return springs




- Inspection of forward clutch and overrun clutch return springs

Inspection standard:

Unit: mm (in)

Part No.	ℓ	D
31505-41X01	35.77 (1.4083)	9.7 (0.382)



- Inspection of forward clutch drive plates


Thickness of drive plate:

Standard

2.0 mm (0.079 in)

Wear limit

1.8 mm (0.071 in)



- Inspection of overrun clutch drive plates


Thickness of drive plate:

Standard

2.0 mm (0.079 in)

Wear limit

1.8 mm (0.071 in)



- Installation of forward clutch piston and overrun clutch piston



1. Install forward clutch piston by turning it slowly and evenly.

- Apply A.T.F. to inner surface of clutch drum.


REPAIR FOR COMPONENT PARTS

Forward and Overrun Clutches (Cont'd)

- Align notch in forward clutch piston with groove in forward clutch drum.



2. Install overrun clutch by turning it slowly and evenly.
- Apply A.T.F. to inner surface of forward clutch piston.



- Measurement of clearance between retaining plate and snap ring of overrun clutch

Specified clearance:

Standard


1.0 - 1.4 mm (0.039 - 0.055 in)

Allowable limit

2.0 mm (0.079 in)

Retaining plate:

Refer to S.D.S.



- Measurement of clearance between retaining plate and snap ring of forward clutch

Specified clearance:

Standard

0.45 - 0.85 mm (0.0177 - 0.0335 in)

Allowable limit


2.05 mm (0.0807 in)

Retaining plate:

Refer to S.D.S.



Low & Reverse Brake

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.



- (ATF) : Apply A.T.F.
- (P) : Apply petroleum jelly.
- ★ : Select with proper thickness.

SAT915B




DISASSEMBLY


1. Check operation of low and reverse brake.
 - a. Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not move to snap ring, D-ring or oil seal may be damaged or fluid may be leaking at piston check ball.
2. Remove snap ring, low and reverse brake drive plates, driven plates and dish plate.

REPAIR FOR COMPONENT PARTS


Low & Reverse Brake (Cont'd)



- Remove low one-way clutch inner race, spring retainer and return spring from transmission case.



- Remove seal rings from low one-way clutch inner race.
- Remove needle bearing from low one-way clutch inner race.



- Remove low and reverse brake piston using compressed air.
- Remove oil seal and D-ring from piston.


INSPECTION

Low and reverse brake snap ring and spring retainer

- Check for deformation, or damage.

Low and reverse brake return springs

- Check for deformation or damage. Also measure free length and outside diameter.



Inspection standard:

Unit: mm (in)

Part No.	ℓ	D
31521-21X00	23.7 (0.933)	11.6 (0.457)

Low and reverse brake drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:


Standard value

2.0 mm (0.079 in)

Wear limit

1.8 mm (0.071 in)

- If not within wear limit, replace.





REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)

Low one-way clutch inner race

- Check frictional surface of inner race for wear or damage.



- Install a new seal rings onto low one-way clutch inner race.
- **Be careful not to expand seal ring gap excessively.**
- Measure seal ring-to-groove clearance.

Inspection standard:


Standard value 0.10 - 0.25 mm (0.0039 - 0.0098 in)

Allowable limit 0.25 mm (0.0098 in)


- If not within allowable limit, replace low one-way clutch inner race.

ASSEMBLY


1. Install bearing onto one-way clutch inner race.
 - Pay attention to its direction — **Black surface goes to rear side.**
 - Apply petroleum jelly to needle bearing.



2. Install oil seal and D-ring onto piston.
 - Apply A.T.F. to oil seal and D-ring.




3. Install piston by rotating it slowly and evenly.
 - Apply A.T.F. to inner surface of transmission case.




REPAIR FOR COMPONENT PARTS


Low & Reverse Brake (Cont'd)




4. Install return springs, spring retainer and low one-way clutch inner race onto transmission case.



5. Install dish plate, low and reverse brake drive plates, driven plates and retaining plate.
6. Install snap ring on transmission case.



7. Check operation of low and reverse brake clutch piston. Refer to "DISASSEMBLY".



8. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


1.1 - 1.5 mm (0.043 - 0.059 in)

Allowable limit

2.5 mm (0.098 in)


Retaining plate:

Refer to S.D.S.



9. Install low one-way clutch inner race seal ring.
 - Apply petroleum jelly to seal ring.
 - Make sure seal rings are pressed firmly into place and held by petroleum jelly.


Forward Clutch Drum Assembly




SAT886A

DISASSEMBLY


1. Remove snap ring from forward clutch drum.



2. Remove side plate from forward clutch drum.




3. Remove low one-way clutch from forward clutch drum.




REPAIR FOR COMPONENT PARTS

Forward Clutch Drum Assembly (Cont'd)

4. Remove snap ring from forward clutch drum.




5. Remove needle bearing from forward clutch drum.



INSPECTION


Forward clutch drum

- Check spline portion for wear or damage.
- Check frictional surfaces of low one-way clutch and needle bearing for wear or damage.




Needle bearing and low one-way clutch

- Check frictional surface for wear or damage.



ASSEMBLY


1. Install needle bearing in forward clutch drum.



REPAIR FOR COMPONENT PARTS


Forward Clutch Drum Assembly (Cont'd)

2. Install snap ring onto forward clutch drum.




SAT890A

3. Install low one-way clutch onto forward clutch drum by pushing the roller in evenly.




SAT894A

● Install low one-way clutch with flange facing rearward.



SAT895A



4. Install side plate onto forward clutch drum.
5. Install snap ring onto forward clutch drum.



SAT887A


REPAIR FOR COMPONENT PARTS

Rear Internal Gear and Forward Clutch Hub




DISASSEMBLY

1. Remove rear internal gear by pushing forward clutch hub forward.



2. Remove thrust washer from rear internal gear.




3. Remove snap ring from forward clutch hub.


REPAIR FOR COMPONENT PARTS

Rear Internal Gear and Forward Clutch Hub (Cont'd)


4. Remove end bearing.



5. Remove forward one-way clutch and end bearing as a unit from forward clutch hub.



6. Remove snap ring from forward clutch hub.





INSPECTION

Rear internal gear and forward clutch hub

- Check gear for excessive wear, chips or cracks.
- Check frictional surfaces of forward one-way clutch and thrust washer for wear or damage.
- Check spline for wear or damage.

Snap ring and end bearing

- Check for deformation or damage.








REPAIR FOR COMPONENT PARTS



Rear Internal Gear and Forward Clutch Hub (Cont'd)

ASSEMBLY

1. Install snap ring onto forward clutch hub.
2. Install end bearing.
3. Install forward one-way clutch onto clutch hub.
 - **Install forward one-way clutch with flange facing rearward.**
4. Install end bearing.
5. Install snap ring onto forward clutch hub.
6. Install thrust washer onto rear internal gear.
 - **Apply petroleum jelly to thrust washer.**
 - **Securely insert pawls of thrust washer into holes in rear internal gear.**
7. Position forward clutch hub in rear internal gear.
8. After installing, check to assure that forward clutch hub rotates clockwise.




Band Servo Piston Assembly




DISASSEMBLY

1. Block one oil hole in O.D. servo piston retainer and the center hole in O.D. band servo piston.
2. Apply compressed air to the other oil hole in piston retainer to remove O.D. band servo piston from retainer.
3. Remove D-ring from O.D. band servo piston.




4. Remove band servo piston assembly from servo piston retainer by pushing it forward.




5. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.

REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)




6. Remove servo piston spring retainer, return spring C and piston stem from band servo piston.



7. Remove E-ring from band servo piston.




8. Remove servo cushion spring retainer from band servo piston.
9. Remove D-rings from band servo piston.
10. Remove O-rings from servo piston retainer.



INSPECTION

Pistons, retainers and piston stem

- Check frictional surfaces for abnormal wear or damage.



Return springs

- Check for deformation or damage. Measure free length and outer diameter.

Inspection standard:

Unit: mm (in)


Parts	Free length	Outer diameter
Spring A	45.6 (1.795)	34.3 (1.350)
Spring B	53.8 (2.118)	40.3 (1.587)
Spring C	29.0 (1.142)	27.6 (1.087)

REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)

ASSEMBLY


1. Install O-rings onto servo piston retainer.
 - Apply A.T.F. to O-rings.
 - Pay attention to position of each O-ring.




2. Install servo cushion spring retainer onto band servo piston.




3. Install E-ring onto servo cushion spring retainer.



4. Install D-rings onto band servo piston.
 - Apply A.T.F. to D-rings.




5. Install servo piston spring retainer, return spring C and piston stem onto band servo piston.




REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)




6. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.



7. Install band servo piston assembly onto servo piston retainer by pushing it inward.





8. Install D-ring on O.D. band servo piston.
● **Apply A.T.F. to D-ring.**




9. Install O.D. band servo piston onto servo piston retainer by pushing it inward.

Parking Pawl Components




DISASSEMBLY

1. Slide return spring to the front of rear extension flange.



2. Remove return spring, pawl spacer and parking pawl from rear extension.
3. Remove parking pawl shaft from rear extension.



4. Remove parking actuator support and rod guide from rear extension.


REPAIR FOR COMPONENT PARTS

Parking Pawl Components (Cont'd)

INSPECTION

Parking pawl and parking actuator support


- Check contact surface of parking rod for wear.



SAT929A


ASSEMBLY

1. Install rod guide and parking actuator support onto rear extension.
2. Insert parking pawl shaft into rear extension.




SAT930A

3. Install return spring, pawl spacer and parking pawl onto parking pawl shaft.








SAT927A

4. Bend return spring upward and install it onto rear extension.



SAT926A

ASSEMBLY




Assembly

1. Install manual shaft components.
 - a. Install oil seal onto manual shaft.
 - **Apply A.T.F. to oil seal.**
 - **Wrap threads of manual shaft with masking tape.**
 - b. Insert manual shaft and oil seal as a unit into transmission case.
 - c. Remove masking tape.
- d. Push oil seal evenly and install it onto transmission case.
- e. Align groove in shaft with drive pin hole, then drive pin into position as shown in figure at left.
- f. Install detent spring and spacer.
- g. While pushing detent spring down, install manual plate onto manual shaft.

ASSEMBLY

Assembly (Cont'd)


h. Install lock nuts onto manual shaft.



2. Install accumulator piston.

a. Install O-rings onto accumulator piston.

● **Apply A.T.F. to O-rings.**



Accumulator piston O-rings:

Unit: mm (in)


Accumulator	A	B	C	D
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)

b. Install return spring for accumulator A onto transmission case.

Free length of return spring:


Unit: mm (in)

Accumulator	A
Free length	43 (1.69)




c. Install accumulator pistons A, B, C and D.

● **Apply A.T.F. to transmission case.**




3. Install band servo piston.

a. Install return springs onto servo piston.




ASSEMBLY


Assembly (Cont'd)




- b. Install band servo piston onto transmission case.
 - Apply A.T.F. to O-ring of band servo piston and transmission case.
- c. Install gasket for band servo onto transmission case.




- d. Install band servo retainer onto transmission case.



- 4. Install rear side clutch and gear components.
 - a. Place transmission case in vertical position.




- b. Slightly lift forward clutch drum assembly and slowly rotate it clockwise until its hub passes fully over the clutch inner race inside transmission case.




- c. Check to be sure that rotation direction of forward clutch assembly is correct.

ASSEMBLY


Assembly (Cont'd)




- d. Install thrust washer onto front of overrun clutch hub.
- Apply petroleum jelly to the thrust washer.
 - Insert pawls of thrust washer securely into holes in overrun clutch hub.




- e. Install overrun clutch hub onto rear internal gear assembly.



- f. Install needle bearing onto rear of overrun clutch hub.
- Apply petroleum jelly to needle bearing.



- g. Check that overrun clutch hub rotates as shown while holding forward clutch hub.




- h. Place transmission case into horizontal position.


ASSEMBLY

Assembly (Cont'd)


- i. Install rear internal gear, forward clutch hub and overrun clutch hub as a unit onto transmission case.




- j. Install needle bearing onto rear internal gear.
● **Apply petroleum jelly to needle bearing.**



- k. Install bearing race onto rear of front internal gear.
● **Apply petroleum jelly to bearing race.**
● **Securely engage pawls of bearing race with holes in front internal gear.**



- l. Install front internal gear on transmission case.





ASSEMBLY

Adjustment

When any parts listed in the following table are replaced, total end play or reverse clutch end play must be adjusted.

Part name	Item	Total end play	Reverse clutch end play
Transmission case		•	•
Low one-way clutch inner race		•	•
Overrun clutch hub		•	•
Rear internal gear		•	•
Rear planetary carrier		•	•
Rear sun gear		•	•
Front planetary carrier		•	•
Front sun gear		•	•
High clutch hub		•	•
High clutch drum		•	•
Oil pump cover		•	•
Reverse clutch drum		—	•



1. Install front side clutch and gear components.

a. Install rear sun gear on transmission case.

- Pay attention to its direction.

b. Install needle bearing on front of front planetary carrier.

- Apply petroleum jelly to needle bearing.

c. Install needle bearing on rear of front planetary carrier.



- Apply petroleum jelly to bearing.

- Pay attention to its direction — Black side goes to front.


ASSEMBLY

Adjustment (Cont'd)

d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.




● Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.




e. Install bearing races on rear of clutch pack.

● Apply petroleum jelly to bearing races.

● Securely engage pawls of bearing race with hole in clutch pack.




f. Place transmission case in vertical position.




g. Install clutch pack into transmission case.

ASSEMBLY


Adjustment (Cont'd)




2. Adjust total end play.
 - a. Install new oil pump gasket on transmission case.




- b. Install pump cover bearing race on clutch pack.



- c. Measure distance "B" between front end of transmission case and oil pump cover bearing race.



- d. Measure distance "C" between front end of transmission case and oil pump gasket.




- e. Determine dimension "A" by using the following equation.


$$A = B - C$$

ASSEMBLY

Adjustment (Cont'd)



- f. Install needle bearing on oil pump assembly.
- g. Measure distance "D" between needle bearing and machined surface of oil pump cover assembly.



- h. Determine total end play "T₁" by using the following equation.

$$T_1 = A - D - 0.1$$


Total end play "T₁":

0.25 - 0.55 mm (0.0098 - 0.0217 in)


- If end play is out of specification, decrease or increase thickness of oil pump cover bearing race as necessary.

Available oil pump cover bearing race:

Refer to S.D.S.



- 3. Adjust reverse clutch drum end play.
- a. Install oil pump thrust washer on clutch pack.




- b. Measure distance "F" between front end of transmission case and oil pump thrust washer.
- c. Measure distance "G" between front end of transmission case and gasket.

ASSEMBLY


Adjustment (Cont'd)

d. Determine dimension "E" by using the following equation.

$$E = F - G$$



e. Measure distance "H".



f. Determine reverse clutch drum end play "T₂" by using the following equation.

$$T_2 = E - H - 0.1$$

Reverse clutch drum end play "T₂":


0.55 - 0.90 mm (0.0217 - 0.0354 in)

- If end play is out of specification, decrease or increase thickness of oil pump thrust washer as necessary.

Available oil pump thrust washer:


Refer to S.D.S.

4. Remove any part installed to adjust end plays.




ASSEMBLY


Assembly




1. Install output shaft and parking gear.
 - a. Insert output shaft from rear of transmission case while slightly lifting front internal gear.
 - Do not force output shaft against front of transmission case.




- b. Carefully push output shaft against front of transmission case. Install snap ring on front of output shaft.
 - Check to be sure output shaft cannot be removed in rear direction.



- c. Install needle bearing on transmission case.
 - Pay attention to its direction — Black side goes to rear.
 - Apply petroleum jelly to needle bearing.



- d. Install parking gear on transmission case.





- e. Install snap ring on rear of output shaft.
 - Check to be sure output shaft cannot be removed in forward direction.


ASSEMBLY

Assembly (Cont'd)


2. Install rear extension.
 - a. Install oil seal on rear extension.
 - Apply A.T.F. to oil seal.




- b. Install O-ring on revolution sensor.
 - Apply A.T.F. to O-ring.
 - c. Install revolution sensor on rear extension.



- d. Install rear extension gasket on transmission case.








- e. Install parking rod on transmission case.



- f. Install rear extension on transmission case.

ASSEMBLY

Assembly (Cont'd)



3. Install front side clutch and gear components.

a. Install rear sun gear on transmission case.

- Pay attention to its direction.

b. Make sure needle bearing is on front of front planetary carrier.

- Apply petroleum jelly to needle bearing.

c. Make sure needle bearing is on rear of front planetary carrier.

- Apply petroleum jelly to bearing.

- Pay attention to its direction — Black side goes to front.

d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.

- Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.

e. Make sure bearing races are on front and rear of clutch pack.


- Apply petroleum jelly to bearing races.

- Securely engage pawls of bearing races with holes in clutch pack.

ASSEMBLY

Assembly (Cont'd)


f. Install clutch pack into transmission case.




4. Install brake band and band strut.

a. Install band strut on brake band.


● Apply petroleum jelly to band strut.



b. Place brake band on periphery of reverse clutch drum, and insert band strut into end of band servo piston stem.




c. Install anchor end bolt on transmission case. Then, tighten anchor end bolt just enough so that reverse clutch drum (clutch pack) will not tilt forward.



5. Install input shaft on transmission case.






● Pay attention to its direction — O-ring groove side is front.

6. Install gasket on transmission case.



ASSEMBLY

Assembly (Cont'd)



7. Install oil pump assembly.
 - a. Install needle bearing on oil pump assembly.
 - **Apply petroleum jelly to the needle bearing.**
 - b. Install selected thrust washer on oil pump assembly.
 - **Apply petroleum jelly to thrust washer.**

- c. Carefully install seal rings into grooves and press them into the petroleum jelly so that they are a tight fit.

- d. Install O-ring on oil pump assembly.
 - **Apply petroleum jelly to O-ring.**



- e. Apply petroleum jelly to mating surface of transmission case and oil pump assembly.

- f. Install oil pump assembly.
 - **Install two converter housing securing bolts in bolt holes in oil pump assembly as guides.**


ASSEMBLY

Assembly (Cont'd)


- Insert oil pump assembly to the specified position in transmission, as shown at left.




8. Install O-ring on input shaft.
- Apply A.T.F. to O-rings.



9. Install converter housing.
- a. Install O-rings on converter housing.



- b. Apply recommended sealant (Nissan genuine part: KP610-00250 or equivalent) to outer periphery of bolt holes in converter housing.
- Do not apply too much sealant.





- c. Apply recommended sealant (Nissan genuine part: KP610-00250 or equivalent) to seating surfaces of bolts that secure front of converter housing.

ASSEMBLY

Assembly (Cont'd)

d. Install converter housing on transmission case.



10. Adjust brake band.


a. Tighten anchor end bolt to specified torque.

Anchor end bolt:


: 4 - 6 N·m

(0.4 - 0.6 kg-m, 2.9 - 4.3 ft-lb)

b. Back off anchor end bolt two and a half turns.



c. While holding anchor end pin, tighten lock nut.




11. Install terminal cord assembly.

a. Install O-ring on terminal cord assembly.

● **Apply petroleum jelly to O-ring.**

b. Compress terminal cord assembly stopper and install terminal cord assembly on transmission case.



12. Install control valve assembly.

a. Install accumulator piston return springs B, C and D.

Free length of return springs:


Unit: mm (in)

Item	Accumulator	B	C	D
Free length		66 (2.60)	45 (1.77)	58.4 (2.299)


ASSEMBLY

Assembly (Cont'd)


- b. Install manual valve on control valve.
 ● Apply A.T.F. to manual valve.




- c. Place control valve assembly on transmission case. Connect solenoid connector for upper body.
 d. Install connector clip.




- e. Install control valve assembly on transmission case.
 f. Install connector tube brackets and tighten bolts (A) and (B).
 ● Check that terminal assembly harness does not catch.




Bolt symbol	ℓ mm (in)	 ℓ
(A)	33 (1.30)	
(B)	45 (1.77)	

- g. Install O-ring on oil strainer.
 ● Apply petroleum jelly to O-ring.
 h. Install oil strainer on control valve.




ASSEMBLY


Assembly (Cont'd)



- i. Securely fasten terminal harness with clips.




- j. Install lock-up solenoid and fluid temperature sensor connectors.



13. Install oil pan.


- a. Attach a magnet to oil pan.



- b. Install oil pan gasket on transmission case.

- c. Install oil pan and bracket on transmission case.

- Tighten four bolts in a criss-cross pattern to prevent dislocation of gasket.



14. Install inhibitor switch.


- a. Check that manual shaft is in "1" range.

- b. Temporarily install inhibitor switch on manual shaft.


- c. Move manual shaft to "N".

ASSEMBLY


Assembly (Cont'd)




- d. Tighten bolts while inserting 4.0 mm (0.157 in) dia. pin vertically into locating holes in inhibitor switch and manual shaft.



15. Install torque converter.
- a. Pour A.T.F. into torque converter.
- Approximately 2 liters (1-3/4 Imp qt) of fluid are required for a new torque converter.
 - When reusing old torque converter, add the same amount of fluid as was drained.



- b. Install torque converter while aligning notches and oil pump.



- c. Measure distance A to check that torque converter is in proper position.

Distance "A":

23.5 mm (0.925 in) or more

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

Engine	CA18DET
Automatic transmission model	RE4R01A
Transmission model code number	41X71
Stall torque ratio	2.0 : 1
Transmission gear ratio	
1st	3.027
2nd	1.619
Top	1.000
O.D.	0.694
Reverse	2.272
Recommended oil	Automatic transmission fluid Type DEXRON™
Oil capacity ℓ (Imp qt)	7.9 (7)

Specifications and Adjustment

VEHICLE SPEED WHEN SHIFTING GEARS

Europe

Throttle position	Vehicle speed km/h (MPH)						
	D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	58 - 62 (36 - 39)	109 - 115 (68 - 71)	176 - 186 (109 - 116)	170 - 180 (106 - 112)	104 - 110 (65 - 68)	44 - 48 (27 - 30)	53 - 57 (33 - 35)
Half throttle	41 - 45 (25 - 28)	78 - 84 (48 - 52)	125 - 135 (78 - 84)	74 - 84 (46 - 52)	29 - 35 (18 - 22)	10 - 14 (6 - 9)	53 - 57 (33 - 35)

Except Europe

Throttle position	Vehicle speed km/h (MPH)						
	D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	54 - 58 (34 - 36)	101 - 107 (63 - 66)	164 - 174 (102 - 108)	158 - 168 (98 - 104)	95 - 101 (59 - 63)	44 - 48 (27 - 30)	53 - 57 (33 - 35)
Half throttle	41 - 45 (25 - 28)	73 - 79 (45 - 49)	119 - 129 (74 - 80)	78 - 88 (48 - 55)	34 - 40 (21 - 25)	10 - 14 (6 - 9)	53 - 57 (33 - 35)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

VEHICLE SPEED WHEN PERFORMING AND RELEASING LOCK-UP

Europe

Throttle position	D ₄	
	Vehicle speed km/h (MPH)	
	Lock-up "ON"	Lock-up "OFF"
Full throttle	176 - 186 (109 - 116)	170 - 180 (106 - 112)
Half throttle	126 - 134 (78 - 83)	110 - 118 (68 - 73)

Except Europe

Throttle position	D ₄	
	Vehicle speed km/h (MPH)	
	Lock-up "ON"	Lock-up "OFF"
Full throttle	164 - 174 (102 - 108)	158 - 168 (98 - 104)
Half throttle	120 - 128 (75 - 80)	102 - 110 (63 - 68)

STALL REVOLUTION

Stall revolution rpm
3,050 - 3,250

LINE PRESSURE

Engine speed rpm	Line pressure kPa (bar, kg/cm ² , psi)	
	D, 2 and 1 ranges	R range
Idle	471 - 510 (4.71 - 5.10, 4.8 - 5.2, 68 - 74)	657 - 696 (6.57 - 6.96, 6.7 - 7.1, 95 - 101)
Stall	1,020 - 1,098 (10.20 - 10.98, 10.4 - 11.2, 148 - 159)	1,422 - 1,500 (14.22 - 15.00, 14.5 - 15.3, 206 - 218)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

RETURN SPRINGS

Unit: mm (in)

Parts	Item	Part No.	Free length	Outer diameter	
Control valve	Upper body	Torque converter relief valve spring	31742-41X18	32.3 (1.272)	9.0 (0.354)
		Pressure regulator valve spring	31742-41X16	61.5 (2.421)	8.9 (0.350)
		Pressure modifier valve spring	31742-41X19	31.95 (1.2579)	6.8 (0.268)
		Shuttle shift valve D spring	31762-41X00	26.5 (1.043)	6.0 (0.236)
		4-2 sequence valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
		Shift valve B spring	31762-41X01	25.0 (0.984)	7.0 (0.276)
		4-2 relay valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
		Shift valve A spring	31762-41X01	25.0 (0.984)	7.0 (0.276)
		Overrun clutch control valve spring	31762-41X03	23.6 (0.929)	7.0 (0.276)
		Overrun clutch reducing valve spring	31742-41X14	38.9 (1.531)	7.0 (0.276)
		Shuttle shift valve S spring	31762-41X04	51.0 (2.008)	5.65 (0.2224)
		Pilot valve spring	31742-41X13	25.7 (1.012)	9.1 (0.358)
		Lock-up control valve spring	31742-41X22	18.5 (0.728)	13.0 (0.512)
	Lower body	Modifier accumulator piston spring	31742-41X15	30.5 (1.201)	9.8 (0.386)
		1st reducing valve spring	31756-41X05	25.4 (1.000)	6.75 (0.2657)
3-2 timing valve spring		31742-41X08	20.55 (0.8091)	6.75 (0.2657)	
Servo charger valve spring		31742-41X06	23.0 (0.906)	6.7 (0.264)	
Reverse clutch	16 pcs	30505-41X02	19.69 (0.7752)	11.6 (0.457)	
High clutch	16 pcs	31505-21X03	22.06 (0.8685)	11.6 (0.457)	
Forward clutch (Overrun clutch)	20 pcs	31505-41X01	35.77 (1.4083)	9.7 (0.382)	
Low & reverse brake	18 pcs	31521-21X00	23.7 (0.933)	11.6 (0.457)	
Band servo	Spring A	31605-41X05	45.6 (1.795)	34.3 (1.350)	
	Spring B	31605-41X00	53.8 (2.118)	40.3 (1.587)	
	Spring C	31605-41X01	29.0 (1.142)	27.6 (1.087)	
Accumulator	Accumulator A	31605-41X02	43.0 (1.693)	27.6 (1.087)	
	Accumulator B	31605-41X10	66.0 (2.598)	27.6 (1.087)	
	Accumulator C	31605-41X09	45.0 (1.772)	27.6 (1.087)	
	Accumulator D	31605-41X06	58.4 (2.299)	27.6 (1.087)	

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

ACCUMULATOR O-RING

Accumulator	Diameter mm (in)			
	A	B	C	D
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)

CLUTCHES AND BRAKES

Reverse clutch		
Number of drive plates	2	
Number of driven plates	2	
Thickness of drive plate mm (in)		
Standard	2.0 (0.079)	
Wear limit	1.8 (0.071)	
Clearance mm (in)		
Standard	0.5 - 0.8 (0.020 - 0.031)	
Allowable limit	1.2 (0.047)	
Thickness of retaining plate	Thickness mm (in)	Part number
	4.6 (0.181)	31537-21X00
	4.8 (0.189)	31537-21X01
	5.0 (0.197)	31537-21X02
	5.2 (0.205)	31537-21X03
	5.4 (0.213)	31537-21X04
	5.6 (0.220)	31567-41X13
5.8 (0.228)	31567-41X14	
High clutch		
Number of drive plates	5	
Number of driven plates	5	
Thickness of drive plate mm (in)		
Standard	1.6 (0.063)	
Wear limit	1.4 (0.055)	
Clearance mm (in)		
Standard	1.8 - 2.2 (0.071 - 0.087)	
Allowable limit	3.2 (0.126)	
Thickness of retaining plate	Thickness mm (in)	Part number
	3.4 (0.134)	31537-41X71
	3.6 (0.142)	31537-41X61
	3.8 (0.150)	31537-41X62
	4.0 (0.157)	31537-41X63
	4.2 (0.165)	31537-41X64
	4.4 (0.173)	31537-41X65
4.6 (0.181)	31537-41X66	
4.8 (0.189)	31537-41X67	

Forward clutch		
Number of drive plates	5	
Number of driven plates	5	
Thickness of drive plate mm (in)		
Standard	2.0 (0.079)	
Wear limit	1.8 (0.071)	
Clearance mm (in)		
Standard	0.45 - 0.85 (0.0177 - 0.0335)	
Allowable limit	2.05 (0.0807)	
Thickness of retaining plate	Thickness mm (in)	Part number
	4.0 (0.157)	31537-41X07
	4.2 (0.165)	31537-41X08
	4.4 (0.173)	31537-41X09
	4.6 (0.181)	31537-41X10
	4.8 (0.189)	31537-41X11
	5.0 (0.197)	31537-41X12
5.2 (0.205)	31537-41X13	
Overrun clutch		
Number of drive plates	3	
Number of driven plates	5	
Thickness of drive plate mm (in)		
Standard	2.0 (0.079)	
Wear limit	1.8 (0.071)	
Clearance mm (in)		
Standard	1.0 - 1.4 (0.039 - 0.055)	
Allowable limit	2.0 (0.079)	
Thickness of retaining plate	Thickness mm (in)	Part number
	4.0 (0.157)	31537-41X79
	4.2 (0.165)	31537-41X80
	4.4 (0.173)	31537-41X81
	4.6 (0.181)	31537-41X82
	4.8 (0.189)	31537-41X83
	5.0 (0.197)	31537-41X84
5.2 (0.205)	31537-41X20	

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Specifications and Adjustment (Cont'd)

Low & reverse brake		
Number of drive plates	6	
Number of driven plates	6	
Thickness of drive plate mm (in)		
Standard	2.0 (0.079)	
Wear limit	1.8 (0.071)	
Clearance mm (in)		
Standard	1.1 - 1.5 (0.043 - 0.059)	
Allowable limit	2.5 (0.098)	
Thickness of retaining plate	Thickness mm (in)	Part number
	8.6 (0.339)	31667-41X03
	8.8 (0.346)	31667-41X04
	9.0 (0.354)	31667-41X05
	9.2 (0.362)	31667-41X06
	9.4 (0.370)	31667-41X09
9.6 (0.378)	31667-41X10	
Brake band		
Anchor end bolt tightening torque N·m (kg-m, ft-lb)	4 - 6 (0.4 - 0.6, 2.9 - 4.3)	
Number of returning revolutions for anchor end bolt	2.5	

REVERSE CLUTCH DRUM END PLAY

Reverse clutch drum end play "T ₂ "	0.55 - 0.90 mm (0.0217 - 0.0354 in)	
Thickness of oil pump thrust washer	Thickness mm (in)	Part number
	0.7 (0.028)	31528-21X00
	0.9 (0.035)	31528-21X01
	1.1 (0.043)	31528-21X02
	1.3 (0.051)	31528-21X03
	1.5 (0.059)	31528-21X04
	1.7 (0.067)	31528-21X05
1.9 (0.075)	31528-21X06	

REMOVAL AND INSTALLATION

Manual control linkage Number of returning revolutions for lock nut	1
Lock nut tightening torque	11 - 15 N·m (1.1 - 1.5 kg-m, 8 - 11 ft-lb)
Distance between end of clutch housing and torque converter	26.0 mm (1.024 in) or more
Drive plate runout limit	0.5 mm (0.020 in)

OIL PUMP AND LOW ONE-WAY CLUTCH

Oil pump clearance mm (in)	
Cam ring - oil pump housing Standard	0.01 - 0.024 (0.0004 - 0.0009)
Rotor, vanes and control piston - oil pump housing Standard	0.03 - 0.044 (0.0012 - 0.0017)
Seal ring clearance mm (in)	
Standard	0.10 - 0.25 (0.0039 - 0.0098)
Allowable limit	0.25 (0.0098)

TOTAL END PLAY

Total end play "T ₁ "	0.25 - 0.55 mm (0.0098 - 0.0217 in)	
Thickness of oil pump cover bearing race	Thickness mm (in)	Part number
	0.8 (0.031)	31429-21X00
	1.0 (0.039)	31429-21X01
	1.2 (0.047)	31429-21X02
	1.4 (0.055)	31429-21X03
	1.6 (0.063)	31429-21X04
	1.8 (0.071)	31429-21X05
2.0 (0.079)	31429-21X06	