

ELECTRICAL SYSTEM

SECTION EL

When you read wiring diagrams:

● Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

CONTENTS

PRECAUTIONS	4	Rotor Check	42
Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	Brush Check	42
HARNES CONNECTOR	5	Stator Check	43
Description	5	Diode Check	44
STANDARDIZED RELAY	6	Assembly	45
Description	6	Service Data and Specifications (SDS)	45
POWER SUPPLY ROUTING	8	COMBINATION SWITCH	46
Schematic	8	Check	46
Wiring Diagram — POWER —	10	Replacement	48
Fuse	19	HEADLAMP	49
Fusible Link	19	Bulb Replacement	49
Circuit Breaker	19	Bulb Specifications	49
BATTERY	20	HEADLAMP — Without Daytime Light System —	50
How to Handle Battery	20	System Description	50
Battery Test and Charging Chart	23	Schematic	51
Service Data and Specifications (SDS)	27	Wiring Diagram — H/LAMP —	52
STARTING SYSTEM	28	Trouble Diagnoses	55
System Description	28	HEADLAMP — Daytime Light System —	56
Wiring Diagram — START —	29	System Description	56
Trouble-shooting	31	Operation (Daytime light system)	57
Construction	32	Schematic	58
Removal and Installation	32	Wiring Diagram — DTRL —	59
Magnetic Switch Check	33	Trouble Diagnoses	62
Pinion/Clutch Check	33	HEADLAMP — Headlamp Aiming Control —	64
Brush Check	33	Description	64
Yoke Check	34	Wiring Diagram — AIM —	66
Armature Check	35	Aiming Adjustment	70
Assembly	36	Trouble Diagnoses	71
Service Data and Specifications (SDS)	37	EXTERIOR LAMP	72
CHARGING SYSTEM	38	Clearance, License and Tail Lamps/System Description	72
System Description	38	Clearance, License and Tail Lamps/ Wiring Diagram — TAIL/L —	74
Wiring Diagram — CHARGE —	39	Stop Lamp/Wiring Diagram — STOP/L —	80
Trouble-shooting	40	Back-up Lamp/Wiring Diagram — BACK/L —	81
Construction	41		
Removal and Installation	41		
Disassembly	42		

CONTENTS (Cont'd.)

Front Fog Lamps/System Description	82	Front Wiper and Washer/Wiring Diagram	
Front Fog Lamp/Wiring Diagram — F/FOG —	84	— WIPER —	140
Front Fog Lamp Aiming Adjustment	89	Trouble Diagnoses	142
Rear Fog Lamp/System Description	90	Front Wiper Amplifier Check	144
Rear Fog Lamp/Wiring Diagram — R/FOG —	91	Front Wiper Installation and Adjustment	144
Turn Signal and Hazard Warning Lamps/System Description	93	Front Washer Nozzle Adjustment	144
Turn Signal and Hazard Warning Lamps/Schematic	95	Front Washer Tube Layout	145
Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN —	96	Front Wiper Linkage	146
Turn Signal and Hazard Warning Lamps/Trouble Diagnoses	101	Rear Wiper and Washer/System Description	147
Combination Flasher Unit Check	101	Rear Wiper and Washer/Wiring Diagram	
Bulb Specifications	102	— WIP/R —	149
INTERIOR LAMP	103	Rear Wiper Amplifier Check	151
Illumination/System Description	103	Rear Wiper Installation and Adjustment	151
Illumination/Schematic	104	Rear Washer Nozzle Adjustment	151
Illumination/Wiring Diagram — ILL —	105	Rear Washer Tube Layout	152
Interior, Spot and Trunk Room Lamps/System Description	110	Check Valve (For rear washer)	152
Bulb Specifications	110	Headlamp Washer/System Description	153
Interior, Spot and Trunk Room Lamps/Wiring Diagram — INT/L —	111	Headlamp Washer/Wiring Diagram — HLC —	154
METER AND GAUGES	113	Headlamp Washer Amplifier Check	156
System Description	113	Headlamp Washer Nozzle Adjustment	156
Combination Meter	114	Headlamp Washer Tube Layout	156
Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram — METER —	115	Check Valve (For headlamp washer)	156
Inspection/Fuel Gauge and Water Temperature Gauge	116	POWER WINDOW	157
Inspection/Tachometer	117	System Description	157
Inspection/Speedometer and Vehicle Speed Sensor	118	Schematic	159
Thermal Transmitter Check	120	Wiring Diagram — WINDOW —	160
Vehicle Speed Sensor Signal Check	120	Trouble Diagnosis	163
Fuel Tank Gauge Unit Check	120	POWER DOOR LOCK	169
Lead Switch	121	System Description	169
WARNING LAMPS AND BUZZER	122	Wiring Diagram — D/LOCK —	171
Warning Lamps/Schematic	122	Trouble Diagnoses	173
Warning Lamps/Wiring Diagram — WARN —	123	POWER DOOR MIRROR	175
Fuel Warning Lamp Sensor Check	129	Wiring Diagram — MIRROR —	175
Oil Pressure Switch Check	129	ELECTRIC SUN ROOF	179
Diode Check	129	Wiring Diagram — SROOF —	179
Warning Buzzer/System Description	130	HORN, CIGARETTE LIGHTER AND CLOCK	181
Warning Buzzer/Wiring Diagram — CHIME —	131	Wiring Diagram — HORN —	181
Trouble Diagnoses — Warning Buzzer	133	REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER	185
Warning Buzzer Check	137	System Description	185
WIPER AND WASHER	138	Wiring Diagram — DEF —	186
Front Wiper and Washer/System Description	138	Trouble Diagnoses	188
		Filament Check	189
		AUDIO AND POWER ANTENNA	190
		Audio/System Description	190
		Audio/Wiring Diagram — AUDIO —	191
		Audio	195
		Radio Fuse Check	195
		Power Antenna/Wiring Diagram — P/ANT —	196
		Location of Antenna	197

CONTENTS (Cont'd.)

Antenna Rod Replacement.....	197	Trouble Diagnoses	230
Window Antenna Repair	198	LOCATION OF ELECTRICAL UNIT	249
HEATED SEAT	200	Engine Compartment.....	249
Wiring Diagram — H/SEAT —	200	Passenger Compartment.....	250
MULTI-REMOTE CONTROL SYSTEM	202	Trunk Compartment	252
System Description.....	202	HARNES LAYOUT	253
Component Parts and Harness Connector		Outline	253
Location.....	204	Main Harness.....	254
Schematic.....	205	Engine Room Harness.....	258
Wiring Diagram — MULTI —	206	Engine Control Harness.....	264
Input/Output Operation Signal.....	210	Engine Harness.....	268
Trouble Diagnoses.....	211	Body Harness	270
Replacing Remote Controller or Control Unit ..	217	Tail Harness.....	274
THEFT WARNING SYSTEM	218	Room Lamp Harness	276
System Description	218	Air Bag and Seat Belt Pre-tensioner Harness.....	277
Component Parts and Harness Connector		Door Harness (LHD models)	278
Location.....	221	Door Harness (RHD models)	279
Schematic	222	SUPER MULTIPLE JUNCTION (SMJ)	Foldout page
Wiring Diagram — THEFT —	223	Disconnecting and Connecting	Foldout page
Input/Output Operation Signal.....	229	Terminal Arrangement	Foldout page

WIRING DIAGRAM REFERENCE CHART

ECCS	EC SECTION
A/T CONTROL	AT SECTION
ANTI-LOCK BRAKING SYSTEM	BR SECTION
DIFFERENTIAL OIL COOLER	PD SECTION
AIR BAG AND SEAT BELT PRE-TENSIONER	PS SECTION
HEATER AND AIR CONDITIONER	HA SECTION

PRECAUTIONS



Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System "Air Bag" and "Seat Belt Pre-tensioner", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnostic sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS** section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS SYSTEM.

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

(Example)




EL

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays



SEL081H

TYPE OF STANDARDIZED RELAYS
















1M 1 Make 2M 2 Make
 1T 1 Transfer 1M-1B 1 Make 1 Break



SEL082H

STANDARDIZED RELAY


Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE or GREEN
2M				BROWN
1M-1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

POWER SUPPLY ROUTING


Schematic



- (L) LHD models
- (R) RHD models
- (A) A/T models
- (EU) For Europe
- (EE) Except for Europe
- (EL) LHD models without daytime light system
- (NE) Except (EL)
- *1 (L) 27, (R) 29
- *2 (L) 16, (R) 14
- *3 (L) 29, (R) 28
- *4 (L) 10A, (R) 15A

POWER SUPPLY UNIT


Schematic (Cont'd)





POWER SUPPLY ROUTING

Wiring Diagram — POWER —

EL-POWER-01




- (L) : LHD models
- (R) : RHD models
- (EU) : For Europe
- (EE) : Except for Europe
- (EL) : LHD models without daytime light system
- (NF) : Except (EL)
- *1... (L) W/R . (R) W/L



FRONT ←



FRONT ←




POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



FRONT ←



(M7)
LHD UP
RHD UP

Refer to last page (Foldout page).




(M10), (E10)

EL

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-03






FRONT ←

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-04



Refer to last page (Foldout page).




(M10), (E101)

EL

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05





Refer to last page (Foldout page).

M10 , E101

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-06





GI
WA
EM
LC
EC
FE
CL
WT
AT
PD
EA
HA
BR
ST
KS
BT
RA
EL
DX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-07





SEL674T

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-08

- ◊ : LHD models
- ◊ : RHD models
- ◊ : For Europe
- *10... ◊ 29 . ◊ 2B
- *11... ◊ A/L . ◊ L





EL


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-09




POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.




Circuit breakers are used in the following systems.

- Power window
- Power door lock
- Power sun roof
- Multi-remote control
- Theft warning
- Warning buzzer
- Rear window defogger and mirror defogger

BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are lightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.



How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level.
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)

- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL



WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

BATTERY

How to Handle Battery (Cont'd)


- Remove the cell plug using a suitable tool
- Add distilled water up to the MAX level.



SULPHATION


A battery will be completely discharged if it is left unattended for a long time and the specific gravity becomes less than 1.100. This may result in sulphation on the cell plates.

To find if a discharged battery has been sulphated, pay attention to its voltage and current when charging it. As shown in the figure at left, if the battery has been "sulphated", less current and higher voltage may be observed in the initial stage of charging.



SPECIFIC GRAVITY CHECK

- 1 Read hydrometer and thermometer indications at eye level



- When electrolyte level is too low, tilt battery case to raise it for easy measurement

BT

MA

EA

LC

EC

TE

CI

WT

AT

PD

TE

MA

EC

CI

EC

BT

MA

EL

TC


BATTERY

How to Handle Battery (Cont'd)

2. Convert into specific gravity at 20°C (68°F).

Example:

- When electrolyte temperature is 35°C (95°F) and specific gravity of electrolyte is 1.230, converted specific gravity at 20°C (68°F) is 1.240.
- When electrolyte temperature is 0°C (32°F) and specific gravity of electrolyte is 1.210, converted specific gravity at 20°C (68°F) is 1.196.



SEL007Z


BATTERY

Battery Test and Charging Chart

Chart I

VISUAL INSPECTION

- Check battery case for cracks or bends
- Check battery terminals for damage
- If the difference between the max. and min. electrolyte level in cells is within 10 mm (0.39 in.), it is OK



* "STANDARD CHARGE" is recommended if the vehicle is in storage after charging.

EL



BATTERY

Battery Test and Charging Chart (Cont'd)

Chart II

- Check battery type and determine the specified current using the following table
- Fig 1 DISCHARGING CURRENT
(Load Tester)

Type	Current (A)
28B19R(L)	90
34B19R(L)	99
46B24R(L)	135
55B24R(L)	135
50D23R(L)	150
55D23R(L)	180
65D26R(L)	195
80D26R(L)	195
75D31R(L)	210
95D31R(L)	240
115D31R(L)	240
95E41R(L)	300
130E41R(L)	330



SEL0082

BATTERY

Battery Test and Charging Chart (Cont'd)

A. SLOW CHARGE

Determine initial charging current from specific gravity referring to Fig. 2.

- Charge battery
- Check charging voltage 30 minutes after starting the battery charge

12 to 15 volts Below 12 volts or above 15 volts

OK

NG

Continue to charge for 12 hours.

Replace battery.

CHECKING SPECIFIC GRAVITY
Refer to "Specific Gravity Check".

Conduct additional charge as per Fig. 3, if necessary


Go to "CAPACITY TEST".

Fig. 2 INITIAL CHARGING CURRENT SETTING (Slow charge)

CON- VERTED SPECIFIC GRAVITY	BATTERY TYPE												
	28B19R(L)	34B19R(L)	46B24R(L)	55B24R(L)	50D23R(L)	55D23R(L)	65D28R(L)	80D28R(L)	75D31R(L)	95D31R(L)	115D31R(L)	95E41R(L)	130E41R(L)
Below 1.100	4.0 (A)	5.0 (A)	5.0 (A)	7.0 (A)	8.0 (A)	9.0 (A)	10.0 (A)	14.0 (A)					

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary.

Fig. 3 ADDITIONAL CHARGE (Slow charge)



CAUTION:

- Set charging current to value specified in Fig. 2. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY



Battery Test and Charging Chart (Cont'd)

Fig 4 INITIAL CHARGING CURRENT SETTING
(Standard charge)

CON- VERTED SPECIFIC GRAVITY	BATTERY TYPE												
	28B19R(L)	34B19R(L)	48B24R(L)	55B24R(L)	50D23R(L)	55D23R(L)	65D26R(L)	80D26R(L)	75D31R(L)	95D31R(L)	115D31R(L)	98E41R(L)	130E41R(L)
1.100 - 1.130	4.0 (A)	5.0 (A)	6.0 (A)	7.0 (A)	8.0 (A)	9.0 (A)	13.0 (A)						
1.130 - 1.160	3.0 (A)	4.0 (A)	5.0 (A)	6.0 (A)	7.0 (A)	8.0 (A)	11.0 (A)						
1.160 - 1.190	2.0 (A)	3.0 (A)	4.0 (A)	5.0 (A)	6.0 (A)	7.0 (A)	9.0 (A)						
1.190 - 1.220	2.0 (A)	2.0 (A)	3.0 (A)	4.0 (A)	5.0 (A)	5.0 (A)	7.0 (A)						

- Check battery type and determine the specified current using the table shown above
- After starting charging, adjustment of charging current is not necessary

Fig 5 ADDITIONAL CHARGE (Standard charge)



CAUTION:

- Do not use standard charge method on a battery whose specific gravity is less than 1.100.
- Set charging current to value specified in Fig. 4. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

Battery Test and Charging Chart (Cont'd)

C QUICK CHARGE

Determine initial charging current setting and charging time from specific gravity referring to Fig. 6.

Charge battery.

Go to CAPACITY TEST

Fig. 6 INITIAL CHARGING CURRENT SETTING AND CHARGING TIME (Quick charge)

BATTERY TYPE		29B19R(L)	34B19R(L)	46B24R(L)	55B24R(L)	50D23R(L)	55D23R(L)	65D26R(L)	80D26R(L)	75D31R(L)	95D31R(L)	115D31R(L)	95E41R(L)	130E41R(L)
		10 (A)	15 (A)	20 (A)	30 (A)	40 (A)								
CONVERTED SPECIFIC GRAVITY	1 100 - 1 130	2.5 hours												
	1 130 - 1 160	2.0 hours												
	1 160 - 1 190	1.5 hours												
	1 190 - 1 220	1.0 hours												
	Above 1 220	0.75 hours (45 min)												

- Check battery type and determine the specified current using the table shown above.
- After starting charging, adjustment of charging current is not necessary

CAUTION:

- Do not use quick charge method on a battery whose specific gravity is less than 1.100.
- Set initial charging current to value specified in Fig. 6. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- Be careful of a rise in battery temperature because a large current flow is required during quick-charge operation.
If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).
- Do not exceed the charging time specified in Fig. 6, because charging battery over the charging time can cause deterioration of the battery.

Service Data and Specifications (SDS)

Applied model	For Europe	Except for Europe	Optional on LHD models for Europe
Type	55D23R	65D26R	80D26R
Capacity	12 - 60	12 - 65	12 - 65

STARTING SYSTEM

System Description

M/T MODELS

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter [h] , located in the fusible link and fuse box).

For models with theft warning system

Power is supplied at all times

- through 7 5A fuse (No 26 , located in the fuse block)
- to theft warning relay terminal ①.

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- to theft warning relay terminal ③.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the starter motor is interrupted.

When the theft warning system is not operating, power is supplied

- through theft warning relay terminal ④
- to terminal ② of the starter motor windings.

For models without theft warning system

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- directly to terminal ② of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

A/T MODELS

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter [h] , located in the fusible link and fuse box).

For models with theft warning system

Power is supplied at all times

- through 7 5A fuse (No 26 , located in the fuse block)
- to theft warning relay terminal ①.

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- to theft warning relay terminal ③.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the inhibitor switch is interrupted.

When the theft warning system is not operating, power is supplied

- through theft warning relay terminal ④
- to inhibitor switch terminal ②
- through inhibitor switch terminal ①, with the selector lever in the P or N position
- to terminal ② of the starter motor windings.

For models without theft warning system

With the ignition switch in the START position, power is supplied


- from ignition switch terminal ⑤
- to inhibitor switch terminal ②
- through inhibitor switch terminal ①, with the selector lever in the P or N position
- to terminal ② of the starter motor windings

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.




STARTING SYSTEM

Wiring Diagram — START —

M/T MODELS



- ◁ L : LHD models
- ◁ R : RHD models
- ◁ TM : Models with theft warning system
- ◁ ET : Models without theft warning system
- *1... ◁ TM B/R, ◁ ET B/Y



Refer to last page (Foldout page).

M10, E101


M1B

GE
MA
EM
LC
EG
EE
CL
MT
AT
ED
EA
RA
BR
BT
NS
BT
NA
EL
DX




STARTING SYSTEM

Wiring Diagram — START — (Cont'd)

A/T MODELS




- Ⓛ : LHD models
- Ⓡ : RHD models
- Ⓣ : Models with theft warning system
- ⓔ : Models without theft warning system
- *2... Ⓣ B/R, ⓔ B/Y



STARTING SYSTEM


Trouble-shooting

If any abnormality is found, immediately disconnect battery negative terminal.



STARTING SYSTEM

Construction



- | | | |
|-------------------|----------------------------|-------------------------|
| ① Gear case | ⑧ Adjusting plate | ⑮ Internal gear |
| ② Bearing cover | ⑨ Magnetic switch assembly | ⑯ Center bracket |
| ③ Ball bearing | ⑩ E-ring | ⑰ Yoke assembly |
| ④ Pinion assembly | ⑪ Thrust washer | ⑱ Armature |
| ⑤ Shift lever | ⑫ Center bracket | ⑲ Brush holder assembly |
| ⑥ Dust cover | ⑬ Pinion shaft | ⑳ Rear cover |
| ⑦ Torsion spring | ⑭ Planetary gear | ㉑ Dust cover |

Removal and Installation


REMOVAL

1. Remove battery negative cable from battery.
2. Remove transmission harness bracket
3. Remove battery cable from starter motor.
4. Disconnect harness connector from starter motor harness
5. Remove starter motor from under vehicle.

INSTALLATION

Installation procedure is basically the reverse order of removal.

STARTING SYSTEM





Magnetic Switch Check

- Before starting to check, disconnect battery ground cable.
- Disconnect "M" terminal of starter motor.
- 1. Continuity test (between "S" terminal and switch body).
- No continuity ... Replace.
- 2. Continuity test (between "S" terminal and "M" terminal).
- No continuity ... Replace.

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident ... Replace.



Brush Check

BRUSH

Check wear of brush.

Wear limit length:

Refer to SDS. (EL-37)

- Excessive wear .. Replace.

STARTING SYSTEM

Brush Check (Cont'd)


BRUSH SPRING PRESSURE

Check brush spring pressure with brush spring detached from brush.

Spring pressure (with new brush):


Refer to SDS. (EL-37)

- Not within the specified values ... Replace.



BRUSH HOLDER

1. Perform insulation test between brush holder (positive side) and its base (negative side).
- Continuity exists. ... Replace.
2. Check brush to see if it moves smoothly.
- If brush holder is bent, replace it; if sliding surface is dirty, clean.




Yoke Check

Magnet is secured to yoke by bonding agent. Check magnet to see that it is secured to yoke and for any cracks. Replace malfunctioning parts as an assembly.


Holder may move slightly as it is only inserted and not bonded.

CAUTION:

Do not clamp yoke in a vice or strike it with a hammer.



STARTING SYSTEM




Armature Check

1. Continuity test (between two segments side by side).
 - No continuity ... Replace.
2. Insulation test (between each commutator bar and shaft).
 - Continuity exists. ... Replace.

GI

MA

EM




3. Check commutator surface.
 - Rough ... Sand lightly with No. 500 - 600 emery paper.

LC

EC

FE

GL




4. Check diameter of commutator.
Commutator minimum diameter:
Refer to SDS. (EL-37)
 - Less than specified value ... Replace.

MY

AT

PD

FA



5. Check depth of insulating mold from commutator surface.
 - Less than 0.2 mm (0.008 in) ... Undercut to 0.5 to 0.8 mm (0.020 to 0.031 in)

RA

BR

ST

RS

BY

HA


EL

IDX

STARTING SYSTEM

Assembly

Apply high-temperature grease to lubricate the bearing, gears and frictional surface when assembling the starter. Carefully observe the following instructions.




PINION PROTRUSION LENGTH ADJUSTMENT

With pinion driven out by magnetic switch, push pinion back to remove slack and measure clearance "l" between the front edge of the pinion and the pinion stopper.

Clearance "l":

Refer to SDS. (EL-37)

- Not in the specified value ... Adjust by adjusting plate.



STARTING SYSTEM

Service Data and Specifications (SDS) STARTER

Type	S114-705B		
	S114-705C		
	HITACHI make		
System voltage		Reduction gear	
V		12	
No-load	Terminal voltage	V	11.0
	Current	A	Less than 90
	Revolution	rpm	More than 2,950
Minimum length of brush		mm (in)	11.0 (0.433)
Brush spring tension (With new brush)		N (kg, lb)	17.6 - 21.6 (1.80 - 2.20, 3.96 - 4.86)
Minimum diameter of commutator		mm (in)	32.0 (1.260)
Clearance between pinion front edge and pinion stopper		mm (in)	0.3 - 1.5 (0.012 - 0.059)
Clearance between bearing metal and armature shaft		mm (in)	Less than 0.2 (0.008)

CHARGING SYSTEM

System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal (S) through

- 100A fusible link (letter (A), located in the fusible link and fuse box), and
- 7.5A fuse (No. (41), located in the fusible link and fuse box).

Terminal (B) supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal (S) detecting the input voltage. The charging circuit is protected by the 100A fusible link.

Terminal (E) of the alternator supplies ground through body ground (E204).

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. (25), located in the fuse block)
- to combination meter terminal (21) for the charge warning lamp.


Ground is supplied to terminal (15) of the combination meter through terminal (L) of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.


CHARGING SYSTEM

Wiring Diagram — CHARGE —

EL-CHARGE-01



Ⓛ : LHD models
 Ⓡ : RHD models
 *1... Ⓛ H4, Ⓡ C6



Refer to last page
 (Foldout page).
 M10, E101


CHARGING SYSTEM

Trouble-shooting

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

Before starting trouble-shooting, inspect the fusible link.


WITH IC REGULATOR



- 1) Use fully charged battery.
- 2) Light : Charge warning light
ACG : Alternator parts except IC regulator
IC-RG : IC regulator
OK : IC-alternator is in good condition.
- 3) When reaching "Damaged ACG", remove alternator from vehicle and disassembly, inspect and correct or replace faulty parts.
- 4) *Method of grounding F terminal (HITACHI make only)

Gasoline engine model

Contact tip of wire with brush and attach wire to alternator body.




SEL0202

- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of alternator.

CHARGING SYSTEM

Construction

SEC. 231
A2T82191



SEL666T


Removal and Installation

REMOVAL


1. Remove engine undercover.
2. Remove stabilizer bracket
3. Remove power steering tube mounting bracket
4. Remove drive bell from alternator.
5. Disconnect harness connector.
6. Remove cooling fan lower shroud
7. Remove alternator

INSTALLATION

To install, reverse the removal procedure.



SEL345T



SEL346T


Disassembly

REAR COVER REMOVAL

CAUTION:

Rear cover may be hard to remove because a ring is used to lock outer race of rear bearing. To facilitate removal of rear cover, heat just bearing box section with a 200W soldering iron.

Do not use a heat gun, as it can damage diode assembly.



REAR BEARING

CAUTION:

- Do not reuse rear bearing after removal. Replace with a new one.
- Do not lubricate rear bearing outer race.

Rotor Check

1. Resistance test

Resistance: Refer to SDS. (EL-45)

- Not within the specified values ... Replace rotor.

2. Insulator test


- Continuity exists ... Replace rotor.

3. Check slip ring for wear.

Slip ring minimum outer diameter:

Refer to SDS. (EL-45)

- Not within the specified values ... Replace rotor.




Brush Check

1. Check smooth movement of brush.

- Not smooth ... Check brush holder and clean.

2. Check brush for wear.

- Replace brush if it is worn down to the limit line.




CHARGING SYSTEM


Stator Check

1. Continuity test
 - No continuity ... Replace stator.
2. Ground test
 - Continuity exists ... Replace stator

Type 1



Type 2



SEL037Z

GF

WH

FW

LC

EC

FE

CL

VT

AT

FD

FR

RL

BF

ST

FS

RT

LA

EL

DM

CHARGING SYSTEM


Diode Check

MAIN DIODES


- Use an ohmmeter to check condition of diodes as indicated in chart below
- If any of the test results is not satisfactory, replace diode assembly.

	Ohmmeter probes		Judgement
	Positive ⊕	Negative ⊖	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Positive diode plate	
Diodes check (Negative side)	Negative diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Negative diode plate	


Type 1




Type 4




Type 2




Type 5



Type 3




Type 6



SEL639Z

CHARGING SYSTEM




Assembly

RING FITTING IN REAR BEARING

- Fix ring into groove in rear bearing so that it is as close to the adjacent area as possible.


CAUTION:

Do not reuse rear bearing after removal.



REAR COVER INSTALLATION

- (1) Fit brush assembly, diode assembly, regulator assembly and stator.
- (2) Push brushes up with fingers and install them to rotor. Take care not to damage slip ring sliding surface.



Service Data and Specifications (SDS)



ALTERNATOR

Type	A21B2191	
	MITSUBISHI make	
Nominal rating	V-A	12-90
Ground polarity		Negative
Minimum revolution under no-load (when 13.5 volts is applied)	rpm	Less than 1,300
Hot output current	A/rpm	More than 22/1,300 More than 67/2,500 More than 90/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	More than 5 (0.20)
Slip ring minimum outer diameter	mm (in)	More than 22.1 (0.870)
Rotor (field coil) resistance	Ω	2.5

COMBINATION SWITCH

Check

FOR EUROPE



LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5	○	○	○	○	○	○	○	○	○
6	○	○	○	○	○	○	○	○	○
7									
8	○	○	○	○	○	○	○	○	○
9	○	○	○	○	○	○	○	○	○
10									
11	○	○	○	○	○	○	○	○	○
12	○	○	○	○	○	○	○	○	○
25									

FRONT WIPER AND WASHER SWITCH

	OFF	INT	LO	HI	WASH
13	○	○	○		
14	○	○	○		
15	○	○	○		
16					
17	○	○	○		
18					
19					

REAR WIPER AND WASHER SWITCH

	WASH	OFF	INT	ON	WASH
21			○		
22				○	
23	○				○
24	○				○

TURN SIGNAL SWITCH

	R	N	L
1	○	○	
2	○	○	
3	○	○	

INTERMITTENT WIPER VOLUME



HORN SWITCH
(Models without air bag system)





SEL671T

COMBINATION SWITCH

Check (Cont'd)

EXCEPT FOR EUROPE



LIGHTING SWITCH

	OFF	1ST	2ND
A	0	0	0
B	0	0	0
C	0	0	0
D	0	0	0
E	0	0	0
F	0	0	0
G	0	0	0
H	0	0	0
I	0	0	0
J	0	0	0
K	0	0	0
L	0	0	0

TURN SIGNAL SWITCH

	R	N	L
1	0	0	0
2	0	0	0

FRONT WIPER AND WASHER SWITCH



	OFF	INT	LO	HI	WASH
13	0	0			
14	0	0			
15	0	0			
16	0	0			
17	0	0			
18	0	0			

REAR WIPER AND WASHER SWITCH

	WASH	OFF	INT	ON	WASH
21			0		
22			0		
23	0		0		0
24	0		0		0



FRONT FOG LAMP SWITCH

	OFF	ON
31	0	0
32	0	0



EL
WA
EM
LC
EC
FE
CL
MT
AT
FD
FA
RA
RR
ST
RS
BT
HA
EL
DA

COMBINATION SWITCH




Replacement

- Each switch can be replaced without removing combination switch base
- To remove combination switch base, remove base attaching screw.

HEADLAMP

Bulb Replacement



The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- Grasp only the plastic base when handling the bulb. Never touch the glass envelope.

1. Disconnect the battery cable.
2. Disconnect harness connector from rear end of bulb (Outer).
3. Turn bulb cover counterclockwise, then remove it.
4. Pull off rubber cap.
5. Push and turn retaining pin to loosen it.
6. Remove headlamp bulb. Do not shake or rotate bulb when removing it.
7. Disconnect harness connector (Inner).
8. Install in the reverse order of removal.

CAUTION:

- Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

Bulb Specifications

Item	Wattage (W)
Outer (High/Low) (H4 type)	60/55
Inner (Low) (H3 type)	55

System Description

The headlamps are controlled by the lighting switch which is built into the combination switch

MODELS FOR EUROPE

Power is supplied at all times

- to lighting switch terminal ⑤
- through 20A fuse (No. ③⑦), located in the fusible link and fuse box), and
- to lighting switch terminal ⑧
- through 20A fuse (No. ③⑧), located in the fusible link and fuse box).

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to terminal ③ of the LH headlamp, and
- from lighting switch terminal ⑦
- to terminal ③ of the RH headlamp.

Terminal ② of each headlamp supplies ground through body ground (E43) or (E57).

With power and ground supplied, the low beam headlamps will illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to terminals ① (Outer) and ④ (Inner) of RH headlamp, and
- from lighting switch terminal ⑨
- to terminals ① (Outer) and ④ (Inner) of LH headlamp, and
- to combination meter terminal ④⑦ for the high beam indicator.

Ground is supplied to terminal ④⑥ of the combination meter through body ground (M1).

Terminals ② (Outer) and ⑤ (Inner) of headlamp supply ground through body ground (E43) or (E57).

With power and ground supplied, the high beams and the high beam indicator will illuminate.

MODELS EXCEPT FOR EUROPE

Power is supplied at all times

- to lighting switch terminal ⑤
- through 20A fuse (No. ③⑧), located in the fusible link and fuse box), and
- to lighting switch terminal ⑧
- through 20A fuse (No. ③⑦), located in the fusible link and fuse box).

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑦
- to terminal ③ of the LH headlamp, and
- from lighting switch terminal ⑩
- to terminal ③ of the RH headlamp.

Terminal ② of each headlamp supplies ground through body ground (E43) or (E57).

With power and ground supplied, the low beam headlamps will illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑨
- to terminals ① (Outer) and ④ (Inner) of each RH headlamp, and
- from lighting switch terminal ⑥
- to terminals ① (Outer) and ④ (Inner) of each LH headlamp, and
- to combination meter terminal ④⑦ for the high beam indicator.


Ground is supplied to terminal ④⑥ of the combination meter through body ground (M1).

Terminals ② (Outer) and ⑤ (Inner) of each headlamp supply ground through body ground (E43) or (E57).

With power and ground supplied, the high beams and the high beam indicator will illuminate

HEADLAMP — Without Daytime Light System —

Schematic



SEL679T



10
 11
 12
 13
 14
 15
 16
 17
 18
 19
 20
 21
 22
 23
 24
 25
 26
 27
 28
 29
 30
 31
 32
 33
 34
 35
 36
 37
 38
 39
 40
 41
 42
 43
 44
 45
 46
 47
 48
 49
 50
 51
 52
 53
 54
 55
 56
 57
 58
 59
 60
 61
 62
 63
 64
 65
 66
 67
 68
 69
 70
 71
 72
 73
 74
 75
 76
 77
 78
 79
 80
 81
 82
 83
 84
 85
 86
 87
 88
 89
 90
 91
 92
 93
 94
 95
 96
 97
 98
 99
 100

EL

HEADLAMP — Without Daytime Light System —

Wiring Diagram — H/LAMP —



EL-H/LAMP-01



HEADLAMP — Without Daytime Light System —

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-02






EL

HEADLAMP — Without Daytime Light System —

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-03



Refer to last page (Foldout page).

(M10), (E101)

HEADLAMP — Without Daytime Light System —

Trouble Diagnoses

Symptom	Possible cause	Repair order
LH headlamps do not operate	1 Bulb 2 Ground (E43) or (E57) 3 20A fuse 4 Lighting switch	1 Check bulb. 2 Check ground (E43) or (E57) 3 Check 20A fuse (No 38) . located in fusible link and fuse box). Verify battery positive voltage is present at terminal *1 of lighting switch. 4 Check lighting switch
RH headlamps do not operate	1 Bulb 2 Ground (E43) or (E57) 3 20A fuse 4 Lighting switch	1 Check bulb 2 Check ground (E43) or (E57) 3 Check 20A fuse (No 37) . located in fusible link and fuse box). Verify battery positive voltage is present at terminal *2 of lighting switch 4 Check lighting switch
LH high beams do not operate, but LH low beam operates	1 Bulbs 2 Open in LH high beams circuit 3. Lighting switch	1 Check bulbs 2 Check R/B wire between lighting switch and LH headlamps for an open circuit 3 Check lighting switch
LH low beam does not operate, but LH high beam operates.	1 Bulb 2 Open in LH low beam circuit 3. Lighting switch	1 Check bulb 2 Check R/Y wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beams do not operate, but RH low beam operates.	1 Bulbs 2 Open in RH high beams circuit 3. Lighting switch	1 Check bulbs. 2 Check R/G wire between lighting switch and RH headlamps for an open circuit 3. Check lighting switch
RH low beam does not operate, but RH high beam operates.	1 Bulb 2 Open in RH low beam circuit 3 Lighting switch	1 Check bulb. 2 Check R/L wire between lighting switch and RH headlamp for an open circuit 3 Check lighting switch.
High beam indicator does not work.	1. Bulb 2. Ground (M1) 3 Open in high beam circuit	1. Check bulb in combination meter 2. Check ground (M1) 3 Check R/B wire between lighting switch and combination meter for an open circuit

*1 (8) Models for Europe
 (5) Models except for Europe

*2 (5) Models for Europe
 (8) Models except for Europe

System Description

The headlamp system on vehicles for Norway and Sweden contains a daytime light unit. The unit activates the following whenever the engine is running with the lighting switch in the OFF position:

- Low beam headlamps
- Clearance, license, tail and illumination lamps

Power is supplied at all times

- through 20A fuse (No. 37), located in the fusible link and fuse box
- to daytime light unit terminal ③ and
- to lighting switch terminal ⑤.

Power is also supplied at all times

- through 20A fuse (No. 38), located in the fusible link and fuse box
- to daytime light unit terminal ② and
- to lighting switch terminal ⑥.

Power is also supplied at all times

- through 10A fuse (No. 2), located in the fuse block)
- to daytime light unit terminal ① and
- to lighting switch terminal ⑦.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 26), located in the fuse block)
- to daytime light unit terminal ⑦.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse (No. 2), located in the fuse block)
- to daytime light unit terminal ⑥.

Ground is supplied to daytime light unit terminal ⑨ through body ground (E43).

HEADLAMP OPERATION

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑦ or
- from daytime light unit terminal ④
- to RH headlamp terminal ③.

Ground is supplied to RH headlamp terminal ② through body ground (E43).

Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩ or
- from daytime light unit terminal ⑤.
- to LH headlamp terminal ③.

Ground is supplied to LH headlamp terminal ② through body ground (E37).

With power and ground supplied, the low beam headlamps illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to terminals ① (Outer) and ④ (Inner) of RH headlamp, and
- from lighting switch terminal ⑨
- to terminals ① (Outer) and ④ (Inner) of LH headlamp, and
- to combination meter terminal ⑪ for the high beam indicator.

Ground is supplied to terminal ⑫ of the combination meter through body ground (M1).

Terminals ② (Outer) and ⑤ (Inner) of headlamp supply ground through body ground (E43) or (E37)

With power and ground supplied, the high beams and the high beam indicator will illuminate.

HEADLAMP — Daytime Light System —

System Description (Cont'd)

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position, power is supplied

- to daytime light unit terminal ②
- through daytime light unit terminal ⑤
- to terminal ③ of LH headlamp
- to daytime light unit terminal ③
- through daytime light unit terminal ④
- to terminal ③ of RH headlamp

Ground is supplied to terminal ② of each headlamp through body ground (E45) or (E57)

Ground is also supplied to terminal ⑨ of daytime light unit through body ground (E43).

Operation (Daytime light system)

The headlamps' low beam and clearance, license, tail and illumination lamps automatically turn on after starting the engine with lighting switch in "OFF" position.

Lighting switch operations other than the above are the same as conventional light systems

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
Lighting switch		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
		Headlamp	High beam	X	X	O	X	X	O	O	X	O	X	X	O	X	X	O	O
Low beam	X		X	X	X	X	X	X	X	O	X	O	O	O	X	X	X	X	O
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O


O: Lamp "ON"

X: Lamp "OFF"

□: Added functions

HEADLAMP — Daytime Light System


Schematic



HEADLAMP — Daytime Light System —

Wiring Diagram — DTRL —

EL-DTRL-01



Refer to last page (Foldout page).

M10 E101



E35



E201

GY






E207

W

EL

HEADLAMP — Daytime Light System —
Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02






HEADLAMP — Daytime Light System —

Wiring Diagram — DTRL — (Cont'd)


EL-DTRL-03

GF
 MA
 EM
 AC
 EC
 FE
 CL
 WT
 ST
 PD
 EA
 RA
 ST
 SS
 RT
 RA
 EL
 IDX



Refer to last page (Foldout page).

M10, E101






















HEADLAMP — Daytime Light System —


Trouble Diagnoses

DAYTIME LIGHT UNIT INSPECTION TABLE

(Data are reference values.)

Terminal No	Item	Condition		Judgement standard
1	Power source (BAT)		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "OFF"	Battery positive voltage
2	Power source (BAT)		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "OFF"	Battery positive voltage
3	Power source (BAT)		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "OFF"	Battery positive voltage
4	RH to beam (Lighting switch)		When turning lighting switch to "HEAD" and 2ND positions	Battery positive voltage
			When turning lighting switch to "OFF" with engine running (daytime light operation)	Battery positive voltage
5	LH to beam (Lighting switch)		When turning lighting switch to "HEAD" and 2ND positions	Battery positive voltage
			When turning lighting switch to "OFF" with engine running (daytime light operation)	Battery positive voltage
6	Start signal		When turning ignition switch to "ST"	Battery positive voltage
			When turning ignition switch to "ON" from "ST"	1V or less
			When turning ignition switch to "OFF"	1V or less
7	Power source (IGN)		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "ST"	Battery positive voltage
			When turning ignition switch to "OFF"	1V or less
8	Alternator		When turning ignition switch to "ON"	More than 5V
			When engine is running	Battery positive voltage
			When turning ignition switch to "OFF"	1V or less

HEADLAMP — Daytime Light System — Trouble Diagnoses (Cont'd)

Ter- minal No	Item	Condition	Judgement standard
9	Ground	—	—
10	Small lamps	When turning lighting switch to 1ST or 2ND position	Battery positive voltage
		 When turning lighting switch to "OFF" with engine running (daytime light operation)	Battery positive voltage
11	Lighting switch	When turning lighting switch to 1ST or 2ND position	Battery positive voltage
		When turning lighting switch to "OFF"	1V or less

GI
 MA
 EM
 LG
 EC
 SE
 EL
 MT
 ET
 PA
 BA
 SA
 ST
 AS
 SI
 BS
 BL
 BR
 BT
 BU
 BV
 BW
 BX
 BY
 BZ
 CA
 CB
 CC
 CD
 CE
 CF
 CG
 CH
 CI
 CJ
 CK
 CL
 CM
 CN
 CO
 CP
 CQ
 CR
 CS
 CT
 CU
 CV
 CW
 CX
 CY
 CZ
 DA
 DB
 DC
 DD
 DE
 DF
 DG
 DH
 DI
 DJ
 DK
 DL
 DM
 DN
 DO
 DP
 DQ
 DR
 DS
 DT
 DU
 DV
 DW
 DX
 DY
 DZ
 EA
 EB
 EC
 ED
 EE
 EF
 EG
 EH
 EI
 EJ
 EK
 EL
 EM
 EN
 EO
 EP
 EQ
 ER
 ES
 ET
 EU
 EV
 EW
 EX
 EY
 EZ
 FA
 FB
 FC
 FD
 FE
 FF
 FG
 FH
 FI
 FJ
 FK
 FL
 FM
 FN
 FO
 FP
 FQ
 FR
 FS
 FT
 FU
 FV
 FW
 FX
 FY
 FZ
 GA
 GB
 GC
 GD
 GE
 GF
 GG
 GH
 GI
 GJ
 GK
 GL
 GM
 GN
 GO
 GP
 GQ
 GR
 GS
 GT
 GU
 GV
 GW
 GX
 GY
 GZ
 HA
 HB
 HC
 HD
 HE
 HF
 HG
 HH
 HI
 HJ
 HK
 HL
 HM
 HN
 HO
 HP
 HQ
 HR
 HS
 HT
 HU
 HV
 HW
 HX
 HY
 HZ
 IA
 IB
 IC
 ID
 IE
 IF
 IG
 IH
 II
 IJ
 IK
 IL
 IM
 IN
 IO
 IP
 IQ
 IR
 IS
 IT
 IU
 IV
 IW
 IX
 IY
 IZ
 JA
 JB
 JC
 JD
 JE
 JF
 JG
 JH
 JI
 JJ
 JK
 JL
 JM
 JN
 JO
 JP
 JQ
 JR
 JS
 JT
 JU
 JV
 JW
 JX
 JY
 JZ
 KA
 KB
 KC
 KD
 KE
 KF
 KG
 KH
 KI
 KJ
 KK
 KL
 KM
 KN
 KO
 KP
 KQ
 KR
 KS
 KT
 KU
 KV
 KW
 KX
 KY
 KZ
 LA
 LB
 LC
 LD
 LE
 LF
 LG
 LH
 LI
 LJ
 LK
 LL
 LM
 LN
 LO
 LP
 LQ
 LR
 LS
 LT
 LU
 LV
 LW
 LX
 LY
 LZ
 MA
 MB
 MC
 MD
 ME
 MF
 MG
 MH
 MI
 MJ
 MK
 ML
 MM
 MN
 MO
 MP
 MQ
 MR
 MS
 MT
 MU
 MV
 MW
 MX
 MY
 MZ
 NA
 NB
 NC
 ND
 NE
 NF
 NG
 NH
 NI
 NJ
 NK
 NL
 NM
 NN
 NO
 NP
 NQ
 NR
 NS
 NT
 NU
 NV
 NW
 NX
 NY
 NZ
 OA
 OB
 OC
 OD
 OE
 OF
 OG
 OH
 OI
 OJ
 OK
 OL
 OM
 ON
 OO
 OP
 OQ
 OR
 OS
 OT
 OU
 OV
 OW
 OX
 OY
 OZ
 PA
 PB
 PC
 PD
 PE
 PF
 PG
 PH
 PI
 PJ
 PK
 PL
 PM
 PN
 PO
 PP
 PQ
 PR
 PS
 PT
 PU
 PV
 PW
 PX
 PY
 PZ
 QA
 QB
 QC
 QD
 QE
 QF
 QG
 QH
 QI
 QJ
 QK
 QL
 QM
 QN
 QO
 QP
 QQ
 QR
 QS
 QT
 QU
 QV
 QW
 QX
 QY
 QZ
 RA
 RB
 RC
 RD
 RE
 RF
 RG
 RH
 RI
 RJ
 RK
 RL
 RM
 RN
 RO
 RP
 RQ
 RR
 RS
 RT
 RU
 RV
 RW
 RX
 RY
 RZ
 SA
 SB
 SC
 SD
 SE
 SF
 SG
 SH
 SI
 SJ
 SK
 SL
 SM
 SN
 SO
 SP
 SQ
 SR
 SS
 ST
 SU
 SV
 SW
 SX
 SY
 SZ
 TA
 TB
 TC
 TD
 TE
 TF
 TG
 TH
 TI
 TJ
 TK
 TL
 TM
 TN
 TO
 TP
 TQ
 TR
 TS
 TT
 TU
 TV
 TW
 TX
 TY
 TZ
 UA
 UB
 UC
 UD
 UE
 UF
 UG
 UH
 UI
 UJ
 UK
 UL
 UM
 UN
 UO
 UP
 UQ
 UR
 US
 UT
 UV
 UW
 UX
 UY
 UZ
 VA
 VB
 VC
 VD
 VE
 VF
 VG
 VH
 VI
 VJ
 VK
 VL
 VM
 VN
 VO
 VP
 VQ
 VR
 VS
 VT
 VU
 VV
 VW
 VX
 VY
 VZ
 WA
 WB
 WC
 WD
 WE
 WF
 WG
 WH
 WI
 WJ
 WK
 WL
 WM
 WN
 WO
 WP
 WQ
 WR
 WS
 WT
 WU
 WV
 WW
 WX
 WY
 WZ
 XA
 XB
 XC
 XD
 XE
 XF
 XG
 XH
 XI
 XJ
 XK
 XL
 XM
 XN
 XO
 XP
 XQ
 XR
 XS
 XT
 XU
 XV
 XW
 XX
 XY
 XZ
 YA
 YB
 YC
 YD
 YE
 YF
 YG
 YH
 YI
 YJ
 YK
 YL
 YM
 YN
 YO
 YP
 YQ
 YR
 YS
 YT
 YU
 YV
 YW
 YX
 YZ
 ZA
 ZB
 ZC
 ZD
 ZE
 ZF
 ZG
 ZH
 ZI
 ZJ
 ZK
 ZL
 ZM
 ZN
 ZO
 ZP
 ZQ
 ZR
 ZS
 ZT
 ZU
 ZV
 ZW
 ZX
 ZY
 ZZ


EL

EL-63


HEADLAMP — Headlamp Aiming Control —

Description

- The vertical direction of the headlamp beam can be adjusted from inside the vehicle. This prevents the headlamp beam axis from facing upward due to changes in number of occupants and vehicle load conditions



HEADLAMP — Headlamp Aiming Control — Description (Cont'd)



CIRCUIT OPERATION

[Example]

Aiming switch "0"




- When the aiming switch is set to "0", the motor will not start. This is because the power terminals are positioned at the nonconductive section of the sensor's rotary unit

Aiming switch "0" → "1"

- When the aiming switch is moved from "0" to "1", the sensor's conductive section activates the relay. Power is supplied through the relay to the motor. The headlamps will then move in the "DOWN" direction.
- The motor continues to rotate while the rotary unit of the sensor moves from point A to point B.
- The power terminals will then be positioned at the nonconductive section, disconnecting the power to the motor. The motor will then stop.

Aiming switch "1" → "0"

- When the aiming switch is moved from "1" to "0", the sensor's conductive section activates the relay. Power is supplied through the relay to the motor. The motor will rotate to move the headlamps in the "UP" direction.
- When the rotary unit of the sensor moves from point B to point A, the motor will stop.





GE
MA
EM
IC
EC
RE
EL
MT
AT
PD
EA
RA
RS
ST
PS
AT
KA
EL
DX

HEADLAMP — Headlamp Aiming Control —

Wiring Diagram — AIM —

LHD MODELS

EL-AIM-01




Refer to last page (Foldout page).

(M10) (E101)

(M11) (B1)

HEADLAMP — Headlamp Aiming Control — Wiring Diagram — AIM — (Cont'd)

EL-AIM-02



Refer to last page (Foldout page)

(M10), (E101)
(M11), (B1)



EL

HEADLAMP — Headlamp Aiming Control —

Wiring Diagram — AIM — (Cont'd)

RHD MODELS

EL-AIM-03



Refer to last page (Foldout page).



(M10), (E101)

(M11), (B1)

HEADLAMP — Headlamp Aiming Control —

Wiring Diagram — AIM — (Cont'd)

EL-AIM-04



Refer to last page (Foldout page).

- M10 , E101
- M11 , B1


EL

Aiming Adjustment


When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated according to their operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:


For details, refer to the regulations in your own country.



MEL 530B



SEL 7201



SEL 2541

CAUTION:

- Keep all tires inflated to correct pressures.
- Place vehicle and tester on one and same flat surface.
- See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).

CAUTION:

Be sure aiming switch is set to "0" when performing aiming adjustment on vehicles equipped with headlamp aiming control.

LOW BEAM

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment
- First tighten the adjusting screw all the way and then make adjustment by loosening the screw.

- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.

- Figure to the left shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.

- Dotted lines in illustration show center of headlamp.

"H": Horizontal center line of headlamps


"W": Distance between each headlamp center

"L": 5,000 mm (196.85 in)

"C": 65 mm (2.56 in)

Trouble Diagnoses

SYMPTOM: Headlamp aiming does not operate.




A

POWER SUPPLY CIRCUIT CHECK (For aiming switch)
Check if 12 volts exist between terminals ① and ⑥

Voltmeter terminals		Voltage [V]
(+)	(-)	
①	⑥	Approx 12

NG → Check 10A fuse at fuse block. (Refer to "POWER SUPPLY ROUTING")




B

AIMING SWITCH CHECK
Check continuity between terminals at each switch position

Terminal	①	②	③	④	⑤
Switch position 0	○	○	○	○	○
1	○	○	○	○	○
2	○	○	○	○	○
3	○	○	○	○	○


NG → Replace aiming switch.



C

GROUND CIRCUIT CHECK FOR AIMING MOTOR
Check continuity between terminals ⑥ and body ground.
Continuity exists ... OK

NG → Repair harness between aiming motor and body ground



D

POWER SUPPLY CIRCUIT CHECK (For aiming motor unit)
Check if 12 volts exist between terminals ①, ②, ③, ④, ⑤ and ⑥.

Voltmeter terminals	Voltage [V]		Aiming switch position
	(+)	(-)	
①	⑥	Approx 12	"0"
	⑥	0	Except "0"
②	⑥	Approx. 12	"1"
	⑥	0	Except "1"
③	⑥	Approx. 12	"2"
	⑥	0	Except "2"
④	⑥	Approx 12	"3"
	⑥	0	Except "3"
⑤	⑥	Approx 12	--
	⑥	0	--

NG → Check harness between aiming switch and aiming motor unit

OK

Replace aiming motor unit

EXTERIOR LAMP

Clearance, License and Tail Lamps/System Description

LHD MODELS WITH DAYTIME LIGHT SYSTEM

The clearance, license and tail lamps on vehicles for Norway and Sweden contain a daytime light unit. The unit activates the small lamps whenever the engine and lighting switch are under the following conditions.

- Engine running
- Lighting switch in the OFF position

(For daytime light system, refer to "HEADLAMP — Daytime Light System —".)

Operation (when daytime light system is triggered.)

Power is supplied at all times

- through 10A fuse (No. 23, located in the fuse block)
- to daytime light unit terminal ①.

With the engine running and the lighting switch in the OFF position, power is supplied

- through daytime light unit terminal ⑩
- to terminal ① of each lamp.

Ground is supplied to terminal ② of clearance lamps through body ground (E43) or (E57).

Ground is also supplied to terminal ② of license lamp and to terminal ④ of tail lamps through body ground (T19).

With power and ground supplied, the clearance, license and tail lamps illuminate.

Operation (when daytime light system is not triggered.)

Power is supplied at all times

- through 10A fuse (No. 23, located in the fuse block)
- to lighting switch terminal ⑪.

With the lighting switch in the 1ST or 2ND position, power is supplied

- through lighting switch terminal ⑫
- to daytime light unit terminal ⑬
- through daytime light unit terminal ⑩
- to terminal ① of each lamp.

Ground is supplied to terminal ② of clearance lamps through body ground (E43) or (E57)

Ground is also supplied to terminal ② of license lamp and to terminal ④ of tail lamps through body ground (T19).

With power and ground supplied, the clearance, license and tail lamps illuminate.

LHD MODELS WITHOUT DAYTIME LIGHT SYSTEM

Power is supplied at all times

- through 45A fusible link (letter I, located in the fusible link and fuse box)
- to lighting switch terminal ⑬.

Operation

With the lighting switch in the 1ST or 2ND position, power is supplied

- from lighting switch terminal ⑭
- through 10A fuse (No. 14, located in the fuse block)
- to terminal ① of clearance, license and RH tail lamps.

With the lighting switch in the 1ST or 2ND position, power is also supplied

- from lighting switch terminal ⑭
- through 7.5A fuse (No. 15, located in the fuse block)
- to LH tail lamp terminal ①.

Ground is supplied to terminal ② of clearance lamps through body ground (E43) or (E57).

Ground is also supplied to terminal ② of license lamp and to terminal ④ of tail lamps through body ground (T19).

With power and ground supplied, the clearance, license and tail lamps illuminate

EXTERIOR LAMP

Clearance, License and Tail Lamps/System Description (Cont'd)

RHD MODELS FOR EUROPE

Power is supplied at all times

- through 10A fuse (No. 23), located in the fuse block
- to lighting switch terminal 11

Operation

With the lighting switch in the 1ST or 2ND position, power is supplied

- through the lighting switch terminal 12
- to terminal 1 of each lamp.

Ground is supplied to terminal 2 of clearance lamps through body ground (E42) or (E57)

Ground is also supplied to terminal 2 of license lamp and to terminal 4 of tail lamps through body ground (T19)

With power and ground supplied, the clearance, license and tail lamps illuminate.

RHD MODELS EXCEPT FOR EUROPE

Power is supplied at all times

- through 10A fuse (No. 23), located in the fuse block
- to lighting switch terminal 12, and
- to front fog lamp relay terminal 6.

Operation (when front fog lamp system is not triggered.)

With the lighting switch in the 1ST or 2ND position, power is supplied

- through lighting switch terminal 11
- to terminal 1 of each lamp.

Ground is supplied to terminal 2 of clearance lamps through body ground (E42) or (E57).

Ground is also supplied to terminal 2 of license lamp and to terminal 4 of tail lamps through body ground (T19).

Operation (when front fog lamp system is triggered.)

With the front fog lamp switch in the ON position.

- ground is supplied to front fog lamp relay terminal 2 through the front fog lamp switch and body ground (E42).

The front fog lamp relay is energized and power is supplied

- through front fog lamp relay terminal 7
- to terminal 1 of each lamp.

Ground is supplied to terminal 2 of clearance lamps through body ground (E42) or (E57).

Ground is also supplied to terminal 2 of license lamp and to terminal 4 of tail lamps through body ground (T19)

With power and ground supplied, the clearance, license and tail lamps illuminate.

20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100


EL

EXTERIOR LAMP

Clearance, License and Tail Lamps/ Wiring Diagram — TAIL/L —

LHD MODELS WITH DAYTIME LIGHT SYSTEM

EL-TAIL/L-01



E35
GY



E109
W



E12
GY

E37
GY

E54
GY




Refer to last page
(Foldout page).

M10, E101

EXTERIOR LAMP

Clearance, License and Tail Lamps/ Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



Refer to last page
(Foldout page).

(M11), (B1)

G1

MA

EN

LS

EC

RE

AL

WT

AT

PD

EA

RA

BR

ST

EA

WT

WT

WT



EL

WT

EXTERIOR LAMP

Clearance, License and Tail Lamps/ Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-04



Refer to last page
(Foldout page).

(M11), (B1)


GI
MA
EM
LC
EC
EF
CL
VF
AT
FD
= 4
RA
RB
ST
NS
RT
FA
EL
DX

EXTERIOR LAMP

Clearance, License and Tail Lamps/ Wiring Diagram — TAIL/L — (Cont'd)

RHD MODELS

EL-TAIL/L-05




Refer to last page
(Foldout page).

(M10), (E101)

EXTERIOR LAMP

Clearance, License and Tail Lamps/ Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-06



(B24)
W



(T17) (T22)
W, W



(T12) BR

Refer to last page
(Foldout page).

(M11), (B1)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

DX

EXTERIOR LAMP

Stop Lamp/Wiring Diagram — STOP/L —

EL-STOP/L-01



M25



B25



T3



T17, T22



Refer to last page (Foldout page)

(M11), (B1)

EXTERIOR LAMP

Back-up Lamp/Wiring Diagram — BACK/L —

EL-BACK/L-01



Refer to last page
(Foldout page).

(M10), (E10)

(M11), (B1)

EL

EXTERIOR LAMP

Front Fog Lamps/System Description

LHD MODELS WITH DAYTIME LIGHT SYSTEM

Power is supplied at all times

- through 15A fuse (No. [31], located in the fusible link and fuse box)
- to front fog lamp relay terminal (3).

Power is also supplied at all times

- through 10A fuse (No. [23], located in the fuse block)
- to lighting switch terminal (1), and
- to daytime light unit terminal (1).

When the daytime light system is triggered, power is supplied

- through daytime light unit terminal (10)
- to front fog lamp relay terminal (1), or

With the lighting switch in the 1ST or 2ND position, power is supplied

- through lighting switch terminal (12)
- to daytime light unit terminal (1)
- through daytime light unit terminal (10)
- to front fog lamp relay terminal (1).

Front fog lamp operation

If the rear fog lamp system is triggered, terminal (2) of rear fog lamp relay is grounded and power to the front fog lamp switch is interrupted.

When the rear fog lamp system is not operating, ground is supplied

With the front fog lamp switch in the ON position:

- ground is supplied to front fog lamp relay terminal (2)
- from rear fog lamp relay terminal (4)
- to rear fog lamp relay terminal (3)
- through front fog lamp switch and body ground (B2) or (B18).

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal (5)
- to terminal (1) of each front fog lamp.

Ground is supplied to terminal (2) of each fog lamp through body ground (E43) or (E57).

With power and ground supplied, the front fog lamps illuminate.

LHD MODELS WITHOUT DAYTIME LIGHT SYSTEM

Power is supplied at all times

- through 15A fuse (No. [31], located in the fusible link and fuse box)
- to front fog lamp relay terminal (3).

With the lighting switch in the 1ST or 2ND position, power is supplied

- through 45A fusible link (letter [1], located in the fusible link and fuse box)
- to lighting switch terminal (1)
- from lighting switch terminal (12)
- through 10A fuse (No. [14], located in the fuse block)
- to front fog lamp relay terminal (1).

Front fog lamp operation

The lighting switch must be in the 1ST or 2ND position for front fog lamp operation.

With the front fog lamp switch in the ON position:

- ground is supplied to front fog lamp relay terminal (2) through the front fog lamp switch and body ground (B2) or (B18).

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal (5)
- to terminal (1) of each fog lamp.

Ground is supplied to terminal (2) of each fog lamp through body ground (E43) or (E57)

With power and ground supplied, the front fog lamps illuminate.

EXTERIOR LAMP

Front Fog Lamps/System Description (Cont'd)

RHD MODELS FOR EUROPE

Power is supplied at all times

- through 15A fuse (No. 31), located in the fusible link and fuse block)
- to front fog lamp relay terminal ③

With the lighting switch in the 1ST or 2ND position, power is supplied

- through 10A fuse (No. 23), located in the fuse block)
- to lighting switch terminal ①
- through terminal ⑫ of lighting switch
- to front fog lamp relay terminal ②.

Front fog lamp operation

The lighting switch must be in the 1ST or 2ND position for front fog lamp operation.

With the front fog lamp switch in the ON position:

- ground is supplied to front fog lamp relay terminal ① through the front fog lamp switch and body ground (B2) or (B19).

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal ⑤
- to terminal ① of each front fog lamp.

Ground is supplied to terminal ② of each front fog lamp through body ground (E43) or (E57)

With power and ground supplied, the front fog lamps illuminate.

RHD MODELS EXCEPT FOR EUROPE

Power is supplied at all times

- through 15A fuse (No. 31), located in the fusible link and fuse box)
- to front fog lamp relay terminals ① and ③.

Front fog lamp operation

The front fog lamp switch is built into the combination switch.

With the front fog lamp switch in the ON position:

- ground is supplied to front fog lamp relay terminal ② through front fog lamp switch and body ground (E44).

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal ⑤
- to terminal ① of each front fog lamp.

Ground is supplied to terminal ② of each front fog lamp through body ground (E43) or (E57)


With power and ground supplied, the front fog lamps illuminate.

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG —

LHD MODELS WITH DAYTIME LIGHT SYSTEM


EL-F/FOG-01



E109
W



E35
GY



E7
L



E41, E50
GY, GY




Refer to last page (Foldout page).

M10, E101

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG — (Cont'd)

EL-F/FOG-02



Refer to last page
(Foldout page).

(M11), (B1)

EL






1/2X

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG — (Cont'd)

LHD MODELS WITHOUT DAYTIME LIGHT SYSTEM

EL-F/FOG-03



Refer to last page
(Foldout page).

M10, E101


M11, B1

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG — (Cont'd)

RHD MODELS FOR EUROPE

EL-F/FOG-04



Refer to EL-POWER.

Refer to last page
(Foldout page).



E109
W



E7
B



E7
L



E41, E50
GY, GY

M10, E101
M11, B1



EL

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG — (Cont'd)

RHD MODELS EXCEPT FOR EUROPE

EL-F/FOG-05



Refer to last page
(Foldout page).

M10, E101

EXTERIOR LAMP


Front Fog Lamp Aiming Adjustment

Before performing aiming adjustment, make sure of the following.


- a. Keep all tires inflated to correct pressure.
- b. Place vehicle on level ground.
- c. See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools) Have the driver or equivalent weight placed in driver's seat

Adjust aiming in the vertical direction by turning the adjusting screw.

Check the distance between the vehicle and the ground point where the main axis of light of fog lamp reaches. Keep the distance within 40,000 mm (1,574.8 in)



SEL538T



SEL538T

EL

EXTERIOR LAMP

Rear Fog Lamp/System Description

Power is supplied at all times

- through 7.5A fuse (No. 27 for LHD models, No. 29 for RHD models, located in the fuse block)
- to rear fog lamp relay terminal 7 (with daytime light system) or 3 (without daytime light system)

With the lighting switch in the 2ND position, power is supplied

- through 20A fuse (No. 37), located in the fusible link and fuse box)
- to lighting switch terminal 4
- through lighting switch terminal 5
- to rear fog lamp relay terminal 1.

Rear fog lamp operation

The lighting switch must be in the 2ND position for rear fog lamp operation.

Ground is supplied to rear fog lamp relay terminal 2 through body ground M1

With the lighting switch in the 2nd position, the rear fog lamp relay is energized and power is supplied

- through rear fog lamp relay terminal 6 (with daytime light system) or 5 (without daytime light system)
 - to rear fog lamp switch terminal 2
- With the rear fog lamp switch in the ON position, power is supplied
- through rear fog lamp switch terminal 1
 - to terminal 1 of rear fog lamp.

Ground is supplied to terminal 2 of rear fog lamp through body ground T19




With power and ground supplied, the rear fog lamp illuminates.

EXTERIOR LAMP

Rear Fog Lamp/Wiring Diagram — R/FOG —


WITH DAYTIME LIGHT SYSTEM

EL-R/FOG-01



Refer to last page (Foldout page).

(M10), (E101)
(M11), (B1)




EL

EXTERIOR LAMP

Rear Fog Lamp/Wiring Diagram — R/FOG — (Cont'd)

WITHOUT DAYTIME LIGHT SYSTEM

EL-R/FOG-02



(L) : LHD models


(R) : RHD models

#1 ... (L) R, (R) R/W

#2 ... (L) 27, (R) 29

#3 ... (L) S5, (R) S7

#4 ... (L) 13, (R) 3



Refer to last page
(Foldout page).

(M10), (E101)

(M11), (B1)

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. 24) . located in the fuse block
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ②
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①

Ground is supplied to combination flasher unit terminal ① through body ground (M1) or (M67).

LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to

- front turn signal lamp LH terminal ①
- side turn signal lamp LH terminal ①
- rear combination lamp LH terminal ②
- combination meter terminal ⑩

Ground is supplied to the front turn signal lamp LH terminal ② through body ground (E67).

Ground is supplied to the side turn signal lamp LH terminal ② through body ground (E67) (LHD models) or (F37) (RHD models).

Ground is supplied to the rear combination lamp LH terminal ④ through body ground (T19).

Ground is supplied to combination meter terminal ⑩ through body ground (M1).

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to

- front turn signal lamp RH terminal ①
- side turn signal lamp RH terminal ①
- rear combination lamp RH terminal ②
- combination meter terminal ⑩

Ground is supplied to the front turn signal lamp RH terminal ② through body ground (E43).

Ground is supplied to the side turn signal lamp RH terminal ② through body ground (F26) (LHD models) or (E43) (RHD models)

Ground is supplied to the rear combination lamp RH terminal ④ through body ground (T19).

Ground is supplied to combination meter terminal ⑩ through body ground (M1).

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 10A fuse (No. 22) . located in the fuse block).

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ②
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④

Ground is supplied to combination flasher unit terminal ① through body ground (M1) or (M67).

Power is supplied through terminal ⑤ of the hazard switch to

- front turn signal lamp LH terminal ①
- side turn signal lamp LH terminal ①
- rear combination lamp LH terminal ②
- combination meter terminal ⑩

Power is supplied through terminal ⑥ of the hazard switch to

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/System Description (Cont'd)

- front turn signal lamp RH terminal ①
- side turn signal lamp RH terminal ①
- rear combination lamp RH terminal ②
- combination meter terminal ⑩

Ground is supplied to terminal ② of each front turn signal lamp through body ground (E43) or (E57).

Ground is supplied to terminal ② of driver's side turn signal lamp through body ground (E43) or (E57).

Ground is supplied to terminal ② of passenger side turn signal lamp through body ground (F26) or (F37).

Ground is supplied to terminal ④ of the rear combination lamps through body ground (T19).

Ground is supplied to combination meter terminal ⑩ through body ground (M1).

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times

- through 10A fuse (No. 22) located in the fuse block
- to multi-remote control relay-1 terminals ①, ⑥ and ③.

Ground is supplied to multi-remote control relay-1 terminal ②, when the multi-remote control system or theft warning system is triggered through the smart entrance control unit.

Refer to "MULTI-REMOTE CONTROL SYSTEM" or "THEFT WARNING SYSTEM".

The multi-remote control relay-1 is energized

Power is supplied through terminal ⑦ of the multi-remote control relay-1

- to front turn signal lamp LH terminal ①
- to side turn signal lamp LH terminal ①
- to rear combination lamp LH terminal ②
- to combination meter terminal ⑩

Power is supplied through terminal ⑤ of the multi-remote control relay-1

- to front turn signal lamp RH terminal ①
- to side turn signal lamp RH terminal ①
- to rear combination lamp RH terminal ②
- to combination meter terminal ⑩

Ground is supplied to terminal ② of each front turn signal lamp through body ground (E43) or (E57).

Ground is supplied to terminal ② of driver's side turn signal lamp through body ground (E43) or (E57).

Ground is supplied to terminal ② of passenger side turn signal lamp through body ground (F26) or (F37).


Ground is supplied to terminal ④ of the rear combination lamps through body ground (T19).

Ground is supplied to combination meter terminal ⑩ through body ground (M1).

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Schematic



51
 52
 53
 54
 55
 56
 57
 58
 59
 60
 61
 62
 63
 64
 65
 66
 67
 68
 69
 70
 71
 72
 73
 74
 75
 76
 77
 78
 79
 80
 81
 82
 83
 84
 85
 86
 87
 88
 89
 90
 91
 92
 93
 94
 95
 96
 97
 98
 99
 100

EL




EX

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN —

LHD MODELS

EL-TURN-01



Refer to last page
(Foldout page).

M10 E101


M11 B1

M60 F4

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)

EL-TURN-02



	0		E110
3	1	2	W

	10	11	

			E42, E49
		BR	BR

			E14, E13
		GY	GY

	0		
2		4	

			T17, T22
		W	W

			10	11	

						E24
						W




- GA
- MA
- EM
- LG
- EC
- FE
- CL
- WT
- ET
- FO
- EA
- BR
- BT
- ES
- BT
- KA
- EL
- FOX

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)

RHD MODELS

EL-TURN-03




Refer to last page (Foldout page).

- M10, E10
- M11, G1
- M60, F4


EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)


EL-TURN-04



EU : For Europe
 EE : Except for Europe
 *K1 : EU LG/B, EE Y




Refer to last page (Foldout page).
 M10, E10
 M11, B1



EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram — TURN — (Cont'd)


EL-TURN-05



EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate	<ol style="list-style-type: none"> 1 Hazard switch 2 Combination flasher unit 3 Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1 Check hazard switch 2 Refer to combination flasher unit check (EL-101) 3 Check wiring to combination flasher unit for open circuit
Turn signal lamps do not operate but hazard warning lamps operate	<ol style="list-style-type: none"> 1 10A fuse 2 Hazard switch 3 Turn signal switch 4 Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. [24] , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch. 2 Check hazard switch 3. Check turn signal switch 4 Check wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2 Hazard switch 3 Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. [22] , located in fuse block). Verify battery positive voltage is present at terminal ③ of hazard switch 2 Check hazard switch 3. Check wire between combination flasher unit and hazard switch for open circuit
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1 Bulb 2 Ground (E44) or (E51) 	<ol style="list-style-type: none"> 1 Check bulb. 2 Check ground (E44) or (E51).
Side turn signal lamp on driver's side does not operate.	<ol style="list-style-type: none"> 1 Bulb 2 Ground (E43) or (E57) 	<ol style="list-style-type: none"> 1 Check bulb. 2 Check ground (E43) or (E57).
Side turn signal lamp on passenger side does not operate.	<ol style="list-style-type: none"> 1 Bulb 2 Ground (F28) or (F37) 	<ol style="list-style-type: none"> 1 Check bulb. 2 Check ground (F28) or (F37).
Rear turn signal lamp LH or RH does not operate	<ol style="list-style-type: none"> 1 Bulb 2. Ground (T19) 	<ol style="list-style-type: none"> 1 Check bulb 2. Check ground (T19)
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1 Ground 	<ol style="list-style-type: none"> 1 Check ground (M1)
LH or RH turn indicator does not operate	<ol style="list-style-type: none"> 1 Bulb 	<ol style="list-style-type: none"> 1 Check bulb in combination meter.



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

EXTERIOR LAMP

Bulb Specifications

Item	Wattage (W)
Front fog lamp	55
Front turn signal lamp	21
Clearance lamp	5
Side turn signal lamp	5
Rear combination lamp	
Turn signal lamp	21
Stop/Tail lamp	21/5
Back-up lamp	21
License plate lamp	5
Rear fog lamp	21
High-mounted stop lamp	5

INTERIOR LAMP

Illumination/System Description

Power supply routing for illumination lamps are the same as that of clearance, license and LH tail lamp. Refer to "Clearance, License and Tail Lamps"

On vehicles for Europe and Australia, illumination of combination meter and clock is controlled by illumination control switch

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.


Component	Connector No.	Power terminal	Ground terminal	Ground
Audio	M40	8	-- (Unit ground)	--
Push control unit	M32	15	16	(M1) or (M67)
Auto A/C unit	M31	13	14	(M1) or (M67)
A/T indicator	B8	7	6	(B2) or (B18)
Power window main switch	D9	15	16	(M1) or (M67)
Cigarette lighter	M42	3	1	(M1) or (M67)
Combination meter	M20	6	33	(*)
Clock	M20	8	33	(*)
Hazard switch (For Europe)	M34	7	8	(M1) or (M67)
Hazard switch (Except for Europe)	M35	7	8	(M1) or (M67)
Glove box lamp (switch)	M103	2	1	(M1) or (M67)
Front fog lamp switch	B7	5	6	(B2) or (B18)
Rear fog lamp switch	M38	6	5	(M1) or (M67)
Headlamp washer switch	M36	4	3	(M1) or (M67)
Rear window defogger switch	M37	5	6	(M1) or (M67)
Illumination control switch	M21	1	3	(M1) or (M67)

*) For Europe and Australia models. Illumination control switch
 Except for Europe and Australia models (M1) or (M67)

INTERIOR LAMP

Illumination/Schematic

- (R) : RHD models
- (E) : For Europe
- (EE) : Except for Europe
- (EL) : LHD models with daytime light system
- (EL) : LHD models without daytime light system
- (NE) : Except (EL)
- (AE) : Models with auto A/C
- (MA) : Models without auto A/C
- (NA) : Except for Australia
- (AE) : For Europe and Australia
- (NA) : Except (AE)






SEL711T

INTERIOR LAMP


Illumination/Wiring Diagram — ILL —

EL-ILL-01



Refer to last page (Foldout page).

(M10), (E101)






81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

EL

INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)





EL-ILL-02



INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-03




EL

INTERIOR LAMP





Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-04

Preceding page R/L R/L Next page





- : Models with auto A/C
- : Models without auto A/C
- : For Europe
- : Except for Europe



INTERIOR LAMP


Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-05



Refer to last page (Foldout page).

(M11), (B1)



INTERIOR LAMP

Interior, Spot and Trunk Room Lamps/System Description

Power is supplied at all times

- through 10A fuse (No. 21) located in the fuse block)
- to interior lamp terminal ①.
- to spot lamp terminal ① and
- to trunk room lamp terminal ①.

INTERIOR LAMP

Switch operation

With interior lamp switch in the ON position, ground is supplied to turn interior lamp on.

When a door switch is set to OPEN with interior lamp switch in the DOOR position, ground is supplied

- to interior lamp terminal ②
- through diode (M4) terminal ① (Except for Europe models)
- to diode (M4) terminal ② (Except for Europe models)
- through diode (M4) terminal ① (Except for Europe models)
- to diode (M4) terminal ② (Except for Europe models)
- through door switch passenger side terminal ① or
- through door switch driver's side terminal ②,
- through door switch unit ground.

Interior lamp control by multi-remote control system

When the smart entrance control unit receives a signal from multi-remote controller to unlock the door with interior lamp switch set in DOOR position, ground is supplied

- to interior lamp terminal ②
- through smart entrance control unit terminal ⑨,
- through smart entrance control unit terminal ⑩ and
- through body ground (M1).

With power and ground supplied, the interior lamp illuminates.

For smart entrance control unit, refer to "MULTI-REMOTE CONTROL SYSTEM".

TRUNK ROOM LAMP

When the trunk room lamp switch is set to OPEN, ground is supplied

- to trunk room lamp terminal ②
- through trunk room switch terminal ①,
- through trunk room lamp switch terminal ② and
- through body ground (T19).

With power and ground supplied, the trunk room lamp illuminates.

SPOT LAMP

With the spot lamp switch in the ON position, ground is supplied

- to spot lamp terminal ②
- through body ground (M1) or (M57).

With power and ground supplied, the spot lamp illuminates.

Bulb Specifications



Item	Wattage (W)
Interior lamp	10
Spot lamp	10
Trunk room lamp	3.4

INTERIOR LAMP

Interior, Spot and Trunk Room Lamps/Wiring Diagram — INT/L —

LHD MODELS

EL-INT/L-01



Refer to last page (Foldout page).

(M11) (B1)


GI
MA
EM
LC
EC
FE
CL
MY
AT
PD
EA
PA
RR
ST
RS
BT
HA
EL
DM

INTERIOR LAMP


Interior, Spot and Trunk Room Lamps/Wiring Diagram — INT/L — (Cont'd)

RHD MODELS

EL-INT/L-02



- ⓔⓤ For Europe
- ⓔⓔ Except for Europe
- ⓈⓇ Models with sun roof
- ⓃⓈ Models without sun roof
- *1 ⓔⓤ R/W, ⓔⓔ L/R
- *2 ⓔⓤ R/W, ⓔⓔ L
- ⓇⓇⓇ ⓃⓈ
- ⓇⓇⓇ ⓈⓇ



Refer to last page (Foldout page)

ⓇⓇⓇ M11, B1

ⓇⓇⓇ M18

METER AND GAUGES

System Description

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 25) located in the fuse block
- to combination meter terminal 21.

Ground is supplied

- to combination meter terminal 22
- through body ground (M1).

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 13 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 7 of the ECM (ECCS control module)
- to combination meter terminal 12 for the tachometer.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 20 for the fuel gauge
- from terminal 1 of the fuel tank gauge unit
- through terminal 3 of the fuel tank gauge unit and
- through body grounds (T19), (B2) and (B18).

SPEEDOMETER

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals 28 and 45 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

21

22

13

7

12

20

1

3

28

45

1

2

EL

EL

EL








EL

EL

EL

EL




Inspection/Fuel Gauge and Water Temperature Gauge





(Go to (A) on next page)





METER AND GAUGES

Inspection/Fuel Gauge and Water Temperature Gauge (Cont'd)




Inspection/Tachometer





Inspection/Speedometer and Vehicle Speed Sensor




SYMPTOM: Speedometer stays at 0 km/h (0 MPH).



METER AND GAUGES

Inspection/Speedometer and Vehicle Speed Sensor (Cont'd)


SYMPTOM: Speedometer indication flutters.



31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100

EL


METER AND GAUGES



Thermal Transmitter Check


Check the resistance between the terminals of thermal transmitter and body ground

Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90Ω
100°C (212°F)	Approx. 21 - 24Ω



Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage across ① and ②.



Fuel Tank Gauge Unit Check

Sending unit

- For removal, refer to FE section.


Check the resistance between terminals ① and ③.

Ohmmeter		Float position		Resistance value (Ω)
(+)	(-)	mm (in)		
①	③	*1	Full	358 (14.09)
		*2	1/2	245 (9.65)
		*3	Empty	42 (1.65)

*1 and *3: When float is in contact with stopper

METER AND GAUGES

Lead Switch



SEL839T


Lead switch is built into the fuel tank.
Check the continuity between terminals ④ and ⑤ or ④ and ⑥

Terminals			Lead switch condition		Fuel level line	Fuel capacity (Approximate values) ℓ (Imp qt)
④	⑤	⑥	SW1	SW2		
○	○	○	ON	ON	Above ①	More than 6.8 (6)
○	○		OFF	ON	① - ②	2.5 - 6.8 (2-1/4 - 6)
			OFF	OFF	Below ②	Less than 2.5 (2-1/4)

EL

WARNING LAMPS AND BUZZER

Warning Lamps/Schematic





WARNING LAMPS AND BUZZER

Warning Lamps/Wiring Diagram — WARN —

LHD MODELS

EL-WARN-01





Refer to last page (Foldout page).

(M10), (E101)

(M11), (B1)

(M60), (F4)

(F1)







EL

WARNING LAMPS AND BUZZER


Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



Refer to last page
(Foldout page).




(M11), (B1)




WARNING LAMPS AND BUZZER

Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



Refer to last page (Foldout page).



Q1
M1A
EM
LC
EG
SE
E1
M1
AT
FD
FA
M1A
RR
ST
RS
RT
M1A
EL
FB




EL

WARNING LAMPS AND BUZZER

Warning Lamps/Wiring Diagram — WARN — (Cont'd)

RHD MODELS

EL-WARN-04



Refer to last page (Foldout page).


- (M10, E101)
- (M11, B1)
- (M60, F4)
- (F1)

WARNING LAMPS AND BUZZER

Warning Lamps/Wiring Diagram — WARN — (Cont'd)


EL-WARN-05

- (NU) : Except for Australia
- (EU) : For Europe
- (EE) : Except for Europe
- *1 : (EU) R/W, (EE) L/R
- *2 : (EU) R/W, (EE) L



Refer to last page (Foldout page).

- (M10), (E101)
- (M11), (E1)





EL

WARNING LAMPS AND BUZZER

Warning Lamps/Wiring Diagram — WARN — (Cont'd)

EL-WARN-06


- Ⓔ : For Europe
- Ⓔ : Except for Europe
- Ⓔ : For Australia



Refer to last page
(foldout page).


- M10, E10
- M11, B1
- M18

WARNING LAMPS AND BUZZER



Fuel Warning Lamp Sensor Check


- It will take a short time for the bulb to light.



Oil Pressure Switch Check

	Oil pressure kPa (bar, kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3)	YES


Check the continuity between the terminals of oil pressure switch and body ground.



Diode Check

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.

WARNING LAMPS AND BUZZER

Warning Buzzer/System Description

The warning buzzer is controlled by the smart entrance control unit

Power is supplied at all times

- through 10A fuse (No. 21), located in the fuse block)
- to warning buzzer terminal ③
- to key switch terminal ①

Power is supplied at all times

(LHD models without daytime light system)

- through 45A fusible link (letter T), located in the fusible link and fuse box).
- to lighting switch terminal ⑪

(LHD models with daytime light system and RHD models)

- through 10A fuse (No. 23), located in the fuse block)
- to lighting switch terminal ⑪ (For Europe) or ⑫ (Except for Europe)

Power is supplied at all times

- through 25A fusible link (letter L), located in the fusible link and fuse box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ①

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 26), located in the fuse block)
- to smart entrance control unit terminal ⑪

Ground is supplied to smart entrance control unit terminal ⑩ through body ground (M1).

When a signal, or combination of signals, is received by the smart entrance control unit, ground is supplied

- through smart entrance control unit terminal ⑭
- to warning buzzer terminal ①

With power and ground supplied, the warning buzzer will sound.

Ignition key warning buzzer (Except for Europe models)

With the key in the ignition switch in the OFF position, and the driver's door open, the warning buzzer will sound. A battery positive voltage is supplied

- from key switch terminal ②
- to smart entrance control unit terminal ⑭

Ground is supplied

- from driver side door switch terminal ①
- to smart entrance control unit terminal ⑮

Driver side door switch terminal ③ is grounded through body grounds (B2) and (B19).

Light warning buzzer

With ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning buzzer will sound. A battery positive voltage is supplied

(LHD models without daytime light system)

- from lighting switch terminal ⑫
- through 10A fuse (No. 14), located in the fuse block)
- to smart entrance control unit terminal ⑮

(LHD models with daytime light system)

- from lighting switch terminal ⑫
- to daytime light unit terminal ⑪
- through daytime light unit terminal ⑩
- to smart entrance control unit terminal ⑮

(RHD models)

- from lighting switch terminal ⑫ (For Europe) or ⑪ (Except for Europe)
- to smart entrance control unit terminal ⑮

Ground is supplied



- from driver side door switch terminal ①
- to smart entrance control unit terminal ⑮

Driver side door switch terminal ③ is grounded through body grounds (B2) and (B19).

WARNING LAMPS AND BUZZER

Warning Buzzer/Wiring Diagram — CHIME —

EL-CHIME-01



Refer to last page (Foldout page).

M10, E100




M11, B1

M18

WARNING LAMPS AND BUZZER

Warning Buzzer/Wiring Diagram — CHIME — (Cont'd)

EL-CHIME-02



Refer to last page
(Foldout page).

(M10), (E101)
(M18)

WARNING LAMPS AND BUZZER

Trouble Diagnoses — Warning Buzzer


SYMPTOM CHART

PROCEDURE	Preliminary Check		Main Power Supply and Ground Circuit Check	Diagnostic Procedure	
	EL-133	EL-133		EL-135	EL-136
SYMPTOM	Preliminary check 1	Preliminary check 2	Main power supply and Ground circuit	Diagnostic Procedure 1	Diagnostic Procedure 2
Light warning buzzer does not activate					
Ignition key warning buzzer does not activate (Except for Europe model)					

PRELIMINARY CHECK


Preliminary check 1

- Light warning buzzer does not activate.



Preliminary check 2


- Ignition key warning buzzer does not activate.



EL


WARNING LAMPS AND BUZZER

Trouble Diagnoses — Warning Buzzer (Cont'd) MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK



Main power supply

Terminals	Battery voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
(11) - (10)	No	No	Yes
(1) - (10)	Yes	Yes	Yes



Ground circuit

Terminals	Continuity
(10) - Ground	Yes





WARNING LAMPS AND BUZZER

Trouble Diagnoses — Warning Buzzer (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Light warning buzzer does not activate.

- Perform "Preliminary check 1" before referring to the following flow chart.



A Step 3

DOOR SWITCH INPUT SIGNAL CHECK
Check continuity between control unit harness terminals (15) and (10)

Condition of driver's door	Continuity
Driver side door is closed	No
Driver side door is open	Yes

OK

NG

- Check door switch (Refer to EL-246)
- Check harness continuity between control unit harness terminal (15) and driver side door switch harness terminal (1).
- Continuity should exist.**
- Check harness continuity between driver side door switch harness terminal (3) and body ground
- Continuity should exist.**

B Step 2

BUZZER POWER SUPPLY CHECK
Measure voltage between warning buzzer harness terminal (3) and body ground
Battery voltage should exist.

OK

NG

Check 10A fuse (21) harness and connector

C

BUZZER OUTPUT SIGNAL CHECK
Check continuity between warning buzzer harness terminal (1) and control unit harness terminal (23)
Continuity should exist.

OK

NG

Repair harness or connectors.

WARNING BUZZER CHECK
Refer to EL-137

OK

NG

Replace warning buzzer

D Step 1

LIGHTING SWITCH INPUT SIGNAL CHECK
Measure voltage between control unit harness terminals (25) and (10).

Condition	Voltage [V]
Lighting switch is ON	Approx 12
Lighting switch is OFF	0

OK

NG

- Check lighting switch
- Check harness continuity between control unit harness terminal (25) and lighting switch harness terminal (12)
- Continuity should exist.**
- Measure voltage between lighting switch harness terminal (11) and body ground
- Battery voltage should exist.**

Replace control unit

EL






WARNING LAMPS AND BUZZER

Trouble Diagnoses — Warning Buzzer (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Ignition key warning buzzer does not activate.
(Except Europe model)

- Perform "Preliminary check 2" before referring to the following flow chart.





WARNING LAMPS AND BUZZER

Warning Buzzer Check

Supply battery voltage to warning buzzer as shown in the illustration.

Warning buzzer should operate.



MEL317D

電
機
器
の
組
立
と
調
試
の
手
順
書
を
読
み
ま
と
り
ま
す
。

EL

WIPER AND WASHER

Front Wiper and Washer/System Description

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch.

There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 111), located in the fuse block
- to front wiper motor terminal ②

Low and high speed wiper operation

Ground is supplied to wiper switch terminal ⑱ through body ground ④③ or ⑤⑦.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal ⑭ of the wiper switch
- to wiper motor terminal ④.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal ⑯ of the wiper switch
- to wiper motor terminal ⑤.

With power and ground supplied, the wiper motor operates at high speed.

Auto stop operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal ⑭ of the wiper switch
- to wiper motor terminal ④, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal ⑬ of the wiper switch
- to wiper amplifier terminal ②
- through terminal ⑦ of the wiper amplifier
- to wiper motor terminal ①
- through terminal ⑥ of the wiper motor, and
- through body ground ⑤⑦.

When wiper arms reach base of windshield, wiper motor terminals ① and ② are connected instead of terminals ① and ⑥. Wiper motor will then stop wiper arms at the PARK position.

Intermittent operation

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 3 to 13 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal ①
- from wiper switch terminal ⑮
- through wiper switch terminal ⑱ and body ground ④③ or ⑤⑦.
- to wiper motor terminal ④
- through the wiper switch terminal ⑭
- to wiper switch terminal ⑰
- through wiper amplifier terminal ②
- to wiper amplifier terminal ③
- through body ground ⑤⑦

The desired interval time is input

- to wiper amplifier terminal ⑧
- from wiper switch terminal ⑲

The wiper motor operates at low speed at the desired time interval.

WIPER AND WASHER

Front Wiper and Washer/System Description (Cont'd)

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied through 20A fuse (No. 11) located in the fuse block

- to washer motor terminal ①
- When the lever is pulled to the WASH position, ground is supplied
- to washer motor terminal ②, and
- to wiper amplifier terminal ⑥
- from terminal ⑩ of the wiper switch
- through terminal ⑪ of the wiper switch, and
- through body ground (E4) or (E7).



With power and ground supplied, the washer motor operates.

The wiper motor operates when the lever is pulled to the WASH position for one second or more and for approximately 3 seconds after the lever is released. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.



WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram — WIPER —

EL-WIPER-01



Refer to last page
(Foldout page).






WIPER AND WASHER


Front Wiper and Washer/Wiring Diagram

— WIPER — (Cont'd)

EL-WIPER-02



Refer to last page (Foldout page).








GI
MA
EM
LG
EC
PE
GL
MT
AT
PD
FA
BA
BR
ST
RS
BT
FA
EL
DS

Trouble Diagnoses

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.





WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.





OK → Replace wiper amp.

NG

Check intermittent wiper volume. Check harness continuity between wiper amp. harness terminal ② and wiper switch harness terminal ⑩. Check harness continuity between wiper switch harness terminal ⑪ and body ground.



DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.



NG → Check harness continuity between wiper amp harness terminal ② and wiper switch harness terminal ⑩

OK



NG → Check wiper switch.

OK

Replace wiper amp

GF

MA

EM

LC

EC

FE

GI

MT

AT

PD

FA

RA

RR

ST

RS


BT

HA

EL


FDX

WIPER AND WASHER



Front Wiper Amplifier Check

1. Connect as shown in the figure at left.
2. If test lamp comes on when connected to terminal ① or ⑥ and battery ground, wiper amplifier is normal.



Front Wiper Installation and Adjustment

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L₁" & "L₂".


Clearance "L₁": 18 - 33 mm (0.71 - 1.30 in)

Clearance "L₂": 17 - 32 mm (0.67 - 1.26 in)


- Tighten wiper arm nuts to specified torque.

Front wiper:

16.7 - 22.6 N·m (1.70 - 2.31 kg·m, 12.32 - 16.67 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



Front Washer Nozzle Adjustment

- Using a suitable tool, adjust windshield washer nozzle to correct its spray pattern.

Adjustable range: $\pm 10^\circ$ (In any direction)


Before attempting to turn the nozzle, gently tap the end of the tool to free the nozzle.

This will prevent "rounding out" the small female square in the center of the nozzle.

WIPER AND WASHER

Front Washer Nozzle Adjustment (Cont'd)

LHD models




Unit: mm (in)


*1	358 (14 09)	*5	70 (2 76)
*2	245 (9 65)	*6	245 (9 65)
*3	300 (11 81)	*7	378 (14 88)
*4	203 (7 99)	*8	503 (19 80)

* The diameters of these circles are less than 80 mm (3.15 in)

RHD models




Front Washer Tube Layout



WIPER AND WASHER

Front Wiper Linkage



This illustration is for LHD models. For RHD models, these units are installed on the opposite side.

REMOVAL

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage

Be careful not to break ball joint rubber boot.

INSTALLATION

- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

Rear Wiper and Washer/System Description

WIPER OPERATION

The rear wiper switch is controlled by a ring built into the combination switch.

There are two wiper switch positions.

- ON (LO speed)
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 10A (LHD models) or 15A (RHD models) fuse (No. 16 (LHD models) or 14 (RHD models), located in the fuse block)
- to rear wiper motor terminal ④, and
- to rear wiper relay terminal ①.

Low speed wiper operation

Ground is supplied to rear wiper switch terminal ② through body ground E42 or E57.

When the rear wiper is placed in the ON position, ground is supplied

- through rear wiper switch terminal ②
- to rear wiper relay terminal ②.

The rear wiper relay is energized and ground is supplied

- to rear wiper motor terminal ①
- through rear wiper relay terminal ③
- to rear wiper relay terminal ⑤
- through body ground T18.

Auto stop operation

With the rear wiper switch turned OFF, rear wiper motor will continue to operate until wiper arm reaches rear window base.

When wiper arm is not located at base of rear window with rear wiper switch OFF, rear wiper relay is not energized and ground is supplied

- to rear wiper motor terminal ①
- through rear wiper relay terminal ③
- to rear wiper relay terminal ④
- through rear wiper motor terminal ③, in order to continue rear wiper motor operation at low speed.

Ground is also supplied

- to rear wiper motor terminal ②
- through body ground B2 or B18.

When wiper arm reaches base of rear window, rear wiper motor terminals ① and ④ are connected instead of terminals ① and ③. Rear wiper motor will then stop wiper arm at the PARK position.

Intermittent operation

The rear wiper motor operates the wiper arm one time at low speed at an interval of approximately 7 seconds. This feature is controlled by rear wiper amplifier.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A (LHD models) or 15A (RHD models) fuse (No. 16 (LHD models) or 14 (RHD models), located in the fuse block)
- to rear wiper relay terminal ①.

When the rear wiper switch is placed in the INT position, ground is supplied

- to rear wiper amplifier terminal ②
- from rear wiper switch terminal ①
- through body ground E43 or E57.

Ground is also supplied

- to rear wiper relay terminal ②
- through rear wiper amplifier terminal ⑥
- to rear wiper amplifier terminal ⑤;
- through body ground M1.

Then the rear wiper relay is energized and ground is supplied

- to rear wiper motor terminal ①
- through rear wiper relay terminal ③;
- to rear wiper relay terminal ⑤
- through body ground T18.

WIPER AND WASHER

Rear Wiper and Washer/System Description (Cont'd)

With power and ground supplied, the rear wiper motor operates intermittently.

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 10A (LHD models) or 15A (RHD models) fuse (No 16 (LHD models) or 14 (RHD models), located in the fuse block)
- to rear washer motor terminal ①.

When the ring is turned WASH position, ground is supplied

- to rear washer motor terminal ②, and
- to rear wiper amplifier terminal ①
- from terminal ③ of rear wiper switch
- through terminal ④ of rear wiper switch, and
- through body ground (E43) or (E57)


With power and ground is supplied, the rear washer motor operates.

The rear wiper motor operates when the ring is turned to WASH position for one second or more and for approximately 3 seconds after the ring is released. This feature is controlled by the rear wiper amplifier in the same manner as the intermittent operation.

WIPER AND WASHER

Rear Wiper and Washer/Wiring Diagram — WIP/R —

EL-WIP/R-01



Refer to last page
(Foldout page).

M10, E101





EL

WIPER AND WASHER

Rear Wiper and Washer/Wiring Diagram

— WIP/R — (Cont'd)

EL-WIP/R-02



Refer to last page (Foldout page).


$\boxed{\text{M11}}$ $\boxed{\text{B1}}$

WIPER AND WASHER

Rear Wiper Amplifier Check

1. Connect as shown in the figure at left.
2. If test lamp comes on when connected to terminal ① or ② and battery ground, wiper amplifier is normal.

Rear wiper amplifier



SEL846T

Rear Wiper Installation and Adjustment


1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₃" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF"
4. Ensure that wiper blades stop within clearance "L₃".

Clearance "L₃": 26 - 42 mm (1.02 - 1.65 in)

- Tighten wiper arm nuts to specified torque.


Rear wiper:

12.7 - 17.7 N·m (1.30 - 1.81 kg-m, 9.37 - 13.06 ft-lb)



SEL847T

- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.




SEL024J

Rear Washer Nozzle Adjustment

- Using a suitable tool, adjust rear window washer nozzle to correct its spray pattern.

Adjustable range: $\pm 15^\circ$ (in any direction)


Suitable tool



SEL848T

WIPER AND WASHER

Rear Washer Nozzle Adjustment (Cont'd)





Unit, mm (in)

*11	219 (8.62)	*12	45 (1.77)
-----	------------	-----	-----------

* The diameters of these circles are less than 90 mm (3.54 in)

Rear Washer Tube Layout



Check Valve (For rear washer)

- A check valve is provided in the rear washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.

Headlamp Washer/System Description

Power is supplied at all times

through 25A fusible link (letter **11**), located in the fusible link and fuse box)

to headlamp washer motor terminal **1**

GI

Power is also supplied at all times

through 20A fuse (No. **38**), located in the fusible link and fuse box)

to lighting switch terminal **8**.

MA

Headlamp washer operation

EM

The headlamp washer operates for approximately 1 second at one time. This feature is controlled by headlamp washer amplifier.

For headlamp washer operation, the lighting switch must be in the 2ND position and ignition switch in the ON or START position.

LG

With the headlamp washer switch in the ON position, ground is supplied

to headlamp washer amplifier terminal **2**

EG

through headlamp washer switch terminal **1**

to headlamp washer switch terminal **5**

FE

through body ground (**M1**) or (**M37**).

Ground is also supplied

to headlamp washer motor terminal **2**

GI

through headlamp washer amplifier terminal **4**

to headlamp washer amplifier terminal **5**

WT

through body ground (**E43**).

With power and ground supplied, headlamp washer will operate.

ST

FD

FA

FE

FR

ST

FD

WT


MA

EL

FDX

Headlamp Washer/Wiring Diagram — HLC —

EL-HLC-01



4	3	E35
5	2	

W

1	E32
2	

BR

1	7	M35
6	5	

BH



Refer to last page (Foldout page).


M10, E101

WIPER AND WASHER

Headlamp Washer/Wiring Diagram — HLC — (Cont'd)


EL-HLC-02






Headlamp Washer Amplifier Check

- 1 Connect as shown in the figure at left.
- 2 If test lamp comes on when connected to the terminal ③ and battery ground, headlamp washer amplifier is normal.




Headlamp Washer Nozzle Adjustment

- Using a suitable tool, adjust headlamp washer nozzle to correct its spray pattern.
Adjustable range: $\pm 3^\circ$ (Up and down)



Headlamp Washer Tube Layout



Check Valve (For headlamp washer)

System Description

Power is supplied at all times

- from 25A fusible link (Letter **T** located in the fuse and fusible link box)
- to circuit breaker terminal **(1)**
- through circuit breaker terminal **(2)**
- to power window relay terminal **(3)**

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse (No. **26** located in the fuse block)
- to power window relay terminal **(1)**

Ground is supplied to power window relay terminal **(2)**

- through body ground **(MT)**.

The power window relay is energized and power is supplied

- through power window relay terminal **(5)**
- to power window main switch terminal **(5)**.
- to power window sub-switch terminal **(4)**.
- to power window amplifier terminal **(3)** and
- to power window amplifier terminal **(4)**.

MANUAL OPERATION

Driver side door

Ground is supplied

- to power window main switch terminal **(4)** and
- to power window amplifier terminal **(7)**
- through body ground **(MT)**.

WINDOW UP

When the driver side switch in the power window main switch is pressed in the up position, ground signal is supplied

- to power window amplifier terminal **(1)**
- from power window main switch terminal **(3)**.

Power is supplied

- to driver side power window regulator terminal **(1)**
- through power window amplifier terminal **(5)**

Ground is supplied

- to driver side power window regulator terminal **(2)**
- through power window amplifier terminal **(6)**

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the driver side switch in the power window main switch is pressed in the down position, ground signal is supplied

- to power window amplifier terminal **(2)**
- from power window main switch terminal **(2)**.

Power is supplied

- to driver side power window regulator terminal **(2)**
- through power window amplifier terminal **(6)**.

Ground is supplied

- to driver side power window regulator terminal **(1)**
- through power window amplifier terminal **(5)**

Then, the motor lowers the window until the switch is released.

Passenger side door

Ground is supplied

- to power window main switch terminal **(4)**
- through body ground **(MT)**

GI

MA

EM

LC

EC

FE

SL

MT

AT

PD

SA

RA

RB

ST

RS

BT

HA

EL

DX

POWER WINDOW

System Description (Cont'd)

NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively

MAIN SWITCH OPERATION

Power is supplied

- through power window main switch (⑤, ⑦)
- to power window sub-switch (①, ⑤).

The subsequent operation is the same as the sub-switch operation.

SUB-SWITCH OPERATION

Power is supplied

- through power window sub-switch (②, ③)
- to passenger side power window regulator (①, ②).

Ground is supplied

- to passenger side power window regulator (②, ①)
- through power window sub-switch (③, ②)
- to power window sub-switch (⑤, ①)
- through power window main switch (⑦, ⑥)

Then, the motor raises or lowers the window until the switch is released.

AUTO OPERATION

The power window AUTO feature enables the driver to raise or lower the driver's window without holding the window switch.

The AUTO feature only operates on the driver's window.

When a power window main switch is pressed and released the AUTO position, ground signal is supplied

- to power window amplifier terminal ⑧
- from power window main switch terminal ①

The subsequent operation is the same as the manual operation of driver side door.

Then, the driver side door window will fully close or fully open.


POWER WINDOW LOCK

The power window lock is designed to lock-out window operation to passenger side door window.

When the lock switch is pressed to lock position, ground of the passenger side switch in the power window main switch is disconnected. This prevents the power window motors from operating.

POWER WINDOW

Schematic




EL


POWER WINDOW

Wiring Diagram — WINDOW —

EL-WINDOW-01



- (L) : LHD models
- (R) : RHD models
- *1 : (L) L/R, (R) W





Refer to last page (Foldout page).

M10, E101

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02





GI
MA
EM
LC
EC
FE
CL
MT
RY
FD
FA
SA
SH
SY
FD
GI
MA
EM

EL

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03






POWER WINDOW

Trouble Diagnosis

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Driver and passenger power window cannot be operated.




POWER WINDOW

Trouble Diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Driver's power window cannot be operated but passenger power window can be operated.




A

CHECK POWER SUPPLY FOR POWER WINDOW AMP.

- 1) Disconnect connector from power window amp.
- 2) Check voltage across power window amp terminal ③ and GND, ④ and GND while ignition switch is "ON".

Terminals	Battery voltage existence
③ - GND	Yes
④ - GND	

NG → Repair harness between power window relay and power window amp



OK

B


CHECK POWER WINDOW MAIN SWITCH CIRCUIT.

- 1) Disconnect connector from power window main switch.
- 2) Check continuity

Power window main switch operation	Terminals
Auto (Down)	① - ④
Up	③ - ④
Down	② - ④

Does continuity exist?

No → Replace power window main switch.



Yes

C

- 1) Disconnect connector from power window amp connector
- 2) Check continuity

Power window main switch operation	Terminals
Auto	① - ⑧
Up	③ - ①
Down	② - ②



Does continuity exist?

No → Repair harness

Yes → (Go to next page)

POWER WINDOW

Trouble Diagnosis (Cont'd)



A

D

CHECK POWER WINDOW MOTOR CIRCUIT.

- 1) Connect power window amp. connector.
- 2) Check voltage for power window motor.

Terminals		Power window main switch operation
⊕	⊖	
⑤	⑥	Up
⑥	⑤	Down

Does battery voltage exist?

Yes

E

- 1) Disconnect driver side power window regulator connector.
- 2) Check continuity.

Terminals	
⑤	①
⑥	②

Does continuity exist?

Yes

Check driver side power window motor
 Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-168)

No

Replace power window amp.

No

Repair harness.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 SA
 PA
 BP
 ST
 RS
 RT
 HA
 EL
 PX

POWER WINDOW

Trouble Diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 3-1

SYMPTOM: Passenger power window (main switch and sub-switch) cannot be operated. But driver side power window can be operated.



A

CHECK GROUND CIRCUIT.

- 1) Disconnect power window main switch connector
- 2) Check continuity between power window main switch terminal (4) and GND.

Does continuity exist?

No

Repair harness

Yes

B

CHECK POWER WINDOW MAIN SWITCH.

Check continuity when power window lock switch is in "UNLOCK" position.

Terminals
7 - 4
5 - 4


Does continuity exist?

No

Replace power window main switch

Yes

Check passenger side power window motor. Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-168)






POWER WINDOW

Trouble Diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 3-2

SYMPTOM: Passenger power window cannot be operated using main switch. But driver side and passenger side (using sub-switch) can be operated.



A

CHECK MAIN POWER SUPPLY.

- 1) Disconnect power window main switch connector.
- 2) Check voltage across power window main switch terminal ⑤ and GND.

Does battery voltage exist?

No → Repair harness

Yes →

B

CHECK POWER WINDOW MAIN SWITCH.

Check continuity.

Power window main switch operation	Terminals
Up	⑥ - ⑤
Down	⑦ - ⑤

Does continuity exist?

No → Replace power window main switch

Yes →

C

- 1) Connect power window main switch connector
- 2) Check voltage

Power window main switch operation	Terminals
Up	① - GND
Down	③ - GND

Does battery voltage exist?

No → Repair harness


Yes → Replace power window sub-switch

POWER WINDOW

Trouble Diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 3-3

SYMPTOM: Passenger power window cannot be operated using sub-switch. But driver side and passenger side (using main switch) can be operated.



A

CHECK MAIN POWER SUPPLY.

- 1) Disconnect power window sub-switch connector
- 2) Check voltage across power window sub-switch terminal (D) and GND.


Does battery voltage exist?

No → Repair harness.

Yes

Replace power window sub-switch

Note: If passenger power window does not lock using lock button of main switch, replace main switch.



ELECTRICAL COMPONENTS INSPECTION

POWER WINDOW MOTOR

Terminals		Operation
⊕	⊖	
①	②	Downward
②	①	

POWER DOOR LOCK

System Description

Power is supplied at all times

- through 25A fusible link (No. 17) located in the fuse and fusible link box
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ①.

Ground is supplied to smart entrance control unit terminal ⑩ through body ground (M1).

POWER DOOR LOCK OPERATION

When one of the following input signals is supplied:

- driver side door is locked/unlocked using key or lock knob.
- passenger side door is locked/unlocked using key or lock knob (Only for models with multi-remote control system);

smart entrance control unit locks/unlocks driver side door (Only for models with multi-remote control system) and passenger side door.

For operation by the remote controller, refer to "MULTI-REMOTE CONTROL SYSTEM".

Input (Unlock signal)

Models with multi-remote control system

When the driver side door is unlocked using key or lock knob, ground is supplied

- to smart entrance control unit terminal ⑫
- through driver side door lock actuator (door unlock sensor) terminal ④
- to driver side door lock actuator (door unlock sensor) terminal ②
- through body ground (M1).

When the passenger side door is unlocked using key or lock knob, ground is supplied

- to smart entrance control unit terminal ⑬
- through passenger side door lock actuator (door unlock sensor) terminal ④
- to passenger side door lock actuator (door unlock sensor) terminal ②
- through body ground (M1).

Models without multi-remote control system

When the driver side door is unlocked using key or lock knob, ground is supplied

- to smart entrance control unit terminal ⑫
- through lock knob switch terminal ②
- to lock knob switch terminal ①
- through body ground (M1).

Input (Lock signal)

The smart entrance control unit terminal ⑫ or ⑬ receives lock signal when the unlock signal is shut off.

Output (Unlock)

Driver side door (Models with multi-remote control system)

Power is supplied

- to driver side door lock actuator terminal ①
- through smart entrance control unit terminal ③.

Then, the door is unlocked.

Ground is supplied

- to driver side door lock actuator terminal ③
- through smart entrance control unit terminal ⑤.

Passenger side door

Power is supplied

- to passenger side door lock actuator terminal ①
- through smart entrance control unit terminal ②.

Ground is supplied

- to passenger side door lock actuator terminal ③
- through smart entrance control unit terminal ④

Then, the door is unlocked.

POWER DOOR LOCK

System Description (Cont'd)

Output (Lock)

Driver side door (Models with multi-remote control system)

Power is supplied

- to driver side door lock actuator terminal ③
- through smart entrance control unit terminal ⑤

Then, the door is locked.

Ground is supplied

- to driver side door lock actuator terminal ①
- through smart entrance control unit terminal ③

Passenger side door

Power is supplied

- to passenger side door lock actuator terminal ③
- through smart entrance control unit terminal ④

Ground is supplied


- to passenger side door lock actuator terminal ①
- through smart entrance control unit terminal ②

Then, the door is locked.




POWER DOOR LOCK

Wiring Diagram — D/LOCK —

EL-D/LOCK-01



- ◊ : LHD models
- ◻ : RHD models
- MR : Models with multi-remote control system
- *1... ◊ L/R, ◻ W



Refer to last page (foldout page).



- M10, E101
- M1B

EL

POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-02



Refer to last page (Foldout page).











M18

POWER DOOR LOCK

Trouble Diagnoses

DIAGNOSTIC PROCEDURE




SYMPTOM: Power door lock cannot be operated.



(Go to next page)

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)



ELECTRICAL COMPONENTS INSPECTION

Power door lock motor

Door lock condition	Terminals	
	⊕	⊖
Unlocked → Locked	③	①
Locked → Unlocked	①	③


POWER DOOR MIRROR

★ For removal of door mirror, refer to "DOOR MIRROR" in BT section.

Wiring Diagram — MIRROR —

LHD MODELS

EL-MIRROR-01



2	3	1			
5	7	4	6		

B6

W

Refer to last page
(Foldout page).

M11 B1

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

SY

RS

BT

HA


EL

DX



POWER DOOR MIRROR

Wiring Diagram — MIRROR — (Cont'd)

EL-MIRROR-02



Refer to last page
(Foldout page).




POWER DOOR MIRROR

Wiring Diagram — MIRROR — (Cont'd)


RHD MODELS

EL-MIRROR-03



Refer to last page
(Foldout page).




M11, B1



POWER DOOR MIRROR

Wiring Diagram — MIRROR — (Cont'd)

EL-MIRROR-04



Refer to last page (Foldout page).




(M13), (B1)

ELECTRIC SUN ROOF

★ For removal and adjustment of sunroof, refer to "SUNROOF" in BT section.

Wiring Diagram — SROOF —

EL-SROOF-01



Refer to last page (Foldout page).

(M10), (E101)


EL

ELECTRIC SUN ROOF

Wiring Diagram — SROOF — (Cont'd)

EL-SROOF-02

Preceding page



4	1	*3
2	3	



BR

HORN, CIGARETTE LIGHTER AND CLOCK

Wiring Diagram — HORN —

LHD MODELS



EL-HORN-01



Refer to last page (Foldout page).
 M10, E101



EL-HORN-02




Refer to last page (Foldout page).

(M10), (E10)

Wiring Diagram — HORN — (Cont'd)


RHD MODELS

EL-HORN-03



Refer to EL-POWER.

Refer to last page (Foldout page).





(M10), (E10)



HORN, CIGARETTE LIGHTER AND CLOCK

Wiring Diagram — HORN — (Cont'd)

EL-HORN-04



Refer to last page (Foldout page).

(M10), (E10)



System Description

The rear window and door mirror defogger system is controlled by the smart entrance control unit. Power is supplied at all times

- to rear window defogger relay terminal ③
- through 15A fuse (No. 181 located in the fuse block) and
- to rear window defogger relay terminal ⑥
- through 15A fuse (No. 117 located in the fuse block) and
- to mirror defogger relay terminal ③
- through 10A fuse (No. 121, located in the fuse block).

With the ignition switch in the ON or START position, power is supplied

- to each defogger relay terminal ① and
- to smart entrance control unit terminal 11

Ground is supplied

- to rear window defogger switch terminal ② and
- to smart entrance control unit terminal 10
- through body ground (M1) or (M67).

Operation

The ignition switch must be in the ON or START position for defogger operation.

With the rear window defogger switch in the ON position and for approximately 15 minutes after the rear window defogger switch has turned to OFF from ON, ground is supplied

- through terminal ① of the rear window defogger switch
- to smart entrance control unit terminal 20.

Terminal 19 of the smart entrance control unit then supplies ground to each defogger relay terminal ②

With power and ground supplied, each defogger relay is energized

For rear window defogger system, power is supplied

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to condenser terminal ①
- through terminal ② of the condenser
- to the rear window defogger terminal ①.

For mirror defogger system, power is supplied

- through mirror defogger relay terminal ⑤
- to each door mirror defogger terminal ①.

Ground is supplied

- to rear window defogger terminal ②
- through body ground (M104), and
- to each door mirror defogger terminal ③
- through body ground (M1) or (M67).

With power and ground supplied, each defogger filament heats and defogs the rear window and door mirror.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal ③ of the rear window defogger switch
- from terminal ⑤ of the rear window defogger relay

Terminal ④ of the rear window defogger switch is grounded through body ground (M1) or (M67)

GI

WA

RA

LI

ED

FR

CA

WT

RT

FD

EA

RA

DA

RT

RA

WT

WA





EL

LI

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER

Wiring Diagram — DEF —

EL-DEF-01







Refer to last page (Foldout page).

(M18)

REAR WINDOW DEFOGGER AND DOOR DEFROSTER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-02



Refer to last page (Foldout page).


(M11), (B1)

EL

Trouble Diagnoses

DIAGNOSTIC PROCEDURE 1


SYMPTOM: Rear defogger does not activate, or does not go off after activating.



A REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK
Measure voltage between control unit harness terminals ③⑥ and ⑩.

Condition	Voltage [V]
Rear defogger switch is "OFF"	Approx 12
Rear defogger switch is "ON"	0


- OK
- Check rear window defogger relay (Refer to EL-189.)
 - Check rear window defogger circuit
 - Check rear window defogger filament. (Refer to EL-189.)



B REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK
Check continuity between control unit harness terminal ②① and body ground.

Condition of defogger switch	Continuity
Rear defogger switch is pushed	Yes
Rear defogger switch is released.	No


- NG
- Check rear window defogger switch. (Refer to EL-189.)
 - Check continuity between control unit harness terminal ②① and rear window defogger switch harness terminal ①.
 - Continuity should exist.
 - Check continuity between rear window defogger switch harness terminal ② and body ground. Continuity should exist.



C IGNITION INPUT SIGNAL CHECK
Check voltage between control unit harness terminal ⑪ and body ground.

Condition	Voltage [V]
Ignition switch is "ON"	Approx 12
Ignition switch is "OFF"	0

- NG
- Repair harness or connectors



D CONTROL UNIT GROUND CIRCUIT CHECK
Check continuity between control unit harness terminal ⑩ and body ground. Continuity should exist.

- NG
- Repair harness or connectors.

OK

Replace control unit

REAR WINDOW DEFOGGER AND DOOR MIRROR DEFOGGER


Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Rear window defogger relay

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.

Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No




SEC202B

Rear window defogger switch

Check continuity between terminals when rear window defogger switch is pushed and released.


Terminals	Condition	Continuity
① - ②	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No



SEL430TA


Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.



SEL263

- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.



SEL122A

AUDIO AND POWER ANTENNA

Audio/System Description

Refer to Owner's Manual for audio system operating instructions

Power is supplied at all times

- through 7.5A fuse (No. 19), located in the fuse block
- to radio terminal ⑥

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 9), located in the fuse block
- to radio terminal ⑩

Ground is supplied through the case of the radio.

When the radio power knob is pushed to the ON position, audio signals are supplied



- through radio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the door, pillar and rear speakers.

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO —

EXCEPT CENTRAL AND SOUTH AMERICA

EL-AUDIO-01



Refer to last page (Foldout page).



(M1), (B1)

EL

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-02





AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)



FOR CENTRAL AND SOUTH AMERICA

EL-AUDIO-03



Refer to last page (Foldout page).

(M1), (B1)





EL

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-04



Audio


ANTI-THEFT SYSTEM

By using a personal 4-digit code known only to the vehicle owner, the possibility of the audio unit being stolen is effectively reduced, because without the code the unit can not be activated. When in normal use, the unit is unlocked and accessible in the usual way.

If however, someone attempts to remove the unit or the ground cable is disconnected from the battery, the Anti-theft system activates and the unit "locks". The only way it can be unlocked is by entering a personal code number known only by the owner

UNLOCKING THE UNIT (How to enter a personal code number)

Use the following procedures to enter a personal code number into the radio




1. Turn ignition switch to "ACC" or "ON".
2. Turn SW VOL knob to "ON" and "0000" will appear on the display.
3. Press any button (except "eject") and "0000" will appear on the display.
4. Enter a personal code number by pressing station select buttons 1, 2, 3, 4 the required number of times to display the code.
5. Press  to enter the code.

Unit is unlocked and the radio/cassette will operate.


If the wrong code number is entered, the display shows "----" Wait ten seconds then enter the correct code

CAUTION:

There is a theft prevention mechanism restricting the number of times a wrong code number can be entered into the radio unit. If a wrong code number is entered 1 to 2 times, you will have to wait for 10 seconds before the radio will receive further input. If a wrong code number is entered 3 to 20 times, you will have to wait a duration of 15 minutes. The radio unit will lock permanently if any further attempts are made.







Radio Fuse Check



AUDIO AND POWER ANTENNA

Power Antenna/Wiring Diagram — P/ANT —



EL-P/ANT-01



Refer to last page
(Foldout page).

(M11), (B1)


Location of Antenna



Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.




2. Withdraw antenna rod while raising it by operating antenna motor.

AUDIO AND POWER ANTENNA

Antenna Rod Replacement (Cont'd)

INSTALLATION



1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base



Window Antenna Repair

ELEMENT CHECK


1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.
2. If an element is broken, no continuity will exist



AUDIO AND POWER ANTENNA

Window Antenna Repair (Cont'd)

- To locate broken point, move probe to left and right along element. Tester needle will swing abruptly when probe passes the point.
- Refer to REAR WINDOW DEFOGGER "Filament Repair" for Element Repair.




HEATED SEAT

★ For location of heating unit, refer to "SEAT" in BT section.

Wiring Diagram — H/SEAT —

EL-H/SEAT-01






Refer to last page (Foldout page)

(M11) , (B1)

HEATED SEAT

Wiring Diagram — H/SEAT — (Cont'd)

EL-H/SEAT-02



EL

System Description

Power is supplied at all times

- through 25A fusible link (letter **1**), located in the fusible link and fuse box)
- to circuit breaker terminal **1**
- through circuit breaker terminal **2**
- to smart entrance control unit terminal **1**.

Power is supplied at all times

- to interior lamp terminal **1** and
- to key switch terminal **1**
- through 10A fuse (No. **21**), located in the fuse block).

Power is supplied at all times

- to multi-remote control relay-1 terminal **1**
- through 10A fuse (No. **22**), located in the fuse block).

Terminal **10** of the smart entrance control unit is grounded through body ground (**M1**).

INPUTS

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal **2**
- to smart entrance control unit terminal **24**.

When the driver side door switch is OPEN, ground is supplied

- to smart entrance control unit terminal **15**
- through driver side door switch terminal **1**
- to driver side door switch terminal **3**
- through body ground (**B2**) or (**R12**).

When the passenger side door switch is OPEN, ground is supplied

- to smart entrance control unit terminal **16**
- through passenger side door switch body ground.

When the driver side door lock actuator (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal **12**
- through driver side door lock actuator (door unlock sensor) terminal **4**
- to driver side door lock actuator (door unlock sensor) terminal **2**
- through body ground (**M1**).

When the passenger side door lock actuator (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal **13**
- through passenger side door lock actuator (door unlock sensor) terminal **4**
- to passenger side door lock actuator (door unlock sensor) terminal **2**
- through body ground (**M67**).

Remote controller signal input

- through window antenna
- to smart entrance control unit terminal **17**.

The multi-remote control system controls operation of the

- power door lock
- interior lamp
- panic alarm
- hazard warning lamp
- ID code entry

OPERATED PROCEDURE

Power door lock operation

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

smart entrance control unit locks all the doors with input of LOCK signal from remote controller.

When key switch is OFF (when ignition key is not inserted in key cylinder), smart entrance control unit unlocks the doors with input of UNLOCK signal from remote controller.

For details of current flow, refer to "POWER DOOR LOCK"

System Description (Cont'd)**Interior lamp operation**

When the following input signals are both supplied.

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller.

For detailed description, refer to "Interior, Spot and Trunk Room Lamps"

Panic alarm operation

When key switch is OFF (when ignition key is not inserted in key cylinder), multi-remote control system turns on and off horn and hazard warning lamp intermittently with input of PANIC ALARM signal from remote controller.

For detailed description, refer to "THEFT WARNING SYSTEM"

Hazard warning lamp operation

When the following input signals are all supplied

- key switch OFF (when ignition key is not inserted in key cylinder),
- door switch CLOSED (when all the doors are closed);
- door lock actuator (door unlock sensor) LOCKED (when all the doors are locked),

multi-remote control system outputs two times the following ground signals with input of LOCK signal from remote controller:







- to multi-remote control relay-1 terminal (2),
- through smart entrance control unit terminal (7)

As a result, multi-remote control relay-1 is energized, and hazard warning lamps flash on and off.

For detailed description, refer to "Turn Signal and Hazard Warning Lamps" and "THEFT WARNING SYSTEM"


MULTI-REMOTE CONTROL SYSTEM

Component Parts and Harness Connector Location



MULTI-REMOTE CONTROL SYSTEM

Schematic




GI
MA
EM
LC
FC
FE
CL
MT
AT
PD
FA
ZA
BR
ST
BS
BT
FA
EL
FOX

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI —

EL-MULTI-01



Refer to last page (Foldout page).


(M10) (E100)

(M18)

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-02



Refer to last page
(Foldout page).

M11, B1



M18

2F
WIA
EM
1G
EG
2F
G1
MT
AT
PD
2A
B5
2Y
2S
2T
HA
EL
FDX

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-03





Refer to last page (Foldout page).

(M18)

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-04



Refer to last page (Foldout page).

(M11), (B1)
(M18)

EL

MULTI-REMOTE CONTROL SYSTEM

Input/Output Operation Signal

SMART ENTRANCE CONTROL UNIT


Terminal No	Connections	Operated condition		Voltage (V) (Approximate values)
1	Power source (C/B)	—		12V
2	Passenger door lock motor	When door unlock signal is received from remote controller or unlock sensor	Unlocked	12V
3	Driver door lock motor		Free	1V or less
4	Passenger door lock motor	When door lock signal is received from remote controller or unlock sensor	Locked	12V
5	Driver's door lock motor		Free	1V or less
7	Multi-remote control relay 1	When doors are locked using remote controller or panic alarm is operated using remote controller		12V → 1V or less
8	Theft warning horn relay	When panic alarm is operated using remote controller		12V → 1V or less
9	Interior lamp	When doors are unlocked using remote controller. (Lamp switch in "DOOR" position)		12V → 1V or less
10	Ground	—		—
11	Ignition switch (ON)	"ON" or "START" position		12V
12	Driver door unlock sensor	Driver door. Locked → Unlocked		12V → 4.5V or less
13	Passenger door unlock sensor	Passenger door. Locked → Unlocked		12V → 4.5V or less
15	Driver door switch	OFF (Closed) → ON (Open)		12V → 4.5V or less
16	Passenger door switch	OFF (Closed) → ON (Open)		12V → 1.5V or less
17	Ignition switch (ACC)	"ACC" or "ON" position		12V
24	Ignition key switch (Insert)	IGN key inserted → IGN key removed from IGN key cylinder		12V → 4.5V or less
37	Multi-remote antenna	—		—

MULTI-REMOTE CONTROL SYSTEM


Trouble Diagnoses

TROUBLE SYMPTOM

- All functions of remote control system do not operate



- Some functions of multi-remote controller do not operate.




Note: The multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

Check remote controller battery.



A

CHECK REMOTE CONTROLLER BATTERY.

Remove battery and measure voltage across battery positive and negative terminals ⊕ and ⊖.


Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal ⊕	Battery negative terminal ⊖	3V or more

Note:

Remote controller does not function if battery is not set correctly.

DIAGNOSTIC PROCEDURE 2

SYMPTOM: All remote controls do not function even if remote controller is operated properly.



A

CHECK MAIN POWER SUPPLY AND GROUND CIRCUIT.


- 1) Remove key from ignition
- 2) Disconnect connector from control unit. Check voltage across control unit terminal ① and GND

Does battery voltage exist?

No

- Check the following.
- Fuse
 - Circuit breaker
 - Power supply harness

Yes



B


Check continuity between terminal ①B and GND

Does continuity exist?

No

Check GND harness

Yes



C

CHECK ANTENNA CIRCUIT.

Disconnect 1-pin connector from control unit

Check continuity between a terminal and filament on the rear window

Does continuity exist?



No

Check antenna circuit (Refer to REAR WINDOW DEFOGGER "Filament Repair")

Yes

(Go to next page)

Trouble Diagnoses (Cont'd)

**D****CHECK DOOR SWITCH CIRCUIT.**

- 1) Close all doors
 - 2) Connect control unit connector
 - 3) Check voltage across control unit terminal 15 and GND, 16 and GND.
- Does battery voltage exist?**

No

Replace smart entrance control unit

Yes

D

- 1) Open all doors.
 - 2) Check voltage across control unit terminal 15 and GND, 16 and GND.
- Is voltage approx. 0V?**

No

Check door switch circuit

Yes

E

- CHECK IGNITION SWITCH "ACC" CIRCUIT.**
- Disconnect connector from control unit. Check voltage across control unit terminal 17 and GND while ignition switch is "ACC".
- Does battery voltage exist?**

No

Check ignition switch "ACC" circuit.





Yes

Check operation parts in multi-remote control system for function

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Door lock or unlock on remote control does not function.



A

CHECK UNLOCK SENSOR CIRCUIT
Check voltage across control unit terminal ② and GND, ④ and GND

Door lock knob condition	Terminals	Voltage (V)
Locked →	② - GND	12 - 0
	④ - GND	→ 12
Unlocked →	② - GND	
	④ - GND	

C

CHECK DOOR LOCK ACTUATOR CIRCUIT.
Check voltage for door lock motor Door lock actuator driver side.

Door lock knob condition	Terminals	
	⊕	⊖
Locked	⑤	③
Unlocked	③	⑤

Door lock actuator passenger side

Door lock knob condition	Terminals	
	⊕	⊖
Locked	④	②
Unlocked	②	④

Does battery voltage exist?

D

1) Disconnect control unit connector and door lock actuator connector
2) Check continuity

	Terminals
Driver side	⑤ - ③
	④ - ②
Passenger side	④ - ②
	② - ④

Does continuity exist?

Check power door lock motor. Refer to ELECTRICAL COMPONENTS INSPECTION in "POWER DOOR LOCK" (EL-174)

E

1) Disconnect connector from control unit
2) Check continuity between ② and GND, ④ and GND

Door lock knob condition	Terminals
Unlocked	② - GND
	④ - GND

Does continuity exist?

No → Repair unlock sensor harness or replace door lock actuator

Yes → Replace smart entrance control unit

No → Replace smart entrance control unit









No → Repair harness

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)






DIAGNOSTIC PROCEDURE 4

SYMPTOM: Hazard warning lamps do not flash twice when pressing lock button of remote controller. Everything else functions.




MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 5

SYMPTOM: Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller. Everything else functions.



Replacing Remote Controller or Control Unit

If the remote controller or the control unit needs to be replaced or if an additional remote controller needs to be set, enter the identity (ID) code manually.

ID Code Entry Procedure

To enter the ID code, follow this procedure.

"Setting mode":

Three steps must be followed to establish the "setting mode".

- (1) Close and lock all doors.
- (2) Insert and remove the key from the ignition more than six times within 10 seconds. (The hazard warning lamp will then flash twice.)

● **At this time, the original ID codes are eliminated.**

ID code entry:

- (3) Turn ignition key to "ACC" position.
- (4) Push lock button on the new remote controller once (for example, if door is locked using the remote controller during this ID code entry enable state, a new ID code can be entered)

● **At this time, the new ID code is entered. (The hazard warning lamp will then flash twice.)**

- (5) If you need to enter additional remote controllers (including the original), release the driver's door lock, then lock again with door lock knob.
- (6) Push lock button on the new additional remote controller once.
- (7) This ID code entry enable state and setting mode remain until the driver's door is opened.

NOTE

- If the same ID code that existing in the memory is input, the entry is canceled, and no ID code will be entered.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.
- Any ID codes entered after termination of the "setting" mode will not be accepted. Additionally remote control signals will be inhibited when an ID code has not been entered during the "setting" mode.

THEFT WARNING SYSTEM

System Description

Refer to Owner's Manual for theft warning system operating instructions.

Power is supplied at all times

- through 30A fusible link (letter [h]), located in the fusible link and fuse box)
- to ignition switch terminal (1).

With the ignition switch in the START position, power is supplied

- from terminal (5) of the ignition switch
- to theft warning relay terminal (3)

Power is supplied at all times

- through 7.5A fuse (No. [19]), located in the fuse block)
- to security indicator lamp terminal (2).

Power is supplied at all times

- through 25A fusible link (letter [f]), located in the fusible link and fuse box)
- to circuit breaker terminal (1)
- through circuit breaker terminal (2)

- to smart entrance control unit terminal (1)

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. [9]), located in the fuse block)
- to smart entrance control unit terminal (17)

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. [26]), located in the fuse block)
- to smart entrance control unit terminal (11) and
- to theft warning relay terminal (1).

Ground is supplied

- to smart entrance control unit terminal (10)
- through body ground (M1)

THEFT WARNING SYSTEM ACTIVATION (Without key or remote controller used to lock doors)

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, the ignition switch must be in the OFF position and the smart entrance control unit must receive signals indicating the doors, hood and trunk are closed and the doors are locked

When a door is open, smart entrance control unit terminal (15) or (16) receives a ground signal from driver side or passenger side door switch.

When a door is unlocked, smart entrance control unit terminal (12) or (13) receives a ground signal

- from terminal (4) of the driver side door unlock sensor
- from terminal (4) of the passenger side door unlock sensor
- through body grounds (M1) or (M67) for the doors.

When the hood is open, smart entrance control unit terminal (25) receives a ground signal

- from terminal (2) of the hood switch
- through body ground (E43).

When the trunk lid is open, smart entrance control unit terminal (26) receives a ground signal

- from terminal (1) of the trunk room lamp switch
- through body ground (T15).

If none of the described conditions exist, the theft warning system will activate automatically

THEFT WARNING SYSTEM ACTIVATION (With key or remote controller used to lock doors)

If the key or remote controller is used to lock doors, terminal (40) receives a ground signal

- from terminal (2) of the driver side key cylinder switch and
- from terminal (1) of the passenger side door key cylinder switch
- through body grounds (M1) and (M67).

If this signal is received by the smart entrance control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, smart entrance control unit terminal (31) supplies ground to terminal (1) of the security indicator lamp

The security lamp will illuminate for approximately 30 seconds and then go on and off

System Description (Cont'd)**THEFT WARNING SYSTEM OPERATION**

The theft warning system is triggered by

- opening a door or the trunk lid without using the key
- opening the hood
- tampering with the key cylinder in the door

Once the theft warning system has been activated, if the smart entrance control unit receives a ground signal at terminal 15, 16, 26 or 29 (as described under THEFT WARNING SYSTEM ACTIVATION), the theft warning system will be triggered. Also, when a door key tamper signal is received at the smart entrance control unit, the system will be triggered. The hazard warning lamps flash and the horns sound intermittently, and the starting system is interrupted.

When a door key cylinder switch has been tampered with, smart entrance control unit terminal 28 receives a ground signal

- from terminal 13 of each door's key cylinder switch
 - through body ground (M) or (M7)
- if the theft warning system is triggered, ground is supplied

- from terminal 42 of the smart entrance control unit
- to theft warning relay terminal 2.

With power and ground supplied, power to the inhibitor switch (A/T models) or starter motor (M/T models) is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 7.5A fuse (No. 43), located in the fusible link and fuse box)
- to theft warning horn relay terminals 1 and 6.

Power is supplied at all times

- through 10A fuse (No. 39), located in the fusible link and fuse box)
- to theft warning horn relay terminal 3.

Power is supplied at all times

- through 10A fuse (No. 22), located in the fuse block)
- to multi-remote control relay-1 terminals 1, 3 and 6.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal 6 of the smart entrance control unit
- to theft warning horn relay terminal 2 and
- to multi-remote control relay-1 terminal 2.

The hazard warning lamps flash and the horns sound intermittently

The alarm automatically turns off after approximately 30 seconds but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key or remote controller.

When the key or remote controller is used to unlock a door, smart entrance control unit terminal 11 receives a ground signal

- from terminal 7 of the driver side door key cylinder switch
- from terminal 2 of the passenger side door key cylinder switch

When the key is used to unlock the trunk lid, smart entrance control unit terminal 27 receives a ground signal from terminal 1 of the trunk key cylinder switch.

When the smart entrance control unit receives either one of these signals, the theft warning system is deactivated

PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horns and hazard warning lamps) as required

When the multi-remote control system is triggered, ground is supplied intermittently.

- from smart entrance control unit terminal 4
- to theft warning horn relay terminal 2 and
- from smart entrance control unit terminal 7
- to multi-remote control relay-1 terminal 2.








THEFT WARNING SYSTEM

System Description (Cont'd)

The hazard warning lamps flash and the horns sound intermittently. The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

THEFT WARNING SYSTEM

Component Parts and Harness Connector Location




GI
WA
PW
LG
EG
FR
GI
WT
AT
ED
FA
HA
FR
ST
RS
ST
HA
EL
HX

SEL856T

THEFT WARNING SYSTEM



Schematic



THEFT WARNING SYSTEM

Wiring Diagram — THEFT —

EL-THEFT-01



Refer to last page (Foldout page).

- M10, E101
- M11, B1
- M18



EL

SEL775T

THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-02





Refer to last page (Foldout page).

(M11), (B1)
(M18)

THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-03



(D1)

(D101)



(D2)



(D1)

(D11)

Refer to last page (Foldout page).



(M18)

EL

THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-04






Refer to last page
(Foldout page).

- (M10), (E10)
- (M11), (B1)
- (M18)

THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-05



Refer to last page
(Foldout page).

(M10), (E101)

(M11), (B1)



(M60), (F4)

EL

THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-06



Refer to last page (Foldout page).

(M10), **(E101)**

(M18)

THEFT WARNING SYSTEM

Input/Output Operation Signal

SMART ENTRANCE CONTROL UNIT

Terminal No	Connections	Operated condition	Voltage (V) (Approximate values)
1	Power source (C/B)	—	12V
7	Multi-remote control relays 1 and 2	When panic alarm is operated	12V · 1V or less
8	Theft warning horn relay	When panic alarm is operated.	12V · 1V or less
10	Ground	—	—
11	Ignition switch (ON)	"ON" or "START" position	12V
12	Driver door unlock sensor	Driver door: Locked → Unlocked	12V · 4.5V or less
13	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V · 4.5V or less
15	Driver door switch	OFF (Closed) → ON (Open)	12V · 4.5V or less
16	Passenger door switch	OFF (Closed) → ON (Open)	12V · 1.5V or less
17	Ignition switch (ACC)	"ACC" or "ON" position	12V
26	Trunk room lamp switch	ON (Open) → OFF (Closed)	0V · 12V
27	Trunk key cylinder switch	OFF (Neutral) · ON (Unlocked)	4.5V or more · 0V
28	Door key cylinders tamper switch	OFF → ON	4.5V or more · 0V
29	Hood switch	ON (Open) · OFF (Closed)	0V · 4.5V or more
30	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	4.5V or more · 0V
31	Door key cylinder unlock switch	OFF (Neutral) → ON (Unlocked)	4.5V or more · 0V
32	Theft warning relay (Starter cut)	OFF → ON	12V · 0V
33	Security indicator	Goes off → Illuminates	12V · 0V


Trouble Diagnoses

SYSTEM OPERATION CHECK

The system operation is canceled by turning ignition switch to "ACC" at any step in the following:

- A step between START and ARMED, or
- In the ARMED phase

in the following flow chart.



(Go to next page)

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)



EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply circuit check

Terminals	Ignition switch position		
	OFF	ACC	ON
(1) - (10)	Battery voltage	Battery voltage	Battery voltage

SEL361TA

Power supply circuit check for system cancel

Terminals	Ignition switch position		
	OFF	ACC	ON
(1) - (10)	0V	Battery voltage	Battery voltage


SEL362TA

Ground circuit check


Terminals	Continuity
(10) - Ground	Yes

SEL363TA


Smart entrance control unit connector (M18)



Smart entrance control unit connector (M18)



Smart entrance control unit connector (M18)



EL

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

- SYMPTOM:**
- Indicator lamp does not blink or
 - Indicator lamp remains blinking every second.
- Diagnostic procedure 1-(1)**

A

DOOR SWITCH INPUT SIGNAL CHECK
Check continuity between control unit harness terminals (15) or (16) and (10)

Condition	Continuity between (15) and (10)
Driver side door is closed	No
Driver side door is opened	Yes

Condition	Continuity between (16) and (10)
Passenger side door is closed	No
Passenger side door is opened	Yes

NG

DOOR SWITCH CHECK
Refer to "Electrical Components Inspection" (EL-245)

NG

Replace door switch

OK

B

DOOR SWITCH CIRCUIT CHECK

- Check harness continuity between control unit harness terminal (15) or (16) and door switch harness terminal (3) and body ground.
 - Check harness continuity between driver side door switch harness terminal (3) and body ground.
- Continuity should exist.**

NG

Repair harness or connectors

OK

C




Check harness continuity between door switch harness terminal and body ground.
(Before checking harness continuity, control unit harness connector should be disconnected.)
Continuity should not exist.

NG

Repair harness
(Short circuit exists between control unit harness terminal (15) or (16) and door switch harness terminals)

OK





CHECK THE CONNECTIONS AT EACH CONNECTOR



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)





Diagnostic procedure 1-(2)







THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(3)






Condition	Voltage
Trunk lid is open.	Approx 0V
Trunk lid is closed.	Approx 12V



THEFT WARNING SYSTEM







Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)








THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 2

SYMPTOM: ● Indicator lamp does not blink or
● Indicator lamp remains "ON".






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Indicator lamp does not come on.



A

DOOR UNLOCK SENSOR INPUT SIGNAL CHECK

Check continuity between control unit harness terminals (12) or (13) and (10).

Condition	Continuity between (12) and (10)
Driver side door is locked	No
Driver side door is unlocked	Yes

Condition	Continuity between (13) and (10)
Passenger side door is locked.	No
Passenger side door is unlocked.	Yes

OK → Go to Diagnostic Procedure 2 (EL-238)

OK ↓

Replace control unit

NG ↓

DOOR UNLOCK SENSOR CHECK
Refer to "Electrical Components Inspection" (EL-247).

NG → Replace door lock actuator.

OK ↓

B

DOOR UNLOCK SENSOR CIRCUIT CHECK

- Check harness continuity between control unit harness terminal (12) or (13) and door actuator terminal (14)
 - Check harness continuity between door lock actuator harness terminal (2) and body ground.
- Continuity should exist.**

NG → Repair harness or connectors

OK ↓

C

Check harness continuity between door lock actuator harness terminal (4) and body ground.
(Before checking harness continuity, control unit harness connector should be disconnected)
Continuity should not exist.

NG → Repair harness (Short circuit exists between control unit harness terminal (12) or (13) and door lock actuator harness terminal (4))

OK ↓








CHECK THE CONNECTIONS AT EACH CONNECTOR

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Indicator lamp does not come on.





OK → CHECK THE CONNECTIONS AT EACH CONNECTOR

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 5

SYMPTOM: Alarm does not operate.



CHECK THE FOLLOWING

- Harness continuity between control unit harness terminal (8) and theft warning horn relay harness terminal (2)
- Harness continuity between fuse and theft warning horn relay harness terminal (1)
- Harness continuity between control unit harness terminal (8) and horn relay harness terminal (1)
- Harness continuity between fuse and horn relay harness terminal (2)
- Theft warning horn relay. Refer to "Electrical Components Inspection" (EL-248).



ALARM SIGNAL INPUT CHECK

- Door switch circuit Refer to Diagnostic Procedure 1-(1) (EL-234)
- Hood switch circuit Refer to Diagnostic Procedure 1-(2) (EL-235).
- Trunk room lamp switch circuit Refer to Diagnostic Procedure 1-(3) (EL-236)
- Key cylinder tamper switch circuit Refer to Diagnostic Procedure 1-(4) (EL-237).
- Door unlock sensor circuit Refer to Diagnostic Procedure 3 (EL-239).

OK →

NG → Repair harness or connectors

HORN CHECK
Refer to "Electrical Components Inspection" (EL-247)

OK →

NG → Replace horn

THEFT WARNING HORN RELAY CHECK
Refer to "Electrical Components Inspection" (EL-248)

OK →

NG → Replace relay

OK →

NG →

OK →









NG →

(A)
(Next page)

GA
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
BA
BR
ST
RS
BT
EA
EL
FOX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM:

- **STARTER MOTOR** can be operated. (Starter killed phase) or
- **STARTER MOTOR** cannot be operated after the theft warning system is deactivated.



A

STARTER MOTOR KILL OUTPUT SIGNAL CHECK
Check voltage between control unit harness terminals ⑫ and ⑩

Condition	Voltage
Except starter killed phase	Approx. 12V
Starter killed phase	0V

CHECK THE FOLLOWING.

- Harness continuity between control unit harness terminal ⑫ and theft warning relay harness terminal ②
- Harness continuity between theft warning relay harness terminal ① and fuse
- Theft warning relay
Refer to "Electrical Components Inspection" (EL-248)

THEFT WARNING RELAY CHECK
Refer to "Electrical Components Inspection" (EL-248)

Replace control unit.

Replace relay

CHECK THE CONNECTIONS AT EACH CONNECTOR.

Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 7

SYMPTOM: Alarm does not stop even if stop signal is given.

A

DOOR UNLOCK SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL)

Check continuity between control unit harness terminals ⑪ and ⑫.

Key position	Continuity
Neutral/Unlock	No
Between neutral and unlock	Yes

OK

ALARM OUTPUT SIGNAL CHECK
Go to Diagnostic Procedure 5. (EL-241).

NG

DOOR UNLOCK SWITCH CHECK

Refer to "Electrical Components Inspection" (EL-247).

NG

Replace key cylinder switch.

OK

B

DOOR UNLOCK SWITCH CIRCUIT CHECK

- Check harness continuity between control unit harness terminal ⑪ and door key cylinder switch terminal.
- Check harness continuity between door key cylinder switch terminal and body ground.

Continuity should exist.

NG

Repair harness or connectors.

OK

C

Check harness continuity between door key cylinder switch terminal and body ground.

(Before checking harness continuity, control unit harness connector should be disconnected.)




Continuity should not exist.

NG

Repair harness.
(Short circuit exists between control unit harness terminal ⑪ and door key cylinder switch terminal.)

OK

CHECK THE CONNECTIONS AT EACH CONNECTOR.







THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: Alarm does not stop even if stop signal is given.



THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches

Check continuity between terminals when door switch is pushed and released.


Terminal No.	Condition	Continuity
Driver side: ① - ③	Door switch is pushed	No
	Door switch is released.	Yes
Passenger side: ① - body ground	Door switch is released.	Yes



Hood switch

Check continuity between terminals when hood switch is pushed and released.


Terminal No.	Condition	Continuity
① - ②	Hood switch is pushed	No
	Hood switch is released	Yes



Trunk room lamp switch

Check continuity between terminals when trunk lid is closed and opened.

Terminal No.	Condition	Continuity
① - ②	Trunk lid is closed.	No
	Trunk lid is opened.	Yes



Trouble Diagnoses (Cont'd)


Key cylinder tamper switch, door lock switch and door unlock switch

● Door key cylinder switch

Door key cylinder switch connector

Driver side (G11)

Passenger side (G111)




- ① Door lock switch terminal (Passenger side)
- ② Door unlock switch terminal (Driver side)
- ③ Door lock switch terminal (Passenger side)
- ④ Door lock switch terminal (Driver side)
- ⑤ Key cylinder tamper switch terminal
- ⑥ Ground terminal

SEL399TA

	Terminal No.	Condition	Continuity
Tamper switch	③ - ④	Key cylinder is installed	No
		Key cylinder is removed	Yes
Door lock switch	Driver side: ② - ④ Passenger side: ① - ④	Key position is neutral or lock.	No
		Key position is between neutral and lock.	Yes
Door unlock switch	Driver side ① - ③ Passenger side ② - ④	Key position is neutral or unlock	No
		Key position is between neutral and unlock.	Yes

● Trunk key cylinder switch (unlock switch)

Trunk key cylinder switch (T8)




SEL907T

Terminal No.	Condition	Continuity
① - ②	Key position is neutral	No
	Key position is unlock	Yes

● Door lock actuator (Door unlock sensor)

Door lock actuator connectors

Driver side (D12), Passenger side (D112)



SEL401TA


Terminal No.	Condition	Continuity
④ - ②	Door is locked	No
	Door is unlocked.	Yes

Horns

Supply horn terminal with battery voltage and check horn operation.

Horn connectors

(E11) (E1) (E4)




SEL402TA

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Theft warning horn relay and multi-remote control relay-1


Check continuity between terminals ③ and ⑤, ⑥ and ⑦.



Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

Theft warning relay



Check continuity between terminals ③ and ④



Condition	Continuity
12V direct current supply between terminals ① and ②	No
No current supply	Yes

LOCATION OF ELECTRICAL UNIT

Engine Compartment




GI
MA
EM
LC
EC
PE
CL
MY
AT
PD
FA
PA
BR
ST
RS
ST
FA
EL
FOX

LOCATION OF ELECTRICAL UNIT

Passenger Compartment


LHD MODELS



LOCATION OF ELECTRICAL UNIT

Passenger Compartment (Cont'd)

RHD MODELS



EL
WA
SM
LC
EC
FE
CL
MT
AT
PD
FA
BA
FR
ST
HS
ST
HA


EL

(BX)

SEL863T

LOCATION OF ELECTRICAL UNIT


Trunk Compartment



HARNES LAYOUT

LHD MODELS


Outline



SEL865T

GA
MA
EM
LC
EC
FE
CL
MT
AT
PT

RHD MODELS




SEL866T

FA
RA
BR
ST
RC
BT
HA
EL
DX

HARNESS LAYOUT

Main Harness

LHD MODELS



HARNESS LAYOUT

Main Harness (Cont'd)


B5	(M1)	Body ground	E2	(M19)	Thermo control amplifier
B5	(M2)	Rear wiper amplifier	F2	(M51)	To (M10)
A5	(M3)	Fuel pump relay	E4	(M52)	Fan resistor
A5	(M4)	Power window relay	F3	(M13)	Blower motor
A5	(M5)	Rear fog lamp relay (Models without daytime light system)	G1	(M54)	Pillar speaker RH
A5	(M6)	Rear fog lamp relay (Models with daytime light system)	F1	(M55)	To (R1)
B4	(M7)	Fuse block	G2	(M56)	To (D29)
B4	(M8)	Data link connector for CONSULT	G2	(M57)	To (D29)
B4	(M9)	Rear window defogger relay	F3	(M68)	Joint connector
A3	(M10)	To (E10) (SMJ)	G4	(M69)	To (F4)
A3	(M11)	To (E11) (SMJ)	F4	(M69)	To (F7) (A/T models)
B3	(M12)	To (E12)	F4	(M63)	To (E51)
B3	(M13)	Circuit breaker	F4	(M65)	To (E8) (M/T models)
A3	(M14)	To (D1)	F3	(M66)	Mirror defogger relay
A3	(M15)	To (D2)	G3	(M67)	Body ground
B2	(M17)	Pillar speaker LH	F3	(M109)	To (M51)
B3	(M18)	Smart entrance control unit	G3	(M109)	Glove box lamp
C1	(M19)	Kickdown switch (A/T models)	G3	(M113)	Glove box lamp switch
C1	(M20)	Combination meter			
B3	(M21)	Illumination control switch			
B3	(M22)	A/T control unit (A/T models)			
C3	(M23)	Combination flasher unit			
C4	(M24)	Buzzer			
C3	(M25)	Stop lamp switch			
D3	(M27)	Air mix door motor			
D4	(M28)	Moose door motor			
E3	(M29)	Bi-level door motor			
E3	(M30)	To (E5)			
D2	(M32)	Push control unit			
D2	(M33)	Fan switch			
E3	(M34)	Hazard switch			
E3	(M36)	Headlamp washer switch			
D3	(M37)	Rear window defogger switch			
D3	(M38)	Rear fog lamp switch			
E4	(M40)	Radio			
E4	(M41)	Not used			
E4	(M42)	Cigarette lighter			
D2	(M45)	Joint connector			
E1	(M47)	Not used			
E2	(M48)	Intake door motor			

EL

HARNESS LAYOUT

Main Harness (Cont'd)

RHD MODELS




HARNES LAYOUT

Main Harness (Cont'd)

- F5 (M1) : Body ground
- G5 (M2) : Rear wiper amplifier (Except for Australia)
- G5 (M3) : Fuel pump relay
- G5 (M4) : Power window relay
- F5 (M5) : Rear fog lamp relay (For Europe)
- F4 (M7) : Fuse block
- F4 (M8) : Data link connector for CONSULT
- F4 (M9) : Rear window defogger relay
- F3 (M10) : To (E10) (SMU)
- F3 (E11) : To (B1) (SMU)
- F3 (M13) : Circuit breaker
- G3 (M14) : To (D1)
- G3 (M15) : To (D2)
- G2 (M18) : To (B1)
- F2 (M17) : Pillar speaker RH
- F4 (M18) : Smart entrance control unit
- F3 (M19) : Kickdown switch (A/T models)
- E3 (M20) : Combination meter
- E3 (M21) : Illumination control switch
- E3 (M22) : A/T control unit (A/T models)
- E3 (M23) : Combination flasher unit
- E4 (M24) : Buzzer
- E4 (M25) : Stop lamp switch
- D2 (M26) : In-vehicle sensor (Auto A/C)
- D3 (M27) : Air mix door motor
- D3 (M28) : Mode door motor
- C3 (M29) : Bi-level door motor
- B4 (M30) : To (Z3)
- D2 (M31) : Auto A/C unit (Auto A/C)
- C2 (M32) : Push control unit (Except auto A/C)
- C2 (M33) : Fan switch (Except auto A/C)
- D4 (M34) : Hazard switch (For Europe)
- C3 (M35) : Hazard switch (Except for Europe)
- D4 (M36) : Headlamp washer switch (For Europe)
- C3 (M37) : Rear window defogger switch
- C3 (M38) : Rear fog lamp switch (For Europe)
- D4 (M39) : Security indicator (Except for Europe)
- C4 (M40) : Radio
- C4 (M41) : Not used
- C4 (M42) : Cigarette lighter

- C4 (M43) : Diode (Except for Europe)
- C3 (M44) : Diode (Except for Europe)
- C2 (M45) : Joint connector
- B1 (M46) : Sunload sensor (Auto A/C)
- B1 (M47) : Not used (For Europe)
- C2 (M48) : Intake door motor
- C2 (M49) : Thermo control amplifier
- C2 (M50) : Fan control amplifier (Auto A/C)
- B2 (M51) : To (M18) (Except for Australia)
- B3 (M52) : Fan resistor (Except auto A/C)
- C3 (M53) : Blower motor
- A1 (M54) : Pillar speaker LH
- A2 (M55) : To (M18)
- A2 (M57) : To (M29)
- B4 (M58) : Joint connector (For Europe)
- B4 (M60) : To (E4)
- B4 (M62) : To (T1) (A/T models)
- B4 (M63) : To (E5) (Models with ABS)
- A3 (M65) : Mirror dip/ogger relay (Except for Australia)
- A4 (M67) : Body ground


- B2 (M10) : To (M21)
- A3 (M12) : Glove box lamp
- A3 (M13) : Glove box lamp switch (Except for Australia)



HARNES LAYOUT

Engine Room Harness

ENGINE COMPARTMENT (LHD models)



HARNESS LAYOUT


Engine Room Harness (Cont'd)

- (E1) : Cooling fan relay-2
- (E2) : Fusible link and fuse block-1
- (E3) : Cooling fan relay-1
- (E4) : Air conditioner relay
- (E5) : Horn relay
- (E6) : Front fog lamp relay
- (E7) : Fusible link and fuse block-2
- (E8) : Fusible link and fuse block-3
- (E9) : Brake fluid level switch
- (E10) : Side turn signal lamp LH
- (E11) : Power transistor unit
- (E12) : Wastegate valve control solenoid valve
- (E13) : Compressor
- (E14) : Power steering oil pressure switch
- (E15) : Dropping resistor (A/T models)
- (E16) : Check connector
- (E17) : Front wheel sensor LH (For ABS)
- (E18) : Boost pressure sensor
- (E19) : Inhibitor switch (A/T models)
- (E20) : Revolution sensor (A/T models)
- (E21) : To terminal code assembly (A/T models)
- (E22) : To (E20)
- (E23) : To (E20)
- (E24) : Battery
- (E25) : Washer fluid level switch
- (E26) : Headlamp washer motor
- (E27) : Front washer motor
- (E28) : Rear washer motor
- (E29) : Daytime light unit
- (E30) : Headlamps washer amplifier
- (E31) : Clearance lamp RH
- (E32) : Headlamp RH outer
- (E33) : Headlamp aiming motor RH
- (E34) : Headlamps RH inner
- (E35) : Front fog lamp RH
- (E36) : Front turn signal lamp RH
- (E37) : Body ground
- (E38) : Cooling fan motor
- (E39) : Horn (High)


Fusible link and fuse box

- (E40) : Horn (Low)
- (E41) : Front turn signal lamp LH
- (E42) : Front fog lamp LH
- (E43) : Headlamp LH inner
- (E44) : Headlamp aiming motor LH
- (E45) : Headlamp LH outer
- (E46) : Clearance lamp LH
- (E47) : To (E20)
- (E48) : Body ground
- (E49) : Ambient sensor (For outside temperature)

Fusible link and fuse box




Dropping resistor (E13)



HARNESS LAYOUT

Engine Room Harness (Cont'd)

ENGINE COMPARTMENT (RHD models)




HARNESS LAYOUT

Engine Room Harness (Cont'd)

- (E1) : Cooling fan relay-2 (Except for Europe)
- (E2) : Fusible link and fuse block-1
- (E3) : Cooling fan relay-1
- (E4) : Theft warning relay (Except for Europe)
- (E5) : Air conditioner relay
- (E6) : Horn relay
- (E7) : Theft warning horn relay (Except for Europe)
- Front fog lamp relay (For Europe)
- (E8) : Fusible link and fuse block-2
- (E9) : Fusible link and fuse block-3
- (E10) : Brake fluid level switch
- (E11) : Theft warning horn (Except for Europe)
- (E12) : Front wheel sensor RH (For ABS)
- (E13) : Side turn signal lamp RH
- (E14) : Boost pressure sensor
- (E15) : Inhibitor switch (A/T models)
- (E16) : Revolution sensor (A/T models)
- (E17) : To terminal code assembly (A/T models)
- (E18) : To (E20)
- (E19) : To (E20)
- (E20) : To (E23)
- (E21) : Battery
- (E22) : Hood switch (Except for Europe)
- (E23) : Washer fluid level switch
- (E24) : Headlamp washer motor (For Europe)
- (E25) : Front washer motor
- (E26) : Rear washer motor (Except for Australia)
- (E27) : Headlamp washer amplifier (For Europe)
- (E28) : Clearance lamp RH
- (E29) : Headlamp RH outer
- (E30) : Headlamp aiming motor RH (For Europe)
- (E31) : Headlamp RH inner
- (E32) : Front fog lamp RH
- (E33) : Front turn signal lamp RH
- (E34) : Body ground
- (E35) : Cooling fan motor (Except for Europe)
- (E36) : Cooling fan motor (For Europe)
- (E37) : Ambient sensor (For auto A/C)
- (E38) : Horn (High)
- (E39) : Horn (Low)

- (E40) : Front turn signal lamp LH
- (E41) : Front fog lamp LH
- (E42) : Headlamp LH inner
- (E43) : Headlamp aiming motor LH (For Europe)
- (E44) : Headlamp LH outer
- (E45) : Clearance lamp LH
- (E46) : Triple-pressure switch
- (E47) : To (E20)
- (E48) : Body ground
- (E49) : Ambient sensor (For outside temperature)

(Fusible link and fuse box)



EL


IDX

CI
WA
EM
LC
FC
FE
CL
MT
AT
PD
FA
AA
BR
ST
RS
ST
FA



HARNESS LAYOUT

Engine Room Harness (Cont'd)

PASSENGER COMPARTMENT (LHD models)




- (E10) : To (M11) (SMU)
- (E12) : To (M12)
- (E107) : Resistor
- (E108) : Diode
- (E109) : Fuse block
- (E107) : Ignition switch
- (E109) : Lighting switch
- (E110) : Turn signal switch
- (E112) : Front wiper and washer switch
- (E113) : Rear wiper and washer switch
- (E114) : Rear fog lamp switch
- (E115) : Horn switch



HARNESS LAYOUT

Engine Room Harness (Cont'd)

PASSENGER COMPARTMENT (RHD models)




AL
WA
EM
LC
AC
RM
CL
MT
AT
PD
FA
FA
SP
ST
ZS
SK
MA
EL
TV

HARNESS LAYOUT

Engine Control Harness

LHD MODELS



HARNES LAYOUT

Engine Control Harness (Cont'd)

E2 (E1) : ECM (ECSS control module)
 D1 (E2) : ECSS relay
 D1 (E3) : Ignition coil relay
 D1 (E4) : To (M52)
 E1 (E5) : To (B53)
 D1 (E7) : To (M52) (A/T models)
 D1 (E8) : To (M52) (M/T models)
 C1 (E10) : Front wiper motor
 B2 (E11) : Front wiper amplifier
 C1 (E13) : Side turn signal lamp RH
 B1 (E14) : ABS actuator
 B3 (E20) : To (E36)
 D4 (E22) : Mass air flow sensor
 E3 (E24) : To (E10)
 F3 (E25) : Heated oxygen sensor
 E2 (E26) : Engine ground
 E2 (E27) : To (E11)
 D2 (E28) : To (E22)
 E2 (E29) : IACV-FICD solenoid valve
 D2 (E30) : IACV-AAC valve
 D3 (E31) : VTC solenoid valve
 D4 (E32) : Camshaft position sensor
 B3 (E33) : Throttle position sensor (Brown)
 B3 (E34) : Throttle position switch (Gray) (A/T models)
 B1 (E35) : Front wheel sensor RH (For ABS)
 C2 (E36) : Triple-pressure switch
 E2 (E37) : Engine ground


Sub-harness
 F3 (F10) : To (F24)
 F3 (F09) : Engine ground
 E3 (F13) : Ignition coil No.4
 E3 (F14) : Ignition coil No.3
 E3 (F15) : Ignition coil No.2
 D3 (F16) : Ignition coil No.1
 E2 (F17) : To (E27)
 D3 (F18) : Injector No.4
 C3 (F19) : Injector No.3
 C3 (F14) : Injector No.2
 C3 (F15) : Injector No.1
 C4 (F16) : Engine coolant temperature sensor
 C4 (F17) : Thermal transmitter
 D2 (F18) : To (F24)
 D3 (F19) : Knock sensor

GI
 WA
 EM
 LC
 EC
 SE
 GI
 MY
 AT
 PR
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 MX

HARNESS LAYOUT

Engine Control Harness (Cont'd)



RHD MODELS



- F3 (E1) : ECM (ECSS control module)
- G4 (E2) : ECCS relay
- G3 (E3) : Ignition coil relay
- G3 (E4) : To (M6)
- G3 (E5) : To (E5) (Model with ABS)
- G4 (E7) : To (M2) (A/T models)
- F4 (E9) : Resistor
- F2 (E10) : Front wiper motor
- F3 (E11) : Front wiper amplifier
- F4 (E12) : Side turn signal lamp LH
- E3 (E14) : ABS actuator (For ABS)
- E4 (E15) : Front wheel sensor LH (For ABS)
- D3 (E16) : Power transistor unit
- D3 (E17) : Wastegate valve control solenoid valve
- D4 (E18) : Check connector
- D4 (E19) : Dropping resistor (A/T models)
- C4 (E20) : To (E56)
- C3 (E7) : Compressor
- C3 (E22) : Mass air flow sensor
- D3 (E23) : Power steering oil pressure switch
- D3 (E24) : To (E10)
- D3 (E25) : Heated oxygen sensor
- C1 (E27) : Engine ground
- C1 (E28) : To (E11)
- B2 (E29) : To (E28)
- B2 (E30) : IACV-FICD solenoid valve
- B2 (E32) : IACV-AAC valve
- B3 (E33) : VTC solenoid valve
- C4 (E34) : Camshaft position sensor
- A2 (E35) : Throttle position sensor (Brown)
- A3 (E34) : Throttle position switch (Gray) (A/T models)
- C1 (E37) : Engine ground

Sub-harness



- D2 (E10) : To (E24)
- D2 (E102) : Engine ground
- C3 (E103) : Ignition coil No.4
- C3 (E104) : Ignition coil No.3
- C3 (E105) : Ignition coil No.2
- C3 (E106) : Ignition coil No.1
- D2 (E110) : To (E27)
- B2 (E112) : Injector No.4
- B2 (E113) : Injector No.3
- B2 (E114) : Injector No.2
- A2 (E115) : Injector No.1
- A3 (E116) : Engine coolant temperature sensor
- B3 (E117) : Thermal transmitter
- B2 (E120) : To (E28)
- B3 (E122) : Knock sensor



EL

HARNES LAYOUT

Engine Harness



- E201 : To E26
- E202 : To E27
- E203 : To E28
- E204 : Battery
- E205 : Fusible link block
- E206 : Body ground
- E207 : Alternator
- E208 : EGR and canister control solenoid valve
- E209 : Oil pressure switch
- E210 : Starter motor
- E211 : Vehicle speed sensor
- E212 : Back-up lamp switch (M/T models)
- E213 : Neutral position switch (M/T models)

HARNESS LAYOUT

NOTE

GF

MA

EW

IC

FC

FE

CL

WT

ST

PE

LS

MS

BR

ST

ST

ST

HA


EL

ICX

HARNES LAYOUT

Body Harness

LHD MODELS



HARNES LAYOUT

Body Harness (Cont'd)


Sub-harness	
A3	(81) : To (411)
A3	(82) : Body ground
B3	(83) : Heated seat LH
B3	(84) : Parking brake switch
C2	(85) : Headlamp aiming switch
B2	(86) : Door mirror control switch
B2	(87) : Front fog lamp switch
B3	(88) : Overdrive switch - A/T illumination
C2	(89) : Heated seat switch RH
C4	(90) : Heated seat switch LH
C3	(91) : To (22)
C3	(91D) : To (558)
B4	(919) : Door switch (Driver's side)
B4	(92) : Seat belt pre-tensioner (Driver's side)
C4	(918) : Body ground
C2	(916) : Condenser (For rear window defogger)
F2	(920) : Rear speaker RH
F3	(921) : Trunk room lamp
E3	(922) : Rear wiper motor
E2	(923) : Rear speaker LH
D3	(924) : To (71)
D4	(925) : To (72)
C2	(951) : To (463)
D2	(928) : To (73)
C3	(956) : To (813)
E3	(957) : Heated seat RH
E3	(958) : Door switch (Passenger side)
G3	(959) : Seat belt pre-tensioner (Passenger side)
G3	(963) : To (726)
G3	(964) : To (727)
F2	(965) : Not used
D2	(926) : Condenser (For rear window defogger)
D2	(927) : Rear window defogger (+)
F2	(929) : Rear window defogger (-)
E2	(924) : Body ground

EL

HARNESS LAYOUT

Body Harness (Cont'd)

IHD MODELS



HARNES LAYOUT

Body Harness (Cont'd)

G3	(81)	To (M1)	
G3	(82)	Body ground	
F3	(84)	Parking brake switch	
F2	(85)	Headlamp aiming switch (For Europe)	
F2	(86)	Door mirror control switch	
F2	(87)	Front fog lamp switch (For Europe)	
F3	(88)	Overdrive switch - A/T illumination	
E4	(81)	To (T2)	
E4	(82)	To (835)	
F4	(81)	Door switch (Driver's side)	
F3	(815)	Seat belt pre-tensioner (Driver's side) (For Europe)	
F3	(816)	Multi-remote control relay-1 (Except for Europe)	
E4	(817)	Multi-remote control relay-2 (Except for Europe)	
E3	(818)	Body ground	
E2	(819)	Condenser (For rear window defogger)	
G2	(820)	Rear speaker RH	
B3	(821)	Trunk room lamp	
B3	(822)	Rear wiper motor (Except for Australia)	
B2	(823)	Rear speaker LH	
D3	(824)	To (T1)	
D4	(825)	To (T2)	
E2	(817)	To (M83) (Models with ABS)	
D2	(85)	To (E5) (Models with ABS)	
D3	(824)	Body ground	
E3	(855)	To (811)	
C3	(826)	Door switch (Passenger side)	
C3	(827)	Seat belt pre-tensioner (Passenger side) (For Europe)	
B2	(828)	Body ground (Models with ABS)	
B3	(857)	To (T2) (Models with ABS)	
B3	(862)	ABS control unit (For ABS)	
B2	(865)	Not used (For Europe)	

Sub-harness

E2	(810)	Condenser (For rear window defogger)
D2	(813)	Rear window defogger (+)
C2	(810)	Rear window defogger (-)
C2	(813)	Body ground

SM
MA
EM
LC
EC
SE
GL
MT
AT
PD
EA
PA
RE
ST
22
ST
GA

EL


MOX

HARNES LAYOUT

Tail Harness

LHD MODELS

- (T1) : To (82A)
- (T2) : To (82Z)
- (T3) : High-mounted stop lamp
- (T4) : Back-up lamp RH
- (T5) : Trunk room lamp switch
- (T6) : Back-up lamp LH
- (T7) : Differential oil pump
- (T8) : Fuel tank gauge unit
- (T9) : Fuel pump
- (T10) : Rear skid sensor (for ABS)
- (T11) : Differential oil warning lamp switch
- (T12) : Differential oil temperature switch
- (T13) : Differential oil cooler relay-1
- (T14) : Differential oil cooler relay-2
- (T15) : Speed control amplifier
- (T16) : Rear combination lamp RH
- (T17) : Rear wiper relay
- (T18) : Body ground
- (T19) : Rear fog lamp
- (T20) : License plate lamp
- (T21) : Rear combination lamp LH
- (T22) : Power antenna timer
- (T23) : ABS control unit
- (T24) : To (82)
- (T25) : To (82A)





HARNESS LAYOUT

Tail Harness (Cont'd)

RHD MODELS


- (T1) : To (824)
- (T2) : To (825)
- (T3) : High-mounted stop lamp
- (T4) : Back-up lamp RH
- (T5) : Trunk room lamp switch
- (T6) : Trunk key cylinder switch (Except for Europe)
- (T7) : Back-up lamp LH
- (T8) : Differential oil pump (For Europe)
- (T9) : Fuel tank gauge unit
- (T10) : Fuel pump
- (T11) : Rear skid sensor (For ABS)
- (T12) : Differential oil warning lamp switch (For Europe)
- (T13) : Differential oil temperature switch (For Europe)
- (T14) : Differential oil cooler relay-1 (For Europe)
- (T15) : Differential oil cooler relay-2 (For Europe)
- (T16) : Speed control amplifier (For Europe)
- (T17) : Rear combination lamp RH
- (T18) : Rear wiper relay (Except for Australia)
- (T19) : Body ground
- (T20) : Rear fog lamp (For Europe)
- (T21) : License plate lamp
- (T22) : Rear combination lamp LH
- (T23) : Power antenna timer
- (T24) : To (861) (Models with ABS)



SEI 879T

HARNES LAYOUT

Room Lamp Harness




- (R1) : To (R5) (LHD models)
To (R15) (RHD models)
- (R2) : To sun roof motor assembly
- (R3) : Spot lamp
- (R4) : Interior lamp (Without sun roof)
- (R5) : Interior lamp (With sun roof)

HARNES LAYOUT


LHD MODELS

Air Bag and Seat Belt Pre-tensioner Harness



GN
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 HA
 RA
 ST
 RS
 BT
 HA
 EL
 DX

RHD MODELS




HARNES LAYOUT

Door Harness (LHD models)

FRONT LH


- (D1) To (M14)
- (D2) To (M15)
- (D3) Door speaker
- (D4) Power window regulator
- (D5) Door mirror defogger
- (D6) Door mirror
- (D8) Power window amplifier
- (D9) Power window main switch
- (D13) Lock knob switch



SEL883T

FRONT RH

- (D101) : To (M56)
- (D102) : To (M57)
- (D103) : Door speaker



- (D104) Power window regulator
- (D105) Door mirror defogger
- (D106) Door mirror
- (D109) Power window sub-switch
- (D113) Door lock actuator


SE1084T

HARNES LAYOUT

FRONT LH


Door Harness (RHD models)

- (D101) : To (M56)
- (D102) : To (M57)
- (D103) : Door speaker
- (D104) : Power window regulator
- (D105) : Door mirror defogger
- (D107) : Door mirror
- (D110) : Power window sub-switch
- (D111) : Key cylinder switch (Except for Europe)
- (D112) : Door lock actuator



SEL885T

FRONT RH



- (D1) : To (M14)
- (D2) : To (M15)
- (D3) : Door speaker
- (D4) : Power window regulator
- (D5) : Door mirror defogger
- (D7) : Door mirror
- (D8) : Power window amplifier
- (D9) : Power window main switch
- (D11) : Key cylinder switch (Except for Europe)
- (D12) : Door lock actuator (Except for Europe)
- (D13) : Lock knob switch (For Europe)

SEL886T

SUPER MULTIPLE JUNCTION (SMJ)


Disconnecting and Connecting

- SMJ is located on left side of dash.
- To disconnect SMJ, loosen fixing bolt.

- To install SMJ, tighten bolts until orange "full-tight" mark appears and then retighten to specified torque as required.
□: 3 - 5 N·m
(0.3 - 0.5 kg-m, 2.2 - 3.6 ft-lb)

CAUTION:


Do not overtighten bolts, otherwise, they may be damaged.



Terminal Arrangement


LHD MODELS

MAIN HARNESS



RHD MODELS



MAIN HARNESS



SUPER MULTIPLE JUNCTION (SMJ)


Terminal Arrangement (Cont'd)

ENGINE CONTROL HARNESS



MAIN HARNESS

ECM (ECCS CONTROL MODULE)




View from harness side

A/T CONTROL UNIT



View from harness side

SMART ENTRANCE CONTROL UNIT



View from harness side